

---

# LCD Television

## Service Manual

---

**Chassis:** MTK5657

**Product:**

LTDN40K321UWAU 、 LTDN50K321UWT 、  
LTDN55K321UWT 、 LTDN58K321UWAU

**Ver 1.0**

**Hisense Electric Co., Ltd.**

**August, 2015**

---

# Contents

<b>Contents</b> .....	- 2 -
<b>Service Manual</b> .....	- 3 -
1. Precautions and notices.....	- 3 -
1.1 Warning.....	- 4 -
1.2 Notes.....	- 7 -
2. Product Function Specifications .....	- 9 -
2.1 TV Front and Rear .....	- 9 -
2.2 TV basic configure.....	- 11 -
2.3 Main board and power board.....	- 11 -
2.4 Specification .....	- 15 -
2.5 Remote control.....	- 16 -
3. Factory/Service OSD Menu and Adjustment.....	- 17 -
3.1 How to enter the Factory OSD Menu .....	- 17 -
3.2 Factory OSD Menu.....	- 19 -
3.3 Designer Menu.....	- 22 -
4. Software Upgrading.....	- 25 -
4.1 USB Upgrdaing .....	- 25 -
4.2 USB upgrade defeat.....	- 27 -
4.3 Upgrading with the FlashTool v0.6.9.1.exe.....	- 29 -
5. Trouble shooting.....	- 33 -
5.1 Troubleshooting for Remote Control.....	- 34 -
5.2 Troubleshooting for Function Key.....	- 35 -
5.3 TV won't Power On.....	- 36 -
5.4 Troubleshooting for Audio.....	- 37 -
5.5 Troubleshooting for TV/VGA/HDMI input.....	- 38 -
5.6 Troubleshooting for YPbPr input.....	- 39 -
5.7 Troubleshooting for Video input.....	- 40 -
6. Signals Block Diagram and power assign: .....	- 40 -
7. Schematic circuit diagram .....	- 40 -
8. Explode View.....	- 40 -

---

# Service Manual

## 1. Precautions and notices

BEFORE SERVICING THE LCD TV, READ THE SAFETY PRECAUTIONS IN THIS MANUAL.

USE ONLY MANUFACTURER SPECIFIED REPLACEMENT PARTS WHEN SERVICING.

USE OF NON-AUTHORIZED PARTS WILL VOID THE MANUFACTURE'S WARRANTY

Proper service and repair is important to the safe, reliable operation of all Hisense Equipment. The service procedures recommended by Hisense and described in this Service Guide are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment and pose risk of personal injury

. It is also important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Service should only be performed by an experienced electronics

---

technician trained in the proper Television safety and service methods and procedures  
Hereafter throughout this manual, HISENSE will be referred to.

## **1.1 Warning**

### 1.1.1

Critical components having special safety characteristics are identified with a ▲ by the Ref. No. in the parts list. Use of non-manufacturer's recommended parts may create shock, fire, or other hazards. Under no circumstances should the original design be modified or altered without written permission from RCA. Hisense Eassumes no liability, express or implied, arising out of any unauthorized modification of design. Servicetech assumes all liability.

**DANGER CAUTION**

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE GUIDE.

### 1.1.2.

All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, be sure to use anti-static table mats and properly use a grounding wrist stra. Keep components and tools also at this same potential.

---

IMPORTANT:

Always disconnect the power cord from AC outlet before replacing parts or modules.

1.1.3

To prevent electrical shock, use only a properly grounded 3 prong outlet or extension cord.

1.1.4

When replacement parts are required, be sure to use replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards and will void the manufacturer's warranty.

1.1.5

Safety regulations require that after a repair the set must be returned in its original condition. In addition, prior to closing set, check that:

-Note:

>All wire harnesses and flex cables are properly routed and secured with factory tape and/or mounted cable clamps.

> All cables and connectors are properly insulated and do not have any bare wires/lead exposed

1.1.6

(1) Do not supply a voltage higher than that specified to this product. This may

---

damage the product and may cause a fire.

(2) Do not use this product:

> High humidity areas

> In an area where any water could enter or splash into the unit.

High humidity and water could damage the product and cause fire.

(3) If a foreign substance (such as water, metal, or liquid) gets inside the panel module, immediately turn off the power. Continuing to use the product may cause fire or electric shock.

(4) If the product emits smoke, and abnormal smell, or makes an abnormal sound, immediately turn off the power. Continuing to use the product, it may cause fire or electric shock.

(5) Do not pull out or insert the power cable from/to an outlet with wet hands. It may cause electric shock.

(6) Do not damage or modify the power cable. It may cause fire or electric shock.

(7) If the power cable is damaged, or if the connector is loose, do not use the product: otherwise, this can lead to fire or electric shock.

(8) If the power connector or the connector of the power cable becomes dirty or dusty, wipe it with a dry cloth. Otherwise, this can lead to fire.

(9) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over

---

## 1.2 Notes

Notes on Safe Handling of the LCD panel and during service

The work procedures shown with the Note indication are important for ensuring the safety of the product and the servicing work. Be sure to follow these instructions.

- Before starting the work, secure a sufficient working space.
- At all times other than when adjusting and checking the product, be sure to turn OFF the POWER Button and disconnect the power cable from the power source of the TV during servicing.
- To prevent electric shock and breakage of PC board, start the servicing work at least 30 seconds after the main power has been turned off. Especially when installing and removing the power board, start servicing at least 2 minutes after the main power has been turned off.
- While the main power is on, do not touch any parts or circuits other than the ones specified. If any connection other than the one specified is made between the measuring equipment and the high voltage power supply block, it can result in electric shock or may trip the main circuit breaker. When installing the LCD module in, and removing it from the packing carton, be sure to have at least two persons perform the work.
- When the surface of the panel comes into contact with the cushioning materials, be sure to confirm that there is no foreign matter on top of the cushioning materials before the surface of the panel comes into contact with the cushioning materials. Failure to observe this precaution may result in, the surface of the panel being scratched by foreign

---

matter.

- Be sure to handle the circuit board by holding the large parts as the heat sink or transformer. Failure to observe this precaution may result in the occurrence of an abnormality in the soldered areas.
- Do not stack the circuit boards. Failure to observe this precaution may result in problems resulting from scratches on the parts, the deformation of parts, and short-circuits due to residual electric charge.
- Perform a safety check when servicing is completed. Verify that the peripherals of the serviced points have not undergone any deterioration during servicing. Also verify that the screws, parts and cables removed for servicing purposes have all been returned to their proper locations in accordance with the original setup.



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock.




The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the set.

## 2. Product Function Specifications

### 2.1 TV Front and Rear

#### TV Front




Item	Description
<b>Remote sensor</b>	Receives remote signals from the remote control. Do not put anything near the sensor, as its function may be affected.
<b>Power indicator</b>	The light is red in standby mode.
<b>MENU</b>	Select among the different input signal sources and put the TV in standby mode.
<b>Source</b>	Select among the different input signal sources.
<b>VOL + / -</b>	Adjust the volume.
<b>CH + / -</b>	Select the channel.
<b>Power button</b> 	Turn on the TV or put the TV in standby mode. <b>Caution:</b> The TV continues to receive power even in standby mode. Unplug the power cord to disconnect power.

#### NOTES

- The Picture is Only for Reference.
- Powering on the TV requires several seconds to load program. Do not rapidly turn the TV off as it may cause the TV to work abnormally.

# TV Rear & Making Connections

## TV Rear



### NOTES

- Check the jacks for position and type before making any connections. Loose connections can result in image or color problems. Make sure that all connections are tight and secure.
- Not all A/V devices have the ability to connect to a TV, please refer to the user's manual of your A/V device for compatibility and connections procedure.
- Before connecting external equipment, remove the mains plug from the wall socket. This may cause electric shock.

## 2.2 TV basic configure

TV Model	Panel Mode	LVDS (Main-Panel)	Main board	Power board
LTDN40K321UWAU	HD396DU-B01	FFC-V-51CP-275-Z1\275.0\ROH	RSAG2.908.6135-02\ROH	RSAG2.908.5687-46\ROH
LTDN50K321UWT	HD500DU-B01	FFC-51CP-260-1-Z1\260.0\RO	RSAG2.908.6135-02\ROH	RSAG2.908.5687-28\ROH
LTDN55K321UWAU	HD550DU-B51	FFC-51CP-350-1-Z1\350.0\ROH	RSAG2.908.6135-02\ROH	RSAG2.908.6106-03\ROH
LTDN58K321UWAU	HD580DU-B01	FFC-V-51CP-341-1-Z1\341\ROH	\RSAG2.908.6135-02\ROH	RSAG2.908.6106-08\ROH

## 2.3 Main board and power board

**Main board :RSAG7.820. 6135/ROH layout:**  
The TOP



Detail terminals function see page 10—The TV Rear

---


Side connectors



Bottom connectors



power board:5687 :



LTDN55K321UWT & LTDN58K321UWAU power board:RSAG7.820.6106/ROH



## 2.4 Specification


☑ Features, appearance and specifications are subject to change without notice.

If you encountered difficulty when setting up your TV, we suggest you refer to the troubleshooting tips in the User Manual.

Model Name		50K321UW	55K321UW	40K321UW	58K321UW
Dimension	Without Stand(mm)	Width: 1124 Height: 649 Depth: 82	Width: 1239 Height: 717 Depth: 83	Width: 902 Height: 515 Depth: 86	Width: 1297 Height: 755 Depth: 84
	With Stand (mm)	Width: 1124 Height: 702 Depth: 247	Width: 1239 Height: 771 Depth: 262	Width: 902 Height: 560 Depth: 192	Width: 1297 Height: 809 Depth: 263
Weight	Without Stand(kg)	13.5	16.5	8.7	18.5
	With Stand (kg)	13.8	17.3	8.9	19
Active Screen Size(Diagonal)		50 inches	55 inches	40 inches	58 inches
Screen resolution		3840×2160	3840×2160	3840×2160	3840×2160
Audio power		10W +10W	10W +10W	7W +7W	10W +10W

Power consumption		Please refer to the rating label.
Power supply		100V - 240V~ 50Hz/60Hz
Receiving systems	Analog	PAL-D/K, B/G, I SECAM-D/K, B/G, L/L'
	Digital	DVB-T/T2, DVB-C
Environmental conditions		Temperature: 5°C - 45°C Humidity: 20% - 80% RH Atmospheric pressure: 86 kPa - 106 kPa
Component Input		480 I / 60 Hz, 480 P / 60 Hz, 576 I /50 Hz, 576 P /50 Hz, 720 P / 50 Hz, 720 P / 60 Hz, 1080 I / 50 Hz, 1080 I / 60 Hz, 1080 P / 50 Hz, 1080 P / 60 Hz
HDMI Input		60 Hz (640×480, 800×600, 1024×768) 60 Hz (480 I, 480 P, 720 P, 1080 I, 1080 P) 50 Hz (576 I, 576 P, 720 P, 1080 I, 1080 P) 24 Hz 30 Hz (3840×2160 HDMI 1,2) 24 Hz 30 Hz 50 Hz 60 Hz (3840×2160 HDMI 3,4)

# Remote Control



---

### 3. Factory/Service OSD Menu and Adjustment

#### 3.1 How to enter the Factory OSD Menu

##### . With user's RC

1. Power TV on
2. Press  button on RC and call up “Quick Setup” Menu.
3. **Quick Setup** -> **ALL**-> then press “>” button to ensure on RC.
4. Select **Sound**-> **Advanced Audio setting** -> **Balance**
5. When Balance is “0” , Input 1->9->6->9 in sequence.

Note: If necessary, re-enter number keys.

6. Factory OSD appears.
7. DC power off and power on the TV, which can exit Factory OSD.


##### Figures as following:




Next



Next




Next



Next

When Balance is “0” ,input figures “1->9->6->9” in sequence.

### 3.2 Factory OSD Menu



### 3.2.1 White Balance


Note: Different source has different WB values. Before adjusting, please change to desired source.

White Balance		R Gain	128
Signal Prefabricate		G Gain	128
Options		B Gain	125
Clean Chip		R Offset	128
Pattern Test		G Offset	128
Write Keys		B Offset	128
Version	TN75.V00.K700.XWT3D	Color Temp	Standard
	01.00a.F0624	Panel	B1
MAC	08:D0:B7:21:1C:30		
HDCP2.2 key	OK		
CI + key	51007D885B6B2130		
ESN	HISETVK32000000		
	0000000000000000		
	000000002001		

### 3.2.1 Signal prefabricate

Factory	Design
White Balance	
Signal Prefabricate	Huang Dao
Options	Huang Dao New
Clean Chip	Qing Dao
Pattern Test	Gui Yang
Write Keys	Jiang Men
Version	Egypt
	South Africa
MAC	Algeria
HDCP2.2 key	Syria
CI + key	Malaysia
ESN	Iran
	Russia
	Poland

### 3.2.3 Factory Option



	Item	Default	Options	Notes
<b>1</b>	<b>MODE</b>	<b>M</b>	<b>M, U</b>	M-Can enter factory mode with factory RC or user RC. U-Can enter factory mode only with user' s RC.

Note: ToFac “M” is only used for factory production.


**Clean Chip**

**Write keys**

**Version**

**MAC**

**HDCP2.2 key**




**Note: The factory menu date varies according to different sources. In case changing the factory data by error, you can choose to "Clean Protected", by which you can resume the default value.**

**To clear the EEPROM:**

- a. Select the item "**Clean chip**".
- b. Press VOL+ button to clear the EEPROM data.
- c. Close the OSD menu after 5 seconds.
- d. Restart the TV.

### 3.3 Designer Menu



If the TV has 3D function, then Design menu has 3d delay (+100) and 3d delay (+1) items.as above figure. otherwise has not.


**Video:**




**Picture mode**



**Audio**



## Audio mode



### Notice:

Above “Factory/Service OSD Menu” is reference for chassis MTK5657 , please refer to the actual units to determine the appearances.

## 4. Software Upgrading

### 4.1 USB Upgrading

#### 4.1.1 USB main software upgrading directly

The main software can be upgraded by USB Disk.

- First, copy the upgrade\_loader.pkg file to USB Disk;
- Second, make sure there is no other .pkg file in the root directory of USB Disk ,and no TCON software ,such for: 6M40.bin ; 6M50.bin ; FRC.bin
- Insert USB Disk to TV USB port, and then power on the TV. at the same time press standby button  on the remote control for about 5-10s,until pop the following update interface.



- The TV will identify the software and upgrade automatically.
- After update success, TV can automatically start.

#### **4.1.2 USB TCON software upgrading directly**


---

## 4.2 USB upgrade defeat

If USB upgrading defeat, TV crashed. We must burn the emmc flash program file“ \*.bin ”to the flash IC first. second USB disk to upgrade the **upgrade\_loader.pkg** file.

### Hardware connecting

Connect the unit to your pc with a USB-to-serial port cable. USB port connects to your PC and serial port to the TV's RS232 port. As following




Connect to the TV  
earphone port

USB Connect to  
the PC

### 4.2.1 Install the driver

#### 4.2.1 Install the bebug board driver for first use MTK FlashTool.

Double click the icon , install the driver.



#### Note:

X64.exe is fit for 64bit system configure of the computer.

X86.exe is fit for 32bit system configure of the computer.




Select the default value, the driver will be installed step by step.




---

### 4.3 Upgrading with the FlashTool v0.6.9.1.exe

1、FlashTool is a green program needing no installation. After Connect the unit to your pc with a USB-to-serial port cable, run FlashTool v0.6.9.1.exe. Please refer to the following steps to set.




How to choose Communicate port and flash baud rate? See the following instruction..




Open “Device Manager” and find which port is connected with the TV. In above picture, COM4 is connected to the TV, so, select “COM4” and if COM6 is connected to the TV, so select “COM6”. Select the right baud rate according to chip model. For this unit( chip model is MT5657), select 115200.


2、AC power on the TV ,then Click  to connect, if connect successfully then button  from red turn green.



Click , bounce the following dialog box. Load Bin File: find the upgrading program file, his\_m1v1\_us\_secure\_emmcbboot.bin.

Press "Upgrade" button and start upgrading., if update defeat, try again.






## 5. Trouble shooting

When there is something wrong with your TV, you can try turning off the TV and then restart it. You can also operate according to the follow chart. If the problems still can't be solved, please contact the profession technician.

No sound or picture	<ol style="list-style-type: none"> <li>1. Check if the power line is in the outlet and if it has electricity.</li> <li>2. Check if you have pressed Power button on the TV or Power button on the remote control</li> <li>3. Check the setting of picture brightness and contrast.</li> <li>4. Check the volume.</li> </ol>
The picture is normal but there is no sound	<ol style="list-style-type: none"> <li>1. Check the volume.</li> <li>2. Check if Mute mode is set.</li> </ol>
No picture and white or black picture	<ol style="list-style-type: none"> <li>1. Adjust Picture Setting.</li> <li>2. Check Color System.</li> </ol>
The sound and picture are interfered	<ol style="list-style-type: none"> <li>1 Try to find the appliance affecting TV set, and move it far away from the TV set.</li> <li>2. Try to insert the power plug of the TV set into another outlet.</li> </ol>
Unclear picture or picture with snow	<ol style="list-style-type: none"> <li>1. Check the direction, position and connection of your antenna.</li> <li>2. Adjust the direction of your antenna or reset or fine tune the channel</li> </ol>
The remote control does not work	<ol style="list-style-type: none"> <li>1. Change the batteries in the remote control.</li> <li>2. Clean the upper side of the remote control (radiating window)</li> <li>3. Check the contacting points of the batteries.</li> <li>4. Check if there is obstruction between the remote control and the monitor.</li> <li>5. Check if the batteries are correctly installed.</li> </ol>
H/V strip or the picture shaking	Check if there is an interfering source nearby, such as appliance or electric tools.
The cabinet of the TV makes "Click" sound	makes "Click" sound"Sometimes the room temperature change can cause the television cabinet to inflate or contra, which makes this sound. This does not mean the TV breaks down.


---

## 5.1 Troubleshooting for Remote Control




---

## 5.2 Troubleshooting for Function Key




### 5.3 TV won't Power On




---

## 5.4 Troubleshooting for Audio




---

## 5.5 Troubleshooting for TV/VGA/HDMI input




---

## 5.6 Troubleshooting for YPbPr input



---


## 5.7 Troubleshooting for Video input






### 6. Signals Block Diagram and power assign:

### 7. Schematic circuit diagram

### 8. Explode View



MT5657



# GPIO LIST

PIN NAME	Function Definition	GPIO Function
CI_A0	CI Interface	CI_A0 (GPIO_0)
CI_A1	CI Interface	CI_A1 (GPIO_1)
CI_A2	CI Interface	CI_A2 (GPIO_2)
CI_A3	CI Interface	CI_A3 (GPIO_3)
CI_A4	CI Interface	CI_A4 (GPIO_4)
CI_A5	CI Interface	CI_A5 (GPIO_5)
CI_A6	CI Interface	CI_A6 (GPIO_6)
CI_A7	CI Interface	CI_A7 (GPIO_7)
CI_A8	CI Interface	CI_A8 (GPIO_8)
CI_A9	CI Interface	CI_A9 (GPIO_9)
CI_A10	CI Interface	CI_A10 (GPIO_10)
CI_A11	CI Interface	CI_A11 (GPIO_11)
CI_A12	CI Interface	CI_A12 (GPIO_12)
CI_A13	CI Interface	CI_A13 (GPIO_13)
CI_A14	CI Interface	CI_A14 (GPIO_14)
CI_MCLKI	CI Interface	CI_MCLKI (GPIO_15)
CI_MIVAL	CI Interface	CI_MIVAL (GPIO_16)
CI_MISTR	CI Interface	CI_MISTR (GPIO_17)
CI_MDIO	CI Interface	CI_MDIO (GPIO_18)
CI_MDI1	CI Interface	CI_MDI1 (GPIO_19)
CI_MDI2	CI Interface	CI_MDI2 (GPIO_20)
CI_MDI3	CI Interface	CI_MDI3 (GPIO_21)
CI_MDI4	CI Interface	CI_MDI4 (GPIO_22)
CI_MDI5	CI Interface	CI_MDI5 (GPIO_23)
CI_MDI6	CI Interface	CI_MDI6 (GPIO_24)
CI_MDI7	CI Interface	CI_MDI7 (GPIO_25)
CI_D0	CI Interface	CI_D0 (GPIO_26)
CI_D1	CI Interface	CI_D1 (GPIO_27)
CI_D2	CI Interface	CI_D2 (GPIO_28)
CI_D3	CI Interface	CI_D3 (GPIO_29)
CI_D4	CI Interface	CI_D4 (GPIO_30)
CI_D5	CI Interface	CI_D5 (GPIO_31)
CI_D6	CI Interface	CI_D6 (GPIO_32)
CI_D7	CI Interface	CI_D7 (GPIO_33)
CI_MDO0	CI Interface	CI_MDO0 (GPIO_34)
CI_MDO1	CI Interface	CI_MDO1 (GPIO_35)
CI_MDO2	CI Interface	CI_MDO2 (GPIO_36)
CI_MDO3	CI Interface	CI_MDO3 (GPIO_37)
CI_MDO4	CI Interface	CI_MDO4 (GPIO_38)
CI_MDO5	CI Interface	CI_MDO5 (GPIO_39)
CI_MDO6	CI Interface	CI_MDO6 (GPIO_40)
CI_MDO7	CI Interface	CI_MDO7 (GPIO_41)
GPIO_42	CI Over Current Protect	CI_OCP
GPIO_43	USB Power Enable	USB_PWR_EN1
GPIO_44	USB Power Enable	USB_PWR_EN2
GPIO_45	---	---
GPIO_46	SYSTEM EEPROM write protect	SYS_EEPROM_WP
GPIO_47	CI Interface	CI_RESET
GPIO_48	CI POWER CONTROL	CI_POWER_EN
GPIO_49	---	---
GPIO_50	VB1	VB1_REQ
GPIO_51	---	---
GPIO_52	---	---
GPIO_53	VB1	VB1_HTPDN_OSD
GPIO_54	VB1	VB1_LOCKN_OSD
GPIO_55	---	---
GPIO_56	JTAG	JTDO
GPIO_57	JTAG	JTCK
GPIO_58	JTAG	JTMS
GPIO_59	JTAG	JTDI
GPIO_60	JTAG	JTRST#
GPIO_61	---	---
GPIO_62	---	---
GPIO_63	SDIO POWER CONTROL	SDIO_PWR_CTRL
GPIO_64	---	---
GPIO_65	---	---
GPIO_66	USB Power Enable	USB_PWR_EN0

PCBA version ID

PIN NAME	Function define	GPIO Function
ADIN0_SRV	Function Select	SCART_FS
ADIN1_SRV	KEY_PAD	KEY_PAD0
ADIN2_SRV	KEY_PAD	KEY_PAD1
ADIN3_SRV	MHL Over Current Protect	USB_MHL_OC
ADIN4_SRV	USB over current detect	USB_OC_P0/P1
ADIN5_SRV	USB over current detect	USB_OC_P2/P3
ADIN6_SRV	Demod	RF_AGCI
ADIN7_SRV	SD Card Detect	SD_DET
ADIN8_SRV	---	---
ADIN9_SRV	---	---





PCBA version ID

PIN NAME	Function define	GPIO Function
OPWM0	---	---
OPWM1	Backlight DIMMING	BL_DIMMING
OPWM2	LNA_AGC switch	LNASW_AGC SW
OPWM3	---	---
OPWM4	---	---
OPWM5	---	---
OPWM6	---	---
OPWM7	---	---
OPWM8	---	---










PIN NAME	Function define	GPIO Function
LED_PWM0	Strapping / Standby mode LED	Strap[3] / LED_PWM0
LED_PWM1	Strapping / Power On LED	Strap[2] / LED_PWM1
LED_PWM2	Strapping	Strap[1]
LED_PWM3	---	---

PIN NAME	Function define	GPIO Function
OPCTRL0	PHY LED	PHYLED2
OPCTRL1	PHY LED	PHYLED3
OPCTRL2	SCART	AV_LINK
OPCTRL3	Fast Boot Control	FB_PWR_CTRL
OPCTRL4	Backlight Control	BL_ON/OFF
OPCTRL5	PWM AMP MUTE	AMP_MUTE
OPCTRL6	Headphone Detect	HP_DET
OPCTRL7	---	---
OPCTRL8	MHL_PWR_EN	MHL_PWR_EN
OPCTRL9	LVDS Power Control	LVDS_PWR_EN
OPCTRL10	USB Power Enable	USB_PWR_EN3
OPCTRL11	Audio Mute Control	MUTE_CTL

















Main board circuit 0135







- (15) BL\_DIMMING <-> BL\_DIMMING
- (15) BL\_ONOFF <-> BL\_ONOFF
- (5) OPWRSB <-> OPWRSB
- (8) 3D\_SG/PWM2 <-> 3D\_SG/PWM2
- (8) PANEL\_3D\_EN <-> PANEL\_3D\_EN
- (8) 3D\_LR/PWM1 <-> 3D\_LR/PWM1
- (8) LDC\_PWM <-> LDC\_PWM




散热器贴N1 (主芯片) 上





- (4) OPWRSB
- (5) SYS\_EEPROM\_WP
- (15) LED\_PWM1
- (15) LED\_PWM0
- (15) LED\_PWM2
- (6,8) OSCL0
- (6,8) OSDAD
- (8) OSCL1
- (8) OSDAT
- (8) OIRI
- OPWRSB
- SYS\_EEPROM\_WP
- LED\_PWM1
- LED\_PWM2
- OSCL0
- OSDAD
- OSCL1
- OSDAT
- OIRI



### SPEAKER Amplifier



Main board circuit 0135














AR80	AE4	AD1	ARD0M0
AR81	AE5	AD2	ARD0M1
AR82	AE6	AD3	ARD0M2
AR83	AE7	AD4	ARD0M3
AR84	AE8	AD5	ARD0M4
AR85	AE9	AD6	ARD0M5
AR86	AE10	AD7	ARD0M6
AR87	AE11	AD8	ARD0M7
AR88	AE12	AD9	ARD0M8
AR89	AE13	AD10	ARD0M9
AR90	AE14	AD11	ARD0M10
AR91	AE15	AD12	ARD0M11
AR92	AE16	AD13	ARD0M12
AR93	AE17	AD14	ARD0M13
AR94	AE18	AD15	ARD0M14
AR95	AE19	AD16	ARD0M15
AR96	AE20	AD17	ARD0M16
AR97	AE21	AD18	ARD0M17
AR98	AE22	AD19	ARD0M18
AR99	AE23	AD20	ARD0M19
AR100	AE24	AD21	ARD0M20
AR101	AE25	AD22	ARD0M21
AR102	AE26	AD23	ARD0M22
AR103	AE27	AD24	ARD0M23
AR104	AE28	AD25	ARD0M24
AR105	AE29	AD26	ARD0M25
AR106	AE30	AD27	ARD0M26
AR107	AE31	AD28	ARD0M27
AR108	AE32	AD29	ARD0M28
AR109	AE33	AD30	ARD0M29
AR110	AE34	AD31	ARD0M30
AR111	AE35	AD32	ARD0M31
AR112	AE36	AD33	ARD0M32
AR113	AE37	AD34	ARD0M33
AR114	AE38	AD35	ARD0M34
AR115	AE39	AD36	ARD0M35
AR116	AE40	AD37	ARD0M36
AR117	AE41	AD38	ARD0M37
AR118	AE42	AD39	ARD0M38
AR119	AE43	AD40	ARD0M39
AR120	AE44	AD41	ARD0M40
AR121	AE45	AD42	ARD0M41
AR122	AE46	AD43	ARD0M42
AR123	AE47	AD44	ARD0M43
AR124	AE48	AD45	ARD0M44
AR125	AE49	AD46	ARD0M45
AR126	AE50	AD47	ARD0M46
AR127	AE51	AD48	ARD0M47
AR128	AE52	AD49	ARD0M48
AR129	AE53	AD50	ARD0M49
AR130	AE54	AD51	ARD0M50
AR131	AE55	AD52	ARD0M51
AR132	AE56	AD53	ARD0M52
AR133	AE57	AD54	ARD0M53
AR134	AE58	AD55	ARD0M54
AR135	AE59	AD56	ARD0M55
AR136	AE60	AD57	ARD0M56
AR137	AE61	AD58	ARD0M57
AR138	AE62	AD59	ARD0M58
AR139	AE63	AD60	ARD0M59
AR140	AE64	AD61	ARD0M60
AR141	AE65	AD62	ARD0M61
AR142	AE66	AD63	ARD0M62
AR143	AE67	AD64	ARD0M63
AR144	AE68	AD65	ARD0M64
AR145	AE69	AD66	ARD0M65
AR146	AE70	AD67	ARD0M66
AR147	AE71	AD68	ARD0M67
AR148	AE72	AD69	ARD0M68
AR149	AE73	AD70	ARD0M69
AR150	AE74	AD71	ARD0M70
AR151	AE75	AD72	ARD0M71
AR152	AE76	AD73	ARD0M72
AR153	AE77	AD74	ARD0M73
AR154	AE78	AD75	ARD0M74
AR155	AE79	AD76	ARD0M75
AR156	AE80	AD77	ARD0M76
AR157	AE81	AD78	ARD0M77
AR158	AE82	AD79	ARD0M78
AR159	AE83	AD80	ARD0M79
AR160	AE84	AD81	ARD0M80
AR161	AE85	AD82	ARD0M81
AR162	AE86	AD83	ARD0M82
AR163	AE87	AD84	ARD0M83
AR164	AE88	AD85	ARD0M84
AR165	AE89	AD86	ARD0M85
AR166	AE90	AD87	ARD0M86
AR167	AE91	AD88	ARD0M87
AR168	AE92	AD89	ARD0M88
AR169	AE93	AD90	ARD0M89
AR170	AE94	AD91	ARD0M90
AR171	AE95	AD92	ARD0M91
AR172	AE96	AD93	ARD0M92
AR173	AE97	AD94	ARD0M93
AR174	AE98	AD95	ARD0M94
AR175	AE99	AD96	ARD0M95
AR176	AE100	AD97	ARD0M96
AR177	AE101	AD98	ARD0M97
AR178	AE102	AD99	ARD0M98
AR179	AE103	AD100	ARD0M99
AR180	AE104	AD101	ARD0M100
AR181	AE105	AD102	ARD0M101
AR182	AE106	AD103	ARD0M102
AR183	AE107	AD104	ARD0M103
AR184	AE108	AD105	ARD0M104
AR185	AE109	AD106	ARD0M105
AR186	AE110	AD107	ARD0M106
AR187	AE111	AD108	ARD0M107
AR188	AE112	AD109	ARD0M108
AR189	AE113	AD110	ARD0M109
AR190	AE114	AD111	ARD0M110
AR191	AE115	AD112	ARD0M111
AR192	AE116	AD113	ARD0M112
AR193	AE117	AD114	ARD0M113
AR194	AE118	AD115	ARD0M114
AR195	AE119	AD116	ARD0M115
AR196	AE120	AD117	ARD0M116
AR197	AE121	AD118	ARD0M117
AR198	AE122	AD119	ARD0M118
AR199	AE123	AD120	ARD0M119
AR200	AE124	AD121	ARD0M120
AR201	AE125	AD122	ARD0M121
AR202	AE126	AD123	ARD0M122
AR203	AE127	AD124	ARD0M123
AR204	AE128	AD125	ARD0M124
AR205	AE129	AD126	ARD0M125
AR206	AE130	AD127	ARD0M126
AR207	AE131	AD128	ARD0M127
AR208	AE132	AD129	ARD0M128
AR209	AE133	AD130	ARD0M129
AR210	AE134	AD131	ARD0M130
AR211	AE135	AD132	ARD0M131
AR212	AE136	AD133	ARD0M132
AR213	AE137	AD134	ARD0M133
AR214	AE138	AD135	ARD0M134
AR215	AE139	AD136	ARD0M135
AR216	AE140	AD137	ARD0M136
AR217	AE141	AD138	ARD0M137
AR218	AE142	AD139	ARD0M138
AR219	AE143	AD140	ARD0M139
AR220	AE144	AD141	ARD0M140
AR221	AE145	AD142	ARD0M141
AR222	AE146	AD143	ARD0M142
AR223	AE147	AD144	ARD0M143
AR224	AE148	AD145	ARD0M144
AR225	AE149	AD146	ARD0M145
AR226	AE150	AD147	ARD0M146
AR227	AE151	AD148	ARD0M147
AR228	AE152	AD149	ARD0M148
AR229	AE153	AD150	ARD0M149
AR230	AE154	AD151	ARD0M150
AR231	AE155	AD152	ARD0M151
AR232	AE156	AD153	ARD0M152
AR233	AE157	AD154	ARD0M153
AR234	AE158	AD155	ARD0M154
AR235	AE159	AD156	ARD0M155
AR236	AE160	AD157	ARD0M156
AR237	AE161	AD158	ARD0M157
AR238	AE162	AD159	ARD0M158
AR239	AE163	AD160	ARD0M159
AR240	AE164	AD161	ARD0M160
AR241	AE165	AD162	ARD0M161
AR242	AE166	AD163	ARD0M162
AR243	AE167	AD164	ARD0M163
AR244	AE168	AD165	ARD0M164
AR245	AE169	AD166	ARD0M165
AR246	AE170	AD167	ARD0M166
AR247	AE171	AD168	ARD0M167
AR248	AE172	AD169	ARD0M168
AR249	AE173	AD170	ARD0M169
AR250	AE174	AD171	ARD0M170
AR251	AE175	AD172	ARD0M171
AR252	AE176	AD173	ARD0M172
AR253	AE177	AD174	ARD0M173
AR254	AE178	AD175	ARD0M174
AR255	AE179	AD176	ARD0M175
AR256	AE180	AD177	ARD0M176
AR257	AE181	AD178	ARD0M177
AR258	AE182	AD179	ARD0M178
AR259	AE183	AD180	ARD0M179
AR260	AE184	AD181	ARD0M180
AR261	AE185	AD182	ARD0M181
AR262	AE186	AD183	ARD0M182
AR263	AE187	AD184	ARD0M183
AR264	AE188	AD185	ARD0M184
AR265	AE189	AD186	ARD0M185
AR266	AE190	AD187	ARD0M186
AR267	AE191	AD188	ARD0M187
AR268	AE192	AD189	ARD0M188
AR269	AE193	AD190	ARD0M189
AR270	AE194	AD191	ARD0M190
AR271	AE195	AD192	ARD0M191
AR272	AE196	AD193	ARD0M192
AR273	AE197	AD194	ARD0M193
AR274	AE198	AD195	ARD0M194
AR275	AE199	AD196	ARD0M195
AR276	AE200	AD197	ARD0M196
AR277	AE201	AD198	ARD0M197
AR278	AE202	AD199	ARD0M198
AR279	AE203	AD200	ARD0M199
AR280	AE204	AD201	ARD0M200
AR281	AE205	AD202	ARD0M201
AR282	AE206	AD203	ARD0M202
AR283	AE207	AD204	ARD0M203
AR284	AE208	AD205	ARD0M204
AR285	AE209	AD206	ARD0M205
AR286	AE210	AD207	ARD0M206
AR287	AE211	AD208	ARD0M207
AR288	AE212	AD209	ARD0M208
AR289	AE213	AD210	ARD0M209
AR290	AE214	AD211	ARD0M210
AR291	AE215	AD212	ARD0M211
AR292	AE216	AD213	ARD0M212
AR293	AE217	AD214	ARD0M213
AR294	AE218	AD215	ARD0M214
AR295	AE219	AD216	ARD0M215
AR296	AE220	AD217	ARD0M216
AR297	AE221	AD218	ARD0M217
AR298	AE222	AD219	ARD0M218
AR299	AE223	AD220	ARD0M219
AR300	AE224	AD221	ARD0M220




### DDR3#1



### DDR3#2









Main board circuit: 6135










HDMI_CEC	R387	CEC	G24	N1-6	HDMI_CEC	HDMI_0_RX_0	A20	RX_0_0
HDMI_0_SCL	F26	F26	F26	HDMI_0_SCL	HDMI_0_RX_0B	B20	RX_0_0B	
HDMI_1_SCL	G30	G30	G30	HDMI_1_SCL	HDMI_0_RX_1	A19	RX_0_1	
HDMI_2_SCL	G31	G31	G31	HDMI_2_SCL	HDMI_0_RX_1B	A18	RX_0_2	
HDMI_3_SCL	D34	D34	D34	HDMI_3_SCL	HDMI_0_RX_2	B18	RX_0_2B	
HDMI_0_SDA	F27	F27	F27	HDMI_0_SDA	HDMI_0_RX_2B	A21	RX_0_C	
HDMI_1_SDA	C28	C28	C28	HDMI_1_SDA	HDMI_0_RX_CB	B21	RX_0_CB	
HDMI_2_SDA	F33	F33	F33	HDMI_2_SDA	HDMI_1_RX_0	C23	RX_1_0	
HDMI_3_SDA	D33	D33	D33	HDMI_3_SDA	HDMI_1_RX_0B	D23	RX_1_0B	
HDMI_0_PWRSV	G26	G26	G26	HDMI_0_PWRSV	HDMI_1_RX_1	C22	RX_1_1	
HDMI_1_PWRSV	E30	E30	E30	HDMI_1_PWRSV	HDMI_1_RX_1B	D22	RX_1_1B	
HDMI_2_PWRSV	E31	E31	E31	HDMI_2_PWRSV	HDMI_1_RX_2	A22	RX_1_2	
HDMI_3_PWRSV	E34	E34	E34	HDMI_3_PWRSV	HDMI_1_RX_2B	B22	RX_1_2B	
HDMI_0_HPD_CBUS	F28	F28	F28	HDMI_0_HPD_CBUS	HDMI_1_RX_C	A24	RX_1_C	
HDMI_1_HPD	F30	F30	F30	HDMI_1_HPD	HDMI_1_RX_CB	B24	RX_1_CB	
HDMI_2_HPD	F31	F31	F31	HDMI_2_HPD	HDMI_2_RX_0	A26	RX_2_0	
HDMI_3_HPD	F34	F34	F34	HDMI_3_HPD	HDMI_2_RX_0B	B26	RX_2_0B	
MHL_SENSE	F24	F24	F24	MHL_SENSE	HDMI_2_RX_1	C25	RX_2_1	
AVDD10_HDMI	B30	B30	B30	AVDD10_HDMI	HDMI_2_RX_1B	D25	RX_2_1B	
AVDD10_HDMI	A30	A30	A30	AVDD10_HDMI	HDMI_2_RX_2	C24	RX_2_2	
AVDD33_HDMI	P27	P27	P27	AVDD33_HDMI	HDMI_2_RX_2B	D24	RX_2_2B	
AVDD33_HDMI	P28	P28	P28	AVDD33_HDMI	HDMI_2_RX_C	C26	RX_2_C	
					HDMI_2_RX_CB	D26	RX_2_CB	
					HDMI_3_RX_0	C28	RX_3_0	
					HDMI_3_RX_0B	D28	RX_3_0B	
					HDMI_3_RX_1	A28	RX_3_1	
					HDMI_3_RX_1B	B28	RX_3_1B	
					HDMI_3_RX_2	C27	RX_3_2	
					HDMI_3_RX_2B	D27	RX_3_2B	
					HDMI_3_RX_C	C29	RX_3_C	
					HDMI_3_RX_CB	D29	RX_3_CB	




Main board circuit: 6135












LTDN55K321UWT & LTDN58K321UWAU PB:6106



更改版本	更改内容	更改人	更改日期
V1.1			
V1.2			
V1.3			
V1.4			
V1.5			

No.	Part Name	Num.	Code No.	Remark
23	screw	9	SJ2836-87 M3X8镀锌白	
22	Main board	1	RSAG2.908.6135-02	
21	screw	2	SJ2825-87 ST3X8C	
20	plastic bezel	1	RSAG8.081.1318	
19	plastic bezel	1	RSAG8.078.3992	
18	WiFi module	1	NU361-HS	
17	speaker	1	VIT3016-8W80-04	
16	metal bracket	1	RSAG8.038.4369	
15	side label	1	RSAG8.804.5333	
14	bottom label	1	RSAG8.804.5362	
13	screw	29	RSAG8.912.0172 M3*8 沉头	
12	TV Rear	1	RSAG6.170.0662	
11	screw	4	G8/T 818-2000 M4X12黑	
10	stand	1	RSAG6.121.0531	
9	metal bracket	1	RSAG8.038.4368	
8	plastic bracket	1	RSAG8.078.4051	
7	IR board	1	RSAG2.908.5624-04	
6	lens	1	RSAG8.640.0434	
5	power board	1	RSAG2.908.5687-46	
4	display board	1	RSAG2.908.5415	
3	display bracket and button zone	1	RSAG6.356.0146	
2	backplate	1	RSAG8.600.0802	
1	Panel	1	HD.596DU-B01	


图号	LTDN40K321UWAU	RSAG2.025.4715
图名	EXPLODE VIEW	
比例	1:4	
日期		
设计		
审核		
工艺		
标准		
批准		

规格(1)

27 版数: A1

RSAG2.025.4564

更改版本	更改内容	更改人	更改日期
V1.1			
V1.2			
V1.3			
V1.4			
V1.5			



序号	名称	数量	代号	备注
17	label	1	RSAG8.804.5333	
16	label	1	RSAG8.804.5362	
15	back cover	1	RSAG8.074.2595	
14	power board	1	RSAG2.908.6106	
13	hanging bracket	4	RSAG6.150.1355	
12	main board	1	RSAG2.908.6135	
11	terminal board	1	RSAG8.081.1318	
10	base bracket(R)	1	RSAG8.038.4606	
9	RC board	1	RSAG2.908.6151	
8	key board	1	RSAG6.356.0145	
7	base bracket(L)	1	RSAG8.038.4606	
6	speak bracket(R)	1	RSAG8.078.4008	
5	speak unit	2	VIT90170-12W8Q	
4	speak bracket(L)	1	RSAG8.078.4007	
3	base	2	RSAG6.121.0544	
2	base bracket(L)	1	RSAG8.038.4605	
1	panel	1	HD550DF-B52(020)\S1	

旧底图总号

底图总号

签名

格式(1)

更改标记	数量	更改单号	签名	日期
设计			张伟亮	
审核				
工艺				
标准化				
批准				

未注公差标准 单位: mm			

爆炸图

LTDN55K321uwT

RSAG2.025.4564

阶段标记

质量

比例

1:4

第 页 共 页

青岛海信电器股份有限公司

