

# LCD Television

## Service Manual

---

**Chassis: MTK5652**

The difference is only in indication light

Product	Indication light
LTDN50K610NXWAM3D	white
LTDN50K610NXWAM3D (14)	blue
LTDN50K610NXWAM3D(19)	red

**Ver 1.0**

**June, 2014**

---

---

# Contents

<b>Contents.....</b>	- 2 -
<b>Service Manual .....</b>	- 3 -
1. Precautions and notices.....	- 3 -
1.1 Warning.....	- 4 -
1.2 Notes.....	- 7 -
2. Product Function.....	- 9 -
2.1 MTK5652 chassis includes:.....	- 9 -
2.2 Specification .....	- 10 -
2.3 TV Front and Back .....	- 11 -
2.4 Remote Control.....	- 13 -
3. Factory/Service OSD Menu and Adjustment.....	- 15 -
3.1 To enter the Factory OSD Menu .....	- 15 -
3.2 Factory OSD Menu.....	- 15 -
3.3 Designer Menu.....	- 18 -
4. Software Upgrading.....	- 20 -
4.1 USB Software Upgrading directly .....	- 20 -
4.2 USB upgrading unsuccessfully .....	- 20 -
4.3 Upgrading with the FlashTool0.6.0.exe.....	- 23 -
4.4 Network updating .....	- 26 -
5. Trouble shooting .....	- 32 -
5.1 Troubleshooting for Remote Control.....	- 33 -
5.2 Troubleshooting for Function Key.....	- 34 -
5.3 TV won't Power On.....	- 35 -
5.4 Troubleshooting for Audio.....	- 36 -
5.5 Troubleshooting for TV/VGA/HDMI input.....	- 37 -
5.6 Troubleshooting for YPbPr input.....	- 38 -
5.7 Troubleshooting for Video input.....	- 39 -
6. Signals Block Diagram and power assign: .....	- 40 -
7. Schematic circuit diagram .....	- 40 -
8. Explode View.....	- 40 -

---

# **Service Manual**

## **1. Precautions and notices**

BEFORE SERVICING THE LCD TV, READ THE SAFETY PRECAUTIONS IN THIS MANUAL.

USE ONLY MANUFACTURER SPECIFIED REPLACEMENT PARTS WHEN SERVICING.

USE OF NON-AUTHORIZED PARTS WILL VOID THE MANUFACTURE'S WARRANTY

Proper service and repair is important to the safe, reliable operation of all Hisense Equipment. The service procedures recommended by Hisense and described in this Service Guide are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment and pose risk of personal injury

. It is also important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Service should only be performed by an experienced electronics

---

technician trained in the proper Television safety and service methods and procedures

Hereafter throughout this manual, HISENSE will be referred to.

## **1.1 Warning**

### **1.1.1**

Critical components having special safety characteristics are identified with a **A** by the Ref. No. in the parts list. Use of non-manufacturer's recommended parts may create shock, fire, or other hazards. Under no circumstances should the original design be modified or altered without written permission from RCA. Hisense Eassumes no liability, express or implied, arising out of any unauthorized modification of design. Servicetech assumes all liability.

#### **DANGER CAUTION**

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE GUIDE.

### **1.1.2.**

All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, be sure to use anti-static table mats and properly use a grounding wrist strap. Keep components and tools also at this same potential.

---

---

## **IMPORTANT:**

Always disconnect the power cord from AC outlet before replacing parts or modules.

### **1.1.3**

To prevent electrical shock, use only a properly grounded 3 prong outlet or extension cord.

### **1.1.4**

When replacement parts are required, be sure to use replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards and will void the manufacturer's warranty.

### **1.1.5**

Safety regulations require that after a repair the set must be returned in its original condition. In addition, prior to closing set, check that:

-Note:

>All wire harnesses and flex cables are properly routed and secured with factory tape and/or mounted cable clamps.

> All cables and connectors are properly insulated and do not have any bare wires/lead exposed

### **1.1.6**

(1) Do not supply a voltage higher than that specified to this product. This may

---

damage the product and may cause a fire.

(2) Do not use this product:

- > High humidity areas
- > In an area where any water could enter or splash into the unit.

High humidity and water could damage the product and cause fire.

(3) If a foreign substance (such as water, metal, or liquid) gets inside the panel module, immediately turn off the power. Continuing to use the product may cause fire or electric shock.

(4) If the product emits smoke, and abnormal smell, or makes an abnormal sound, immediately turn off the power. Continuing to use the product, it may cause fire or electric shock.

(5) Do not pull out or insert the power cable from/to an outlet with wet hands. It may cause electric shock.

(6) Do not damage or modify the power cable. It may cause fire or electric shock.

(7) If the power cable is damaged, or if the connector is loose, do not use the product: otherwise, this can lead to fire or electric shock.

(8) If the power connector or the connector of the power cable becomes dirty or dusty, wipe it with a dry cloth. Otherwise, this can lead to fire.

(9) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over

---

---

## 1.2 Notes

Notes on Safe Handling of the LCD panel and during service

The work procedures shown with the Note indication are important for ensuring the safety of the product and the servicing work. Be sure to follow these instructions.

- Before starting the work, secure a sufficient working space.
- At all times other than when adjusting and checking the product, be sure to turn OFF the POWER Button and disconnect the power cable from the power source of the TV during servicing.
- To prevent electric shock and breakage of PC board, start the servicing work at least 30 seconds after the main power has been turned off. Especially when installing and removing the power board, start servicing at least 2 minutes after the main power has been turned off.
- While the main power is on, do not touch any parts or circuits other than the ones specified. If any connection other than the one specified is made between the measuring equipment and the high voltage power supply block, it can result in electric shock or may trip the main circuit breaker. When installing the LCD module in, and removing it from the packing carton, be sure to have at least two persons perform the work.
- When the surface of the panel comes into contact with the cushioning materials, be sure to confirm that there is no foreign matter on top of the cushioning materials before the surface of the panel comes into contact with the cushioning materials. Failure to

---

observe this precaution may result in, the surface of the panel being scratched by foreign matter.

- Be sure to handle the circuit board by holding the large parts as the heat sink or transformer. Failure to observe this precaution may result in the occurrence of an abnormality in the soldered areas.
- Do not stack the circuit boards. Failure to observe this precaution may result in problems resulting from scratches on the parts, the deformation of parts, and short-circuits due to residual electric charge.
- Perform a safety check when servicing is completed. Verify that the peripherals of the serviced points have not undergone any deterioration during servicing. Also verify that the screws, parts and cables removed for servicing purposes have all been returned to their proper locations in accordance with the original setup.



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the set.

---

## 2. Product Function

### 2.1 MTK5652 chassis includes:

Product	Main & Power board	chassis	Panel	LVDS cable (main board-panel)
LTDN65XT880NXWAM3D	5744、5013	MT5652+6M40	INX*V650DK1-KS2	1、HX2-2X21KLBB600P\ROH 2、HX2-2X26KLBB450-HS\ROH
LTDN65K680XWAM3D	5744、5013	MT5652+6M40	INX*V650DK1-LS1	1、HX2-2X26KLBB450-HS\ROH 2、HX2-2X21KLBB600P\ROH
LTDN50K610NWAMN	5419、5652	MTK5652	HE500HF-B53(010)	FFC-51-594-1\ROH
LHD32N10WAM	5725、5268	MTK5652	HS*HE315GH-E77	HX2-2×20KLB400-BOE
LTDN42A300NWAM	5725、5030	MTK5652	HS*HE416GF-E01	FFC-51P-737\ROH
LHD39N16WAM	5725、5424	MTK5652	HE390HH-E51	HX2-2×20KLB400-BOE
LHD32K160WAMN	5649、5023	MTK5652	HS*HE315GH-E77	HX2-2X15KLB400P-CMO-3\ROH
LTDN50K600XWAMN3D	5649、4903	MTK5652	CMI*V500HK1-LS6(E4)	HX2-2X26KLBB450-HS\ROH
LTDN65XT780XWAM3D	5649、5275	MTK5652	HE650GFD-B51	FFC-51P-594\ROH
LTDN50K660RWAM3D	5649、5024	MTK5652	HE500HFR-B51(2000)	FFC-51-594-1\ROH
LTDN40K160WAMN	5649、4737	MTK5652	HE400GF-B31(1000)	FFC-51-625-2A\ROH
LTDN50K610NXWAM3D	5725、4903	MTK5652	V500HK1-LS6 (E4)	HX2-2X26KLBB450-HS\ROH


---

## 2.2 Specification

Model Name		LTDN50K610NXWAM3D
Dimension (mm)	Without Stand	1126 × 658 × 59
	With Stand	1126 × 730 × 285
Weight(kg)	Without Stand	17.6
	With Stand	20.6
LCD Panel Minimum size (diagonal)		50 inches ( 125 cm )
Screen resolution		1920 × 1080
Audio power		10W + 10 W
Power consumption		90 W
Power supply		AC 100-240 V, 50/60 Hz
Receiving systems	RF	PAL-M/N, NTSC, ISDB-T
	AV	PAL, NTSC
Environmental conditions		Temperature: 5°C~45°C Humidity: 20%-80% RH Atmospheric pressure: 86 kPa - 106 kPa
Component Input		480 I / 60 Hz, 480 P / 60 Hz, 720 P / 60 Hz, 1080 I / 60 Hz, 1080 P / 60 Hz
VGA Input		VGA (640×480 / 60 Hz), SVGA (800×600 / 60 Hz), XGA (1024×768 / 60 Hz)
HDMI Input		RGB / 60 Hz (640×480, 800×600, 1024×768) YUV / 60 Hz (480 I, 480 P, 720 P, 1080 I, 1080 P)


## 2.3 TV Front and Back

### TV Front- LTDN50K610NXWAM3D



<b>Item</b>	<b>Description</b>
1 <b>Power indicator</b>	White light up in standby mode and the LED will be off when the TV is switched on.
2 <b>Power switch I/O</b>	Switch the I/O power on or off.
3 <b>Remote sensor and 3D emitter</b>	Receives remote signals from the remote control. Sends signals to 3D glasses during playback of 3D movies and TV shows. Do not put anything near the sensor, as its function may be affected.
4 <b>MENU</b>	Display menu settings.
5 <b>SOURCE</b>	Select among the different input signal sources.
6 <b>VOL + / VOL -</b>	Adjust the volume.
7 <b>CH ^ / CH v</b>	Switch between channels.
8 <b>Power button ⏪</b>	Turn on the TV from the standby mode or switch the TV back to standby mode. <b>Caution:</b> The TV continues to consume the power even in standby mode. Please turn the I/O Power off or unplug the power cord to save the power.


### TV Rear-- LTDN50K610NXWAM3D



Some external devices impossible insert to this set for individual difference. Please replace with appropriate external signal cable or increase the adapter to match with the port in such case.


<b>Item</b>	<b>Description</b>
<b>ANT</b>	Connect an antenna or cable TV to this jack.
<b>HDMI</b>	HDMI provides an uncompressed, all digital audio/video interface between this TV and any HDMI-device.
<b>COMPONENT</b>	Connect to a DVD player, Digital Set-Top-Box, or other A/V devices with component ( $YP_BP_R$ ) video and audio output jacks.
<b>AV</b>	Connect to the composite video and audio (L/R) output jacks on external video devices.
<b>VGA/VGA AUDIO IN</b>	Connect to a PC or other devices with a VGA interface.
<b>AV OUT</b>	Connect to external devices with video input function and transmit the video signals being played to these devices.
<b>HEADPHONE</b>	Connect headphone for private listening.
<b>COAXIAL</b>	Connect to an external digital audio device.
<b>USB</b>	Port for Digital Media Player.
<b>LAN</b>	Connect an ethernet cable to access a Network or the Internet.

## 2.4 Remote Control



---

## **Main board layout t (5725)**



Detail description look up the quick setup guide, please.

---

### **3. Factory/Service OSD Menu and Adjustment**


#### **3.1 To enter the Factory OSD Menu**

With user's RC

1. Power TV On
2. Press Menu button and call up User OSD Menu
3. Select Audio-> Balance, when Balance is “0”
4. Enter 1->9->6->9 in sequence.  
Note: If necessary, re-enter number keys.
5. Factory OSD appears.
6. Press Menu again and leave factory OSD.

#### **3.2 Factory OSD Menu**

Take LTDN50K660RWAM3D for example



### 3.2.1 White Balance

Note: Different source has different WB values. Before adjusting, please change to desired source.

Factory	Design	
	White Balance	
	Signal Prefabricate	
	Pattern Test	
	Factory Option	
	Version info	
Chip	MT5652	
Model	LTDN50K660RWAM3D	
Version	V00.01.91a.D1021	
Mac	90:CF:7D:DD:20:34	
Cdn	api.sa.hismarttv.com	
	Panel	B1
	R Gain	128
	G Gain	128
	B Gain	128
	R Offset	128
	G Offset	128
	B Offset	128

### 3.2.2 Signal prefabricate

Factory	Design	
	White Balance	
	Signal Prefabricate	
	Pattern Test	
	Factory Option	
	Version info	
Chip	MT5652	
Model	LTDN50K660RWAM3D	
Version	V00.01.91a.D1021	
Mac	90:CF:7D:DD:20:34	
Cdn	api.sa.hismarttv.com	
	Zhong Shi	
	Huang Dao	
	Gui Yang	
	Liao Ning	
	Hungary	
	Australia	
	France	

### 3.2.3 Factory Option

Factory	Design																
White Balance																	
Signal Prefabricate																	
Pattern Test																	
Factory Option	<table border="1"> <thead> <tr> <th>TO FAC</th> <th>M</th> </tr> </thead> <tbody> <tr> <td>FirmWare Update</td> <td>On</td> </tr> <tr> <td>Blue Mute</td> <td>On</td> </tr> <tr> <td>Logo Option</td> <td>devant</td> </tr> <tr> <td>LVDS Spread</td> <td>0</td> </tr> <tr> <td>OpenVchip-Limit</td> <td>US</td> </tr> <tr> <td>Clean Protected</td> <td></td> </tr> <tr> <td>Clean All</td> <td></td> </tr> </tbody> </table>	TO FAC	M	FirmWare Update	On	Blue Mute	On	Logo Option	devant	LVDS Spread	0	OpenVchip-Limit	US	Clean Protected		Clean All	
TO FAC	M																
FirmWare Update	On																
Blue Mute	On																
Logo Option	devant																
LVDS Spread	0																
OpenVchip-Limit	US																
Clean Protected																	
Clean All																	
Chip	MT5652																
Model	LTDN50K660RWAM3D																
Version	V00.01.91a.D1021																
Mac	90:CF:7D:DD:20:34																
Cdn	api.sa.hismarttv.com																

	Item	Default	Options	Notes
1	MODE	M	M, U	M-Can enter factory mode with factory RC or user RC. U-Can enter factory mode only with user's RC.

Note: MODE “M” is only used for factory production.

	Item	Default	Options	Note
1	Version			Software version
2	Date			The date of current version

Note: Software version info of the TV, readable only.

Item	Meaning	Note
Clean Protected	Clear partly	Clean data except WB data and Auto Color data
Clean All	Clear completely	Clean all data

---

**Note:** The factory menu date varies according to different sources. In case changing the factory data by error, you can choose to “Clean Protected”, by which you can resume the default value.




**To clear the EEPROM:**

- a. Select the item “Clean All” .
- b. Press VOL+ button to clear the EEPROM data.
- c. Close the OSD menu after 5 seconds.
- d. Restart the TV.

### 3.3 Designer Menu

A screenshot of the "Color Temp" sub-menu from the Designer menu. The "Color Temp" tab is highlighted in orange at the top left. The sub-menu options are "Video", "Audio", and "Setup". To the right, there is a detailed configuration table for "Color Temp" settings under the "Cool" profile.

Color Temp	Cool
R Gain	128
G Gain	128
B Gain	168
R Offset	128
G Offset	128
B Offset	128



**Note:**

The above “Factory/Service OSD Menu” is reference for chassis MTK5652 , please refer to the actual units to determine the appearances for different TV.

---

---

## 4. Software Upgrading

### 4.1 USB Software Upgrading directly

The software can be upgraded by USB Disk.


- First, copy the upgrade\_loader.pkg file to USB Disk;.
- Second, make sure there is no other .pkg file in the root directory of USB Disk.
- Insert USB Disk to USB port, and then power on the TV.
- The TV will identify the software and upgrade automatically.

### 4.2 USB upgrading unsuccessfully

If USB upgrading unsuccessfully, then need burning the Nand Flash program file“ \*.bin ”to the Nand Flash.


#### Hardware connecting

Connect the unit to your pc with a USB-to-serial port cable. USB port connects to your PC and serial port to the TV’s RS232 port. As following




#### 4.2.1 Install the driver

Double click the icon  , install the driver.



Select the default value, the driver will be installed step by step.




---

## Find New Hardware Wizard

Finish Finding New Hardware Wizard

The wizard has finished the software installation:



If you close the wizard, Please click "Finish".


Last Step(B)

Finish


Cancel

## 4.3 Upgrading with the FlashTool0.6.0.exe

1、FlashTool is a green program needing no installation. After Connect the unit to your pc with a USB-to-serial port cable, run FlashTool0.6.0.exe. Please refer to the following steps to set.




How to choose Communicate port and flash baud rate? See the following instruction..




Open “Device Manager” and find which port is connected with the TV. In above picture, COM4 is connected to the TV, so, select “COM4” and if COM6 is connected to the TV, so select “COM6”. Select the right baud rate according to chip model. For this unit( chip model is MT5652), select 115200.

2、 Click to connect, if connect successfully then button from red turn green .



Click , bounce the following dialog box. Load Bin File: find the upgrading program file, and select it. for example:HIS\_5651\_m1v2\_oceania\_secure\_nandboot.bin.

Press “Upgrade” button and start upgrading., if update defeat, try again.



If bootloader Tool upgrading is ok, then need renew USB upgrading.reference to 4.1( **USB Software Upgrading directly**)

## 4.4 Network updating

Network updating includes three ways. Auto Upgrade 、 Network upgrade and USB upgrade.

No matter Auto Upgrade is ON or Off, Network Upgrade is validated

4.4.1 Auto Upgrade---- When set to “on” , system can automatically check whether or not have any new updating file in servers after have connected to the network. Customer can download and update according to the guide.

Network upgrade ---- Check the process and it will prompt you to upgrade the software.

### Network upgrade

Press “menu” key with RC, select as following.




Figure-1




Figure-2




Figure-3

Check new version, bounce the following.




Figure-4

Select Yes to downloading.....




Figure-5

After verify, bounce dialog to select “yes” to update the firmware. Waiting.....



Figure-6





Figure-7

---

Bounding the following interface that indicates firmware update is successful.




Figure-8

Remote control Power off and restart TV. indication led is linking .about 5 minutes , TV bounce following prompt message. otherwise upgrade is defeated.




Figure-9


---

## USB upgrade:

1. Copy the upgrade\_loader.pkg file to USB Disk;
2. Make sure there is no other .pkg file in the root directory of USB Disk.
3. Insert USB Disk to USB port. and then turn on the TV.



figure-2



Next update steps can according to the network upgrade.

---


## 5. Trouble shooting

When there is something wrong with your TV, you can try turning off the TV and then restart it. You can also operate according to the follow chart. If the problems still cann't be solved, please contact the profession technician.

No sound or picture	<ol style="list-style-type: none"><li>1. Check if the power line is in the outlet and if it has electricity.</li><li>2. Check if you have pressed Power button on the TV or Power button on the remote control</li><li>3. Check the setting of picture brightness and contrast.</li><li>4. Check the volume.</li></ol>
The picture is normal but there is no sound	<ol style="list-style-type: none"><li>1. Check the volume.</li><li>2. Check if Mute mode is set.</li></ol>
No picture and white or black picture	<ol style="list-style-type: none"><li>1. Adjust Picture Setting.</li><li>2. Check Color System.</li></ol>
The sound and picture are interfered	<ol style="list-style-type: none"><li>1. Try to find the appliance affecting TV set, and move it far away from the TV set.</li><li>2. Try to insert the power plug of the TV set into another outlet.</li></ol>
Unclear picture or picture with snow	<ol style="list-style-type: none"><li>1. Check the direction, position and connection of your antenna.</li><li>2. Adjust the direction of your antenna or reset or fine tune the channel</li></ol>
The remote control does not work	<ol style="list-style-type: none"><li>1. Change the batteries in the remote control.</li><li>2. Clean the upper side of the remote control (radiating window)</li><li>3. Check the contacting points of the batteries.</li><li>4. Check if there is obstruction between the remote control and the monitor.</li><li>5. Check if the batteries are correctly installed.</li></ol>
H/V strip or the picture shaking	Check if there is an interfering source nearby, such as appliance or electric tools.
The cabinet of the TV makes "Click" sound	makes "Click" sound"Sometimes the room temperature change can cause the television cabinet to inflate or contra, which makes this sound. This does not mean the TV breaks down.


---

## 5.1 Troubleshooting for Remote Control




---

## 5.2 Troubleshooting for Function Key



## 5.3 TV won't Power On




**Note:**

**Above the indicated led color is only for standby is red , normal is blue.**


---

## 5.4 Troubleshooting for Audio




---

## 5.5 Troubleshooting for TV/VGA/HDMI input




---

## 5.6 Troubleshooting for YPbPr input



---

## 5.7 Troubleshooting for Video input



---

## **6. Signals Block Diagram and power assign:**

(The next page)

## **7. Schematic circuit diagram**

## **8. Explode View**

# MT5652

## GPIO LIST

PIN NAME	GPIO Function	Function define
GPIO_0	LOCAL_DIM_EN	
GPIO_1	TUNER_SW	
GPIO_2	LVDS_PWR_EN	
GPIO_3	EMMC_RST	
GPIO_4	Demod_RST#	
GPIO_5	not used	
GPIO_6	3D_EN	
GPIO_7	3D相关	
GPIO_8	3D相关	
GPIO_9	3D_OUT	
GPIO_10	HPDET#	
GPIO_11	SYS_EEPROM_WP	

ADIN0	SCART_FS_SEL	
ADIN1	通过10k接地,未使用	
ADIN2	ADINO	
ADIN3	ADIN1	
ADIN4	LED_DX	
ADIN5	POWER_LED	
OPCTRL0	FLASH写保护控制	
OPCTRL1	BL_ON/OFF	
OPCTRL2	AMP_MUTE	
OPCTRL3	strap[2]	
OPCTRL4	strap[3] RST_AMP	
OPWM0	WIFI_EN	
OPWM1	MEMC_ON/OFF	
OPWM2	BL_DIMMING	
OPWM3	MUTE_HP	
OPWM4	3D_CTRL	
OPWM5	LED2/PHYAD2	
OPWM6	LED3/PHYAD3	
PACLE	strap[0]	
CIGPIO0	RESERVED LVDS预留	


CIGPIO15	TS1_OUT_CLK	
CIGPIO16	TS1_OUT_VLD	
CIGPIO17	TS1_OUT_SYNC	
CIGPIO18	TS1_OUT_D0	
CIGPIO19	TS1_OUT_D1	
CIGPIO20	TS1_OUT_D2	
CIGPIO21	TS1_OUT_D3	
CIGPIO22	TS1_OUT_D4	
CIGPIO23	TS1_OUT_D5	
CIGPIO24	TS1_OUT_D6	
CIGPIO25	TS1_OUT_D7	


与5419区别 VER0.1

P\_03增加C654, C655  
P\_04增加R41 NC  
P\_08 X5S插头改为转接头  
P\_12 R738,R739,R740,R741,R742  
云加屏之R738,R739,R740,R741  
增加屏之R742  
P\_14去掉一路USB

R711 NC  
R41 NC  
R233 NC


## Block Diagram







Hisense Electric Co.,LTD

Title:  
Power Tree








MB:5725

## ETHERNET PHY



Hisense Electric Co., LTD



Title: GPO/AD/ETHERNET PHY


Size: A3 Document Number: MT5652






Rev: 1.0







Date: Tuesday, November 12, 2013

Sheet 4 of 17











E1

Hisense Electric Co.,LTD			
Title YPBPR/AV INPUT			
Size A3	Document Number MT5652	Rev 1.0	
Date: Tuesday, November 12, 2013	Isheet 8	of 17	



### Analog Power



2,3,4,5,6,7,8,10,11,12,13,14,15,16,17

2,5,6,7,8,10,12,14,15,16,17

2,3,4,6,8,10,13

2,3,4,5,10,11

8

7

6

16,17

16,17

16,17

16,17

10

17

3,7

3,7

3,7

3,5

2,5,16

9

8

GND

$\triangleleft \triangleright$  GND

+5V

AVDD3V3

3.3VS

AINL\_YPBPR

AINR\_YPBPR

VGA\_L\_IN

VGA\_R\_IN

AOMCLK\_D

AOBCLK\_D

AOLRCK\_D

AOMCLK\_D

AOSDATA0\_D

AOSDATA1\_D

AOSDATA0\_D

SPDIF\_OUT

HDMI\_ARC

AL00

AR00

U0RX

U0TX

U0TX

U0TX

OIRI

5VS

MUTE\_DRV632

TUNER\_BYPASS\_OUT

$\triangleleft \triangleright$  MUTE\_DRV632

TUNER\_BYPASS\_OUT

$\triangleleft \triangleright$  TUNER\_BYPASS\_OUT

2,3,4,5,6,7,8,10,11,12,13,14,15,16,17

2,5,6,7,8,10,12,14,15,16,17

2,3,4,6,8,10,13

2,3,4,5,10,11

8

7

6

16,17

17

3,7

3,7

3,7

3,5

2,5,16

9

8

MUTE\_DRV632

TUNER\_BYPASS\_OUT

$\triangleleft \triangleright$  TUNER\_BYPASS\_OUT

2,3,4,5,6,7,8,10,11,12,13,14,15,16,17

2,5,6,7,8,10,12,14,15,16,17

2,3,4,6,8,10,13

2,3,4,5,10,11

8

7

6

16,17

17

3,7

3,7

3,7

3,5

2,5,16

9

8

MUTE\_DRV632

TUNER\_BYPASS\_OUT

$\triangleleft \triangleright$  TUNER\_BYPASS\_OUT

2,3,4,5,6,7,8,10,11,12,13,14,15,16,17

2,5,6,7,8,10,12,14,15,16,17

2,3,4,6,8,10,13

2,3,4,5,10,11

8

7

6

16,17

17

3,7

3,7

3,7

3,5

2,5,16




9

8

MUTE\_DRV632

TUNER\_BYPASS\_OUT

$\triangleleft \triangleright$  TUNER\_BYPASS\_OUT













Hisense Electric Co., LTD

Title: AUDIO IN/OUT/COAXIAL OUT


Size: A3 Document Number: MT5652


Rev: 1.0 Date: Tuesday, November 12, 2013 Sheet: 9 of 17







Hisense Electric Co.,LTD	
Title	
Size	Document Number
A3	MT5652
Date:	Tuesday, November 12, 2013
Sheet	11
of	17
Rev	1.0






## USB\_HUB




## Near Connector

EQUAL LENGTH and DIFFERENTIAL IMPEDANCE 90ohm


### USB PORT 1



### USB PORT 2



## WIFI




Hisense Electric Co.,LTD


Title		USB	Rev
Size	Document Number	MT5652	1.0
A3			
Date:	Tuesday, November 12, 2013	Sheet	14 of 17

## SPEAKER Amplifier

I2C Address  
= 0x6A



## MTUE CIRCUIT



Hisense Electric Co., LTD

Title SPEAKER/MUTE



Size Document Number

A3 MT5652




Rev 1.0

Date Tuesday, November 12, 2013


Sheet 15 of 17



MB.5725



# Power board:4903



RSAG2. 025. 4282

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U


V

W

X

Y

Z



No.	Description	Qty.	Code No.	Remark
1	EXPLONE	1	RSAG2. 025. 4282	
2	LTDN50K610NXWAM3D	1		
3	Front Endlosure	1	RSAG8. 074. 1655\W6+GR2\VO\ROH\X0	
4	Speaker	2	V1190170-10W8Ω-01\ROH	
5	Bracket Unit(L)	1	RSAG8. 078. 3455\VO\ROH\X0	
6	Bracket Unit(R)	1	RSAG8. 038. 2711\ROH	
7	Back Light	1	GIW5309-700\ROH	
8	Panel	1	CML*V500HK1-LS6(E4)\JK\ROH	
9	Bracket Unit	1	RSAG8. 038. 3641\ROH	
10	Keypad PCA	1	RSAG2. 908. 5654\ROH	R&key/board are complex.
11	Bracket Unit	1	RSAG8. 335. 0212\MB2\HB\ROH\X1	
12	Terminal Bracket	1	RSAG8. 804. 4763\ROH	
13	Rear Endlosure	1	RSAG8. 074. 1656\MB2\VO\ROH\X0	
14	Power Cord Cover	1	RSAG8. 634. 0221\B2\VO\ROH	
15	Stand	1	RSAG6. 121. 0338\FB2\W8\X0	
16	Terminal Bracket	1	RSAG8. 804. 5086\ROH	
17	Bottom Label	1	RSAG8. 041. 1272\B2\ROH\X0	
18	Side Label	1	RSAG8. 041. 1271\B2\ROH\X0	
19	Main Board	1	RSAG2. 908. 5725\O2\ROH	
20	Power Board	1	RSAG2. 908. 4903-11\ROH	
21	Bracket Unit	1	RSAG8. 038. 3681\T-R\ROH	
22	Bracket Unit	1	RSAG8. 038. 3292\VO\ROH\X0	
23	Bracket Unit	1	RSAG8. 038. 5085\VO\ROH	
24	Insulating Spacer	1	RSAG8. 600. 0535\VO\ROH	
25	Bracket Unit	1	RSAG8. 038. 3684\T-R\ROH	
26	Bracket Unit	1	RSAG8. 038. 3682\T-L\ROH	
27	Bracket Unit	1	RSAG8. 038. 4652\VO\ROH	
28	3D RF Board	1	RSAG2. 908. 4652\VO\ROH	
29	Bracket Unit	1	RSAG8. 078. 3238A\VO\ROH\X0	
30	Bracket Unit	1	RSAG8. 078. 3321\HB\VO\ROH\X0	
31	IR Board	1	RSAG2. 908. 5654\VO\ROH	R&key board are complex.
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				