



LED-TV

Chassis : U74D
Model : UN40EH6030F
UN46EH6030F
UN55EH6030F

SERVICE MANUAL

LED TV



UN**EH6030F

Refer to the service manual in the GSPN (see the rear cover) for more information.

1. Precautions

1.1. Safety Precautions

Follow these safety, servicing and ESD precautions to prevent damage and to protect against potential hazards such as electrical shock.

1-1-1. Warnings



For continued safety, do not attempt to modify the circuit board.
Disconnect the AC power and DC power jack before servicing.


1-1-2. Servicing the LED TV

1. When servicing the LED TV, Disconnect the AC line cord from the AC outlet.
2. It is essential that service technicians have an accurate voltage meter available at all times. Check the calibration of this meter periodically.

1-1-3. Fire and Shock Hazard

Before returning the monitor to the user, perform the following safety checks:

1. Inspect each lead dress to make certain that the leads are not pinched or that hardware is not lodged between the chassis and other metal parts in the monitor.
2. Inspect all protective devices such as nonmetallic control knobs, insulating materials, cabinet backs, adjustment and compartment covers or shields, isolation resistor/capacitor networks, mechanical insulators, etc.
3. Leakage Current Hot Check:



Do not use an isolation transformer during this test.

Use a leakage current tester or a metering system that complies with American National Standards Institute (ANSI C101.1, Leakage Current for Appliances), and Underwriters Laboratories (UL Publication UL1410, 59.7).

4. With the unit completely reassembled, plug the AC line cord directly into a 120V AC outlet. With the unit's AC switch first in the ON position and then OFF, measure the current between a known earth ground (metal water pipe, conduit, etc.) and all exposed metal parts, including: metal cabinets, screwheads and control shafts. The current measured should not exceed 0.5 milliamp. Reverse the power-plug prongs in the AC outlet and repeat the test.

1-1-4. Product Safety Notices

Some electrical and mechanical parts have special safety-related characteristics which are often not evident from visual inspection. The protection they give may not be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by  on schematics and parts lists. A substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire and/or other hazards. Product safety is under review continuously and new instructions are issued whenever appropriate.

www.eletronica geral.com.br

1.2. Servicing Precautions



An electrolytic capacitor installed with the wrong polarity might explode.



Before servicing units covered by this service manual, read and follow the Safety Precautions section of this manual.



If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions, always follow the safety precautions.

1-2-1. General Servicing Precautions

1. Always unplug the unit's AC power cord from the AC power source and disconnect the DC Power Jack before attempting to: (a) remove or reinstall any component or assembly, (b) disconnect PCB plugs or connectors, (c) connect a test component in parallel with an electrolytic capacitor.
2. Some components are raised above the printed circuit board for safety. An insulation tube or tape is sometimes used. The internal wiring is sometimes clamped to prevent contact with thermally hot components. Reinstall all such elements to their original position.
3. After servicing, always check that the screws, components and wiring have been correctly reinstalled. Make sure that the area around the serviced part has not been damaged.
4. Check the insulation between the blades of the AC plug and accessible conductive parts (examples: metal panels, input terminals and earphone jacks).
5. Insulation Checking Procedure: Disconnect the power cord from the AC source and turn the power switch ON. Connect an insulation resistance meter (500 V) to the blades of the AC plug. The insulation resistance between each blade of the AC plug and accessible conductive parts (see above) should be greater than 1 megohm.
6. Always connect a test instrument's ground lead to the instrument chassis ground before connecting the positive lead; always remove the instrument's ground lead last.

1.3. Static Electricity Precautions

Some semiconductor (solid state) devices can be easily damaged by static electricity. Such components are commonly called Electrostatically Sensitive Devices (ESD). Examples of typical ESD are integrated circuits and some field-effect transistors. The following techniques will reduce the incidence of component damage caused by static electricity.

1. Immediately before handling any semiconductor components or assemblies, drain the electrostatic charge from your body by touching a known earth ground. Alternatively, wear a discharging wrist-strap device. To avoid a shock hazard, be sure to remove the wrist strap before applying power to the monitor.
2. After removing an ESD-equipped assembly, place it on a conductive surface such as aluminum foil to prevent accumulation of an electrostatic charge.
3. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ESDs.
4. Use only a grounded-tip soldering iron to solder or desolder ESDs.
5. Use only an anti-static solder removal device. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ESDs.
6. Do not remove a replacement ESD from its protective package until you are ready to install it. Most replacement ESDs are packaged with leads that are electrically shorted together by conductive foam, aluminum foil or other conductive materials.
7. Immediately before removing the protective material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.



Be sure no power is applied to the chassis or circuit and observe all other safety precautions.

8. Minimize body motions when handling unpackaged replacement ESDs. Motions such as brushing clothes together, or lifting your foot from a carpeted floor can generate enough static electricity to damage an ESD.

www.electroniccage.com

1.4. Installation Precautions

1. For safety reasons, more than a people are required for carrying the product.
2. Keep the power cord away from any heat emitting devices, as a melted covering may cause fire or electric shock.
3. Do not place the product in areas with poor ventilation such as a bookshelf or closet. The increased internal temperature may cause fire.
4. Bend the external antenna cable when connecting it to the product. This is a measure to protect it from being exposed to moisture. Otherwise, it may cause a fire or electric shock.
5. Make sure to turn the power off and unplug the power cord from the outlet before repositioning the product. Also check the antenna cable or the external connectors if they are fully unplugged. Damage to the cord may cause fire or electric shock.
6. Keep the antenna far away from any high-voltage cables and install it firmly. Contact with the highvoltage cable or the antenna falling over may cause fire or electric shock.
7. When installing the product, leave enough space (0.4m) between the product and the wall for ventilation purposes. A rise in temperature within the product may cause fire.

www.eletronica geral.com.br

2. Product Specifications

2.1. Product Information

2-1-1. Model Comparison

Model	UN**EH6030F		
Front View	 <p>*W: Width H: High D: Depth</p>		
Detail View			
Front Color	Black (panel)		
Dimensions (W x H x D)	40"	Set with Stand	927.5 x 607.2 x 227.6 mm / 36.5 x 23.9 x 9.0 inches
		Set without Stand	927.5 x 548.0 x 93.1 mm / 36.5 x 21.6 x 3.7 inches
	46"	Set with Stand	1060.0 x 681.1 x 277.6 mm / 41.7 x 26.8 x 10.9 inches
		Set without Stand	1060.0 x 622.5 x 96.2 mm / 41.7 x 24.5 x 3.8 inches
	55"	Set with Stand	1251.4 x 789.6 x 277.6 mm / 48.7 x 31.1 x 10.9 inches
		Set without Stand	1251.4 x 730.1 x 94.4 mm / 48.7 x 28.7 x 3.7 inches
Weight	40"	Set with Stand	10.9 kg / 24.0 lbs
		Set without Stand	8.9 kg / 19.6 lbs
	46"	Set with Stand	13.3 kg / 29.3 lbs
		Set without Stand	11.3 kg / 24.9 lbs
	55"	Set with Stand	20.6 kg / 45.4 lbs
		Set without Stand	18.0 kg / 39.7 lbs
Panel Type	Anti Glare		
Internal Memory	256 Mbyte		
DDR	512 Mbyte		
Feature	Samsung 3D		

2-1-2. Feature & Specifications

Model	UN40EH6030F	
Feature		
<ul style="list-style-type: none"> • Digital-TV, RF, 2-HDMI, 1-Component, 1-A/V, 1-USB2.0, LAN • Brightness : 350 cd/m² • Response Time : 6 ms • Clear Motion Rate : 200/240 Hz • Dynamic contrast Ratio : 16.7 Mega Contrast, Super-PVA • Samsung 3D, Dolby Digital+, SRS TheaterSound HD 		
Specifications		
Item	Description	
LCD Panel	40 inch FHD 120 Hz	
Scanning Frequency	Horizontal : 60 kHz ~ 73 kHz (Automatic) Vertical : 47 Hz ~ 63 Hz (Automatic)	
Display Colors	16.7M color	
Maximum Resolution	Horizontal : 1920 Pixels Vertical : 1080 Pixels	
Input Signal	Analog 0.7 Vp-p ± 5% positive at 75Ω, internally terminated	
Maximum Pixel Clock Rate	74.25 MHz	
Active Display (H x V)* * Horizontal x Vertical	890.6 (H) x 503.2 (V) mm / 35.1 (H) x 20.5 (V) inches	
AC Power Voltage & Frequency	AC110 ~ 120 V 60 Hz	
Power Consumption	86 W (Under 0.3 W, Stand by)	
Dimensions (W x H x D)	927.5 x 607.2 x 227.6 mm / 36.5 x 23.9 x 9.0 inches_Set with Stand 927.5 x 548.0 x 93.1 mm / 36.5 x 21.6 x 3.7 inches_Set without Stand	
Weight	10.9 kg / 24.0 lbs_Set with Stand 8.9 kg / 19.6 lbs_Set without Stand	
TV System	Tuning	Frequency Synthesize (Refer to detailed Frequency Table)
	System	ATSC & Clear QAM
	Sound	NTSC-M, Dolby Digital Plus/Pulse
Environmental Considerations	Operating Temperature : 32°F ~ 122°F (0°C ~ 50°C) Operating Humidity : 20% ~ 90% Storage Temperature : -4°F ~ 140°F (-20°C ~ 60°C) Storage Humidity : 10% ~ 90%	
Audio Specifications	MAX Internal Audio Output Power : Each 10 W (Left/Right) Equalizer : 5 Band Output Frequency : RF : 20 Hz ~ 15.4 kHz AV/Componet/HDMI : 20 Hz ~ 20 kHz	
Note : Samsung 3D, 3D Converter, Dolby Digital +, SRS TheaterSound HD, Game Mode, Film Mode, Energy Saving		

Model	UN46EH6030F	
Feature		
<ul style="list-style-type: none"> • Digital-TV, RF, 2-HDMI, 1-Component, 1-A/V, 1-USB2.0, LAN • Brightness : 350 cd/m² • Response Time : 6 ms • Clear Motion Rate : 200/240 Hz • Dynamic contrast Ratio : 16.7 Mega Contrast, Super-PVA • Samsung 3D, Dolby Digital+, SRS TheaterSound HD 		
Specifications		
Item	Description	
LCD Panel	46 inch FHD 120 Hz	
Scanning Frequency	Horizontal : 60 kHz ~ 73 kHz (Automatic) Vertical : 47 Hz ~ 63 Hz (Automatic)	
Display Colors	16.7M color	
Maximum Resolution	Horizontal : 1920 Pixels Vertical : 1080 Pixels	
Input Signal	Analog 0.7 Vp-p ± 5% positive at 75Ω, internally terminated	
Maximum Pixel Clock Rate	74.25 MHz	
Active Display (H x V)* * Horizontal x Vertical	1023.0 (H) x 577.6 (V) mm / 41.8 (H) x 23.6 (V) inches	
AC Power Voltage & Frequency	AC110 ~ 120 V 60 Hz	
Power Consumption	109 W (Under 0.3 W, Stand by)	
Dimensions (W x H x D)	1060.0 x 681.1 x 277.6 mm / 41.7 x 26.8 x 10.9 inches_Set with Stand 1060.0 x 622.5 x 96.2 mm / 41.7 x 24.5 x 3.8 inches_Set without Stand	
Weight	13.3 kg / 29.3 lbs_Set with Stand 11.3 kg / 24.9 lbs_Set without Stand	
TV System	Tunning	Frequency Synthesize (Refer to detailed Frequency Table)
	System	ATSC & Clear QAM
	Sound	NTSC-M, Dolby Digital Plus/Pulse
Environmental Considerations	Operating Temperature : 32°F ~ 122°F (0°C ~ 50°C) Operating Humidity : 20% ~ 90% Storage Temperature : -4°F ~ 140°F (-20°C ~ 60°C) Storage Humidity : 10% ~ 90%	
Audio Specifications	MAX Internal Audio Output Power : Each 10 W (Left/Right) Equalizer : 5 Band Output Frequency : RF : 20 Hz ~ 15.4 kHz AV/Componet/HDMI : 20 Hz ~ 20 kHz	
Note : Samsung 3D, 3D Converter, Dolby Digital +, SRS TheaterSound HD, Game Mode, Film Mode, Energy Saving		

2. Product Specifications

Model		UN55EH6030F	
Feature			
<ul style="list-style-type: none"> • Digital-TV, RF, 2-HDMI, 1-Component, 1-A/V, 1-USB2.0, LAN • Brightness : 350 cd/m² • Response Time : 6 ms • Clear Motion Rate : 200/240 Hz • Dynamic contrast Ratio : 16.7 Mega Contrast, Super-PVA • Samsung 3D, Dolby Digital+, SRS TheaterSound HD 			
Specifications			
Item		Description	
LCD Panel		55 inch FHD 120 Hz	
Scanning Frequency		Horizontal : 60 kHz ~ 73 kHz (Automatic) Vertical : 47 Hz ~ 63 Hz (Automatic)	
Display Colors		16.7M color	
Maximum Resolution		Horizontal : 1920 Pixels Vertical : 1080 Pixels	
Input Signal		Analog 0.7 Vp-p ± 5% positive at 75Ω, internally terminated	
Maximum Pixel Clock Rate		74.25 MHz	
Active Display (H x V)* * Horizontal x Vertical		1213.4 (H) x 684.3 (V) mm / 49.5 (H) x 27.9 (V) inches	
AC Power Voltage & Frequency		AC110 ~ 120 V 60 Hz	
Power Consumption		138 W (Under 0.3 W, Stand by)	
Dimensions (W x H x D)		1251.4 x 789.6 x 277.6 mm / 48.7 x 31.1 x 10.9 inches_Set with Stand 1251.4 x 730.1 x 94.4 mm / 48.7 x 28.7 x 3.7 inches_Set without Stand	
Weight		20.6 kg / 45.4 lbs_Set with Stand 18.0 kg / 39.7 lbs_Set without Stand	
TV System		Tuning	Frequency Synthesize (Refer to detailed Frequency Table)
		System	ATSC & Clear QAM
		Sound	NTSC-M, Dolby Digital Plus/Pulse
Environmental Considerations		Operating Temperature : 32°F ~ 122°F (0°C ~ 50°C) Operating Humidity : 20% ~ 90% Storage Temperature : -4°F ~ 140°F (-20°C ~ 60°C) Storage Humidity : 10% ~ 90%	
Audio Specifications		MAX Internal Audio Output Power : Each 10 W (Left/Right) Equalizer : 5 Band Output Frequency : RF : 20 Hz ~ 15.4 kHz AV/Componet/HDMI : 20 Hz ~ 20 kHz	
Note : Samsung 3D, 3D Converter, Dolby Digital +, SRS TheaterSound HD, Game Mode, Film Mode, Energy Saving			

2-1-3. Specification Comparison to Old Models

Model	UE6Q(UN**EH6030F)	UD6V(UE**D6500**)
Design		
Display Type	LED TV	LED TV
Built-in TUEer	○	○
Resolution	1920 x 1080	1920 x 1080
LCD Panel	TFT LCD Panel 120 Hz	TFT LCD Panel 120 Hz
Screen Size	40"/46"/55"	32"/37"/40"/46"/55"/60"
Picture ratio	16:9	16:9
Contrast Ratio	MEGA	MEGA
Picture Enhancer	3D HyperReal Engine	3D HyperReal Engine
Wide Color Enhance Plus	Wide Color Enhance Plus	Wide Color Enhance Plus
Equalizer	5 Band	5 Band
Auto Volume Control	○	○
Surround Sound	Dolby Digital Plus/Pulse	Dolby Digital Plus
Speaker Output	10 W x 10 W	10 W x 10 W
PIP	X	○
Function	Jog Function	Touch Function
Caption	○	○
Game Mode	○	○
Energy Saving	○	○
3D	○	X
Antenna	1 (Cable/Air)	1 (Cable/Air)

2.2. Detail Factory Option



NOTE

If you replace the main board with new one, please change the factory option as well.
The options you must change are "Type".

Model Name		UN40EH6030F	UN46EH6030F	UN55EH6030F
PANEL	Vendor	AML	AML	AML
	Code	BN95-00698A	BN95-00700A	BN95-00702A
	Spec.	LTJ400HV10-V	LTJ460HW09-V	LTJ550HW12-V
SMPS	Vendor	SEM	SEM	HANSOE
	Code	BN44-00552A	BN44-00552A	BN44-00556A
	Spec.	PD46CV1_CSM	PD46CV1_CSM	PD55CV1_CHS
MAIN	Chassis Ass'y	Depending on Region, Chassis Ass'y is different.		
	PBA Ass'y	Depending on Region, PBA Ass'y code is different.		
Byte	Item			
0	Factory Reset	-	-	-
1	Type	40A6AF6D	46A6AF6D	55A6AF6D
2	Local Set	US		
3	Basic Model	UE6030	UE6030	UE6030
4	SVC Model	6030	6030	6030
5	TUNER	SI_ATC_2176	SI_ATC_2176	SI_ATC_2176
6	Ch Table	-	-	-
7	Front Color	U-S-BK	U-S-BK	U-S-BK

2.3. Accessories

Product	Description	Code. No	Remark
	Remote Control	AA59-00601A	Samsung Electronics Service center
	Batteries (AAA x 2)	4301-000103	
	Power Cord	3903-000599	
	Warranty Card	BP68-00263E	
	Safety Guide	AA68-03242L	
	User Manual	BN68-04458*	
	3D Glasses	BN96-22902A	
	Holder-Wire Stand	BN61-05491A	



NOTE


The part code for some accessories may differ depending on your region.

4. Troubleshooting

4.1. Troubleshooting

■ Previous Check

1. Check the various cable connections first.
 - Check to see if there is a burnt or damaged cable.
 - Check to see if there is a disconnected or loose cable connection.
 - Check to see if the cables are connected according to the connection diagram.
2. Check the power input to the Main Board.




3. Check the power in & output between IP & Main Board, Main Board & Panel, IP & Panel.

■ How to know it is from Main Board or T-Con when some problems happen


1. No Picture : Backlight is on, but there is no picture and LED indicator in front of TV is blinking.
 - Check the LVDS Cable connection. If still problems, change the T-CON Board and then Main Board step by step.
2. Picture distortion : Enter the service mode → Choose 'SVC' → Check the 'internal pattern.'

- Enter 'Service Mode.'

- If you do not have Factory remote control



- If you have Factory remote control



3. Choose 'SVC.'
4. Choose 'Test pattern.'
5. Select the each pattern and then check all pattern is ok or not.




- For All mode

NT72558	Echo_FS FRC Post	Picture	Problem
OK	OK	NG	Main Board or Signal Source.
NG	OK	NG	Main Board.
NG	NG	NG	Main or LVDS cable or T-CON or Panel.

- Only for HDMI mode (additional check)

HDMI	Picture	Problem
OK	NG	There is no problems after HDMI IC check HDMI source or HDMI jack.
NG	NG	There is no problems before HDMI IC check X10+ pattern or LVDS cable or T-CON.

■ Simple flow chart of malfunction



4.2. How to check fault symptom


4-2-1. No Power

Symptom	<ul style="list-style-type: none"> The PD board relay does not work when connecting the power cord. The units appears to be dead.
Major checkpoints	<p>The PD relay does not work when connecting the power cord if the cables are improperly connected or the Main Board or PD is not functioning. In this case, check the following: Check the internal cable connection status inside the unit.</p> <ul style="list-style-type: none"> Check the fuses of each part. Check the output voltage of PD. Replace the Main Board.
Diagnostics	<pre> graph TD Q1[Power indicator LED on?] -- No --> A1[Check an AC power connection.] Q1 -- Yes --> Q2[Check the backlight on, when 20P cable unconnected?] Q2 -- No --> A2[Change 20P power cable. Change Main Power Assy.] Q2 -- Yes --> Q3[Check 'Stand-By 5.3V' appear at? BD207 : A5.3V] Q3 -- No --> A2 Q3 -- Yes --> Q4[Check 'Power input of Main Ass'y' DC B13V, B5.3V appear at? CN201 #11, 12, 13(B13V) 0V to 13V (CN201 #11, 12, 13) CN201 #1, 3 (B5.3V) 0V to 5.3V (CN201 #1, 3)] Q4 -- No --> A2 Q4 -- Yes --> Q5[Check 'Power IC output of Main Ass'y? L202 : B3.3V / L201 : B1.1V IC201 : A3.3V / IC202 : B1.5V IC203 : B2.5V] Q5 -- No --> A3[Change Main Assy.] Q5 -- Yes --> Q6[Check Input power of 'T-CON Board'? F11(T-CON) : B13V] Q6 -- No --> A4[Reconnect or change the LVDS cable.] Q6 -- Yes --> Q7[Check Input power of 'T-CON Board'? L9(T-CON) : VCC12 / TP_VCC33 : VCC33] Q7 -- No --> A5[Change the T-CON Board.] </pre> <p>The flowchart starts with 'Power indicator LED on?'. If 'No', the action is 'Check an AC power connection.'. If 'Yes', it proceeds to 'Check the backlight on, when 20P cable unconnected?'. If 'No', the action is 'Change 20P power cable. Change Main Power Assy.'. If 'Yes', it goes to 'Check 'Stand-By 5.3V' appear at? BD207 : A5.3V'. If 'No', the action is 'Change 20P power cable. Change Main Power Assy.'. If 'Yes', it goes to 'Check 'Power input of Main Ass'y' DC B13V, B5.3V appear at? CN201 #11, 12, 13(B13V) 0V to 13V (CN201 #11, 12, 13) CN201 #1, 3 (B5.3V) 0V to 5.3V (CN201 #1, 3)'. If 'No', the action is 'Change 20P power cable. Change Main Power Assy.'. If 'Yes', it goes to 'Check 'Power IC output of Main Ass'y? L202 : B3.3V / L201 : B1.1V IC201 : A3.3V / IC202 : B1.5V IC203 : B2.5V'. If 'No', the action is 'Change Main Assy.'. If 'Yes', it goes to 'Check Input power of 'T-CON Board'? F11(T-CON) : B13V'. If 'No', the action is 'Reconnect or change the LVDS cable.'. If 'Yes', it goes to 'Check Input power of 'T-CON Board'? L9(T-CON) : VCC12 / TP_VCC33 : VCC33'. If 'No', the action is 'Change the T-CON Board.'.</p>

	<p style="text-align: center;">↓ Yes ↓</p> <div style="border: 1px solid black; padding: 5px; margin: 0 auto; width: fit-content;">Please, Contact tech support.</div>
Caution	Make sure to disconnect the power before working on the IP Board.

www.eletronica geral.com.br


■ Location of Parts




4-2-2. No Video (3-HDMI_Digital signal)

Symptom	Audio is normal but no picture is displayed on the screen.
Major checkpoints	<ul style="list-style-type: none"> • Check the HDMI source. • Check the HDMI switch. • This may happen when the LVDS cable connecting the Main Board and the Panel is disconnected.
Diagnostics	<pre> graph TD Q1[Power indicator LED is off. Lamp(Backlight) on, no video ?] -- No --> A1[Check a set in the 'Stand-by mode'.] Q1 -- Yes --> Q2[Check the HDMI source and connection of HDMI cable ?] Q2 -- No --> A2[Input the HDMI signal properly.] Q2 -- Yes --> Q3[1 Check the signal at Input of Main board ?] Q3 -- No --> A3[Check CN601~3. Check HDMI cable. Change the Main Assy.] Q3 -- Yes --> Q4[2 Check the LVDS clk signal at output of Main Board? ODD_TXCLK- / ODD_TXCLK+ EVEN_TXCLK- / EVEN_TXCLK+] Q4 -- No --> A4[Check IC901(Novatek). Change the Main Assy.] Q4 -- Yes --> Q5[Check the LVDS cable? Replace the T-CON / LCD panel?] Q5 -- No --> A5[Please, Contact Tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

■ Location of Parts



■ Waveforms




www.electroniccegal.com.br



4-2-3. No Video (Tuner_CVBS)

Symptom	Audio is normal but no picture is displayed on the screen.
Major checkpoints	<ul style="list-style-type: none"> • Check the Tuner CVBS source. • Check the Tuner. • This may happen when the LVDS cable connecting the Main Board and the Panel is disconnected.
Diagnostics	<pre> graph TD Q1[Power indicator LED is off. Lamp(Backlight) on, no video ?] -- No --> A1[Check a set in the 'Stand-by mode'.] Q1 -- Yes --> Q2[Check the RF source and the connection of RF cable ?] Q2 -- No --> A2[Input the RF source properly.] Q2 -- Yes --> Q3[1 Check the Power of Tuner ? Pin #17 of Tuner : B3.3V_Tuner Pin #18 of Tuner : B1.2V_Tuner] Q3 -- No --> A3[Change the Main Assy.] Q3 -- Yes --> Q4[2 Check the CVBS data out of IC901? C807 : Tuner CVBS] Q4 -- No --> A4[Check IC901(Novatek). Change the Main Assy.] Q4 -- Yes --> Q5[Check the LVDS clk signal at output of Main Board? ODD_TXCLK- / ODD_TXCLK+ EVEN_TXCLK- / EVEN_TXCLK+] Q5 -- No --> A5[Check IC901(Novatek). Change the Main Assy.] Q5 -- Yes --> Q6[Check the LVDS cable? Replace the T-CON / LCD panel?] Q6 -- No --> A6[Please, Contact Tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

■ Location of Parts



■ Waveforms




www.electroniccogral.com.br




4-2-4. No Video (Tuner_DTV)

Symptom	Audio is normal but no picture is displayed on the screen.
Major checkpoints	<ul style="list-style-type: none"> • Check the DTV source. • Check the Tuner. • This may happen when the LVDS cable connecting the Main Board and the Panel is disconnected.
Diagnostics	<pre> graph TD Q1[Power indicator LED is off. Lamp(Backlight) on, no video ?] -- No --> A1[Check a set in the 'Stand-by mode'.] Q1 -- Yes --> Q2[Check the RF source and the connection of RF cable ?] Q2 -- No --> A2[Input the RF source properly.] Q2 -- Yes --> Q3[1 Check the 'signal strength' in Self Diagnosis menu Strength is enough?] Q3 -- No --> A3[Check the DTV source.] Q3 -- Yes --> Q4[2 Check the Power of Tuner ? Pin #17 of Tuner : B1.2V_Tuner Pin #18 of Tuner : B3.3V_Tuner] Q4 -- No --> A4[Change the Main Assy.] Q4 -- Yes --> Q5[2 Check the LVDS clk signal at output of Main Board? ODD_TXCLK- / ODD_TXCLK+ EVEN_TXCLK- / EVEN_TXCLK+] Q5 -- No --> A5[Check IC901(Novatek). Change the Main Assy.] Q5 -- Yes --> Q6[Check the LVDS cable? Replace the T-CON / LCD panel?] Q6 -- No --> A6[Please, Contact Tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

■ Location of Parts



■ Waveforms




4-2-5. No Video (Video AV 1, 2)



Symptom	Audio is normal but no picture is displayed on the screen.
Major checkpoints	<ul style="list-style-type: none"> • Check the Video CVBS source. • This may happen when the LVDS cable connecting the Main Board and the Panel is disconnected.
Diagnostics	<pre> graph TD Q1[Power indicator LED is off. Lamp(Backlight) on, no video ?] -- No --> A1[Check a set in the 'Stand-by mode'.] Q1 -- Yes --> Q2[Check the video source and the connection of video cable?] Q2 -- No --> A2[Input the video source properly.] Q2 -- Yes --> Q3[Check the LVDS clk signal at output of Main Board? ② ODD_TXCLK- / ODD_TXCLK+ EVEN_TXCLK- / EVEN_TXCLK+] Q3 -- No --> A3[Check IC901(Novatek). Change the Main Assy.] Q3 -- Yes --> Q4[Check the LVDS cable? Replace the T-CON / LCD panel?] Q4 -- No --> A4[Please, Contact Tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

www.electronicrepair.com.br

■ Location of Parts



■ Waveforms




www.electroniccogral.com.br




4-2-6. No Video (Component)

Symptom	Audio is normal but no picture is displayed on the screen.
Major checkpoints	<ul style="list-style-type: none"> • Check the Component source. • This may happen when the LVDS cable connecting the Main Board and the Panel is disconnected.
Diagnostics	<pre> graph TD Q1[Power indicator LED is off. Lamp(Backlight) on, no video ?] -- No --> A1[Check a set in the 'Stand-by mode'.] Q1 -- Yes --> Q2[Check the component source and the connection of component cables? Y, Pb, Pr] Q2 -- No --> A2[Input the component source properly.] Q2 -- Yes --> Q3[Does the component data appear at ? Comp1 Y : R703 Pb : R705 Pr : R707] Q3 -- No --> A3[Check CN401 or Component gender. Change the Main Assy.] Q3 -- Yes --> Q4[Check the LVDS clk signal at output of Main Board? ODD_TXCLK- / ODD_TXCLK+ EVEN_TXCLK- / EVEN_TXCLK+] Q4 -- No --> A4[Check IC901(Novatek). Change the Main Assy.] Q4 -- Yes --> Q5[Check the LVDS cable? Replace the T-CON / LCD panel?] Q5 -- No --> A5[Please, Contact Tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

■ Location of Parts



■ Waveforms




www.electronicmag.com.br

4-2-7. No No Sound (1. Speaker, 2. Monitor_Out, 3. Optical)





Symptom	Video is normal but there is no sound.
Major checkpoints	<ul style="list-style-type: none"> • When the speaker connectors are disconnected or damaged. • When the sound processing part of the Main Board is not functioning. • Speaker defect.
Diagnostics	<pre> graph TD Q1[Check the source and the connection of sound cable? Comp/DVI to HDMI] -- No --> A1[Input the sound source properly.] Q1 -- Yes --> Q2[Check the signal at input of Main Board? AV, COMP R : R427 / L : R426 MO R : R422 / L : R421] Q2 -- No --> A2[Check CN301, CN401. Change the Main Assy.] Q2 -- Yes --> Q3[1. Check the DATA between the Audio IC's ? Pin #4 of IC301 : WCK Pin #3 of IC301 : SDATA] Q3 -- No --> A3[Check IC303. Change the Main Assy.] Q3 -- Yes --> Q4[1. Check the Speaker sound data at? CN302 2. Check the Monitor out sound data at? CN301 3. Does the SODIF OUT sound data appear at? OP301] Q4 -- No --> A4[Check IC303. Change the Main Assy.] Q4 -- Yes --> Q5[Replace speaker ?] Q5 -- No --> A5[Please, Contact Tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

■ Location of Parts



www.electroniccage.com.br

■ Waveforms




4.3. Factory Mode Adjustments

4-3-1. Entering Factory Mode

To enter 'Service Mode' Press the remote -control keys in this sequence :

- If you do not have Factory remote control



- If you have Factory remote control



- If you don't have Factory remote control, can't control some menus. (Expert, Advanced menu)

Option	T-NVTE5AKUC-xxxx
Control	T-NVTE5AKUC-xxxx
SVC	E-Manual : NVATSCE-xxxx
Expert	EDID SUCCESS
ADC/WB	HDCP SUCCESS
Advanced	CALIB : AV/COMP/PC/HDMI/ Option : 32A6AF6D,US,6030,NONE FactoryCS : 0x581ff12e
	DTP-SP-NT558-0401-000
	RFS : "NT558 0090"
	Kernel Ver : 0072.0724, DTV, NT558
	2012-XX-XX
	FUNC-TAG-ERR
	PPQT Version : 0003, 2012/3/31
	NT72312 : 0x0308

- How to enter the hidden factory mode.

- Into the factory mode.
- Move the tap to Advanced.
- Key input : 0 + 0 + 0 + 0.



NOTE

hidden menu : Advanced

4-3-2. Factory Data

■ Option

Factory Menu Name	Data	Range
Factory Reset	-	
Type	40A6AF6D / 46A6AF6D / 55A6AF6D	
Local set	US	
Basic Model	UE6030	
SVC Model	6030	
TUNER	SI_ATC_2176	
Ch table	NONE	
Front Color	U-S-BK	

■ Control

Factory Menu Name	Data	Range
EDID		
EDID ON/OFF	OFF	
EDID WRITE ALL	...	
EDID WRITE HDMI	...	
EDID WRITE PC	...	
EDID Ver	...	
EDID Port		
EDID WRITE DVI	...	
Sub Option		
RF Mute Time	600ms	
RS-232 Jack	UART	
Watchdog	OFF	
WD COUNT	0	
Dimm Type	EXT	
LVDS FORMAT	JEIDA	
LVDS Srive Strength	400mv	
Language_Arabic	EU	
TOOLS Support	57	
LNA Support	0	
NETWORK Support	Ext-Wifi	
IPERF	Stopped	
Info Link Server Type	operating	
Info Link Country	None	
TTX List	Flof	

Factory Menu Name	Data	Range
TTX Group	UserOSD	
24Px4 Support	OFF	
Power Indicator Support	ON	
BD Wise Support	OFF	
Data Service Support	OFF	
Cable Modulation	Error	
IIC Bus Stop	OFF	
Visual Test	Disable	
Emergency Log Copy		
Checksum	0x0000	
View Log		
Select Log Type	MICOM	
Log View		
Delete Log		
ColorSpace Support	RGB Type	
Gemstar On/Off	OFF	
WSS Support	ON	
PVR Support	OFF	
CI Support	ON	
Eeprom Reset		
Spread Spectrum		
LVDS Spread	ON	
LVDS Period	40K	
LVDS Amplitude	1	
DDR Period	20K	
DDR Amplitude	0.00%	
NT72312 LVDS SSC ON/OFF	ON	
NT72312 LVDS SSC Period	30K	
NT72312 LVDS SSC Modulation	1.00%	
NT72312 DDR SSC ON/OFF	ON	
NT72312 DDR SSC Period	30K	
NT72312 DDR SSC Modulation	1.00%	
DDR Margin		
A CTRL_OFFSET_0_3	0x0	
A CTRL_OFFSET_D	0x0	
B CTRL_OFFSET_0_3	0x0	
B CTRL_OFFSET_D	0x0	
H.264 Margin	8	

4. Troubleshooting

Factory Menu Name	Data	Range
MPEG Margin	1000	
Region	PANEURO	
PnP Language	ENG	
PC Auto Ident	Enable	
OTP Lock	...	
Auto Power	MEMORY	
Key SENSITIVITY	39	
Key Proximity		
OTA Support	OFF	
FKP Down		
WIFI REGION	E	
e-Pop Default	ON	
OPTION_SWU		
OPTION_MEDIAPLAY		
Energy Star Logo	ON	
3D OPTIMIZE VALUE	1	
ECO IC TYPE	NLS1006	
Fast USB Booting	ON	
Nume of Network Stream	0	
CI+1.3	OFF	
HOTEL Option		
Hospitality Mode	OFF	
Power On	...	
Menu OSD	...	
Operation	...	
Music Mode	...	
External Source	...	
Eco Solution	...	
Cloning	...	
Shop Option		
Shop Mode	OFF	
Exhibition Mode	OFF	
3D Cube	OFF	
Asia Option		
TTX	OFF	
China HD	OFF	
NT Conversion	OFF	
Sepco 120Hz	OFF	

www.eletronica geral.com.br

Factory Menu Name	Data	Range
Unbalance	OFF	
FMTransmitter Support	OFF	
FMTransmitter Carrier	OFF	
AF Level adjust	3	
TX Power Level	0	
Mono Last Memory	OFF	
H Shaking	OFF	
SOUND		
High Devi	OFF	
Carrier Mute	OFF	
Volume Curve	Type1	
Speaker Delay Normal	0	
Pilot Level High Thld	0x1Fh	
Pilot Level Low Thld	0x1Dh	
FM Prescale	23	
AM Prescale	30	
NICAM Prescale	29	
Amp Volume	0xC7h	
Amp Scale	0x8eh	
Amp Check Sum	0x1B52015	
Woofer Type	0	
Woofer Scale	0x8ah	
Woofer Check Sum		
Speaker EQ	ON	
PEQ Test	0	
Amp Model	NTP7412	
Speaker cut-off Freq	5	
SPDIF PCM Gain	-9	
FM M Prescale	0	
BTSC Mono Prescale	0	
BTSC stereo Prescale	0	
SAP Prescale	0	
A2Ident High Thld	11	
A2Ident Low Thld	5	
Carrier2 Amp High Thld	4	
Carrier2 Amp Low Thld	2	
Carrier2 SNR High THR	16	
Carrier2 SNR Low THR	6	

4. Troubleshooting

Factory Menu Name	Data	Range
Audio-IP Test	Ready	
TruBass CheckSum	0xFFFFFFFF	
PWM Mode	BD	
Mic Scale	0	
SubWoofer Support	0	
India Sound	OFF	
SAP High T'hld	9	
SAP Low T'hld	7	
Config Option		
Num of ATV	1	
Num of DTV	1	
Num of AV	1	
Num of SVIDEO	0	
Num of COMP	1	
Num of HDMI	2	
Num of PC	0	
Num of SCART	1	
Num of DVI	0	
Num of OPTICAL Link	1	
Num of MEDIA	1	
Num of PANEL KEY	6	
Num of USB Port	1	
Num of HeadPhone	1	
Num of RVU	0	
Num of IPTV	0	
Num of Display	1	
Num of CI	1	
MFT Offset	62.5	
Select LCD/PDP	LCD	
HDMI/DVI SEL	1	
Indicator Led	OFF	
Wall Mount	OFF	
HV Flip	HV Flip	
BackEnd SEL	120Hz	
DVI/HDMI SOUND	Auto	
HDMI HOT PLUG	Disable	
HOTPLUG SWITCHING	Boot	
HOTPLUG DURATION	200ms	

Factory Menu Name	Data	Range
CLK TERM DURATION	200ms	
HDMI FLT CNT SIG	100ms	
HDMI FLT CNT LOS	100ms	
UNSTABLE BAN CNT	3500ms	
HDMI Err Cnt	1	
HDMI ROBIN	ON	
HDMI Callback	OFF	
HDMI CTS Thld	8	
HDMI CTS Cnt1	1	
HDMI EQ	AUTO	
HDMI Write Type	Combine	
HDMI Switch	NONE	
DVI SET TIME	300ms	
Type Of PANEL KEY	Horizontal	
Function Vendor	AUTO	
EcoSensor Support	ON	
LEDMotionPlus Support	ON	
Natural Mode Support	ON	
All Share Support	ON	
Relax Mode Support	OFF	
BT Support	ON	
3D Support	ON	
3D Explorer Support	ON	
DVI-I Support	OFF	
H Write		
HDMI Sync	DE	
HeadPhone Port	A Out2	
FANET	ON	
Support MultiMedia Key	ON	
Config_AV_PATH		
5 Way Function Key	R BOTTOM	
SCC		
SCC Mode	Dynamic	
SCC ON/OFF	OFF	
SCC Input Data		
Hx	272	
Hy	278	
Lx	272	

Factory Menu Name	Data	Range
Ly	278	
sSCC Const		
sSCC Hx	550	
sSCC Hy	556	
sSCC Lx	598	
sSCC Ly	550	
pSCC Const		
pSCC Hx	550	
pSCC Hy	566	
pSCC Lx	598	
pSCC Ly	550	
SCC Source Data	PBA	
SWAP	PBA	

■ SVC

Factory Menu Name	Data	Range
Test Pattern		
LOGIC Pattern Sel	...	
LOGIC Level Sel	...	
NT72312 Pre Test Pattern	0	
NT72312 Post Test Pattern	0	
NT72312 PC mode ON/OFF	OFF	
Panel Auto Setting		
Panel Display Time	21Hr	
Logic Usb D/L	...	
Tuner Status		
T-CON Usb Download		
T-CON CheckSum	0x3076	
Tuner Margin	10	
CAM Wait Time	1500	
MICOM UPGRADE	Off	
BT ADDRESS	8cc8cdc192da	
BT UPGRADE		
BT FREPAIRING	ON	
BT ER COUNT	0	
T-CON TEMP READ	50.05	
TEMP LAST	50.05	
DCC VERSION	0x2C39	

Factory Menu Name	Data	Range
DCC CHK SEL	0	
DCC CHECK LOCAL	0x2131	
DCC CHECK TOTAL		
TS Clock delay	0	
Wifi Fail	...	
TS Clock Delay TC	0	
TS Clock Delay S	0	
Delete S/N		
SVC Reset		
Debug Log Down		

■ Expert

Factory Menu Name	Data	Range
N/D ADJ		
Source		

■ ADC/WB

Factory Menu Name	Data	Range
ADC		
AV Calibration	Success	
Comp Calibraion	Success	
PC Calibration	Success	
HDMI Calibration	Success	
ADC Target		
1st_AV_Low	64	
1st_AV_High	880	
1st_AV_Delta	2	
1st_COMP_Y_Low	64	
1st_COMP_Cb_Low	512	
1st_COMP_Cr_Low	512	
1st_COMP_Y_High	940	
1st_COMP_Cb_High	512	
1st_COMP_Cr_High	512	
1st_COMP_Delta	2	
1st_PC_Low	4	
1st_PC_High	1016	
1st_PC_Delta	2	
2nd_ACH_Low	4	
2nd_ACH_High	940	

4. Troubleshooting


Factory Menu Name	Data	Range
2nd_PC_Low	4	
2nd_PC_High	940	
2nd_Delta	2	
ADC Result		
1st_Y_GH	134	
1st_Y_GL	126	
1st_Cb_BH	...	
1st_Cb_BL	...	
1st_Cr_RH	...	
1st_Cr_RL	...	
2nd_R_L	133	
2nd_G_L	133	
2nd_B_L	133	
2nd_R_H	69	
2nd_G_H	69	
2nd_B_H	69	
White Balance		
Sub Brightness	128	
R-Offset	128	
G-Offset	128	
B-Offset	128	
Sub Contrast	128	
R-Gain	128	
G-Gain	128	
B-Gain	128	
Movie R-Offset	...	
Movie B-Offset	...	
Movie R-Gain	...	
Movie B-Gain	...	

www.eletronica geral.com.br

4.4. White Balance

4-4-1. Calibration

1. Into the Factory Mode.
2. Select **SVC** Menu.
3. Select **ADC/WB** menu.
4. Select **ADC** menu.




4-4-2. Service Adjustment

You must perform Calibration in the Lattice Pattern before adjusting the White Balance.

■ Color Calibration

- Adjust Specification

Source	Setting Mode	Pattern	Use Equipment
HDMI	1280 x 720@60 Hz	Pattern #24 (Chess Pattern)	CA210 & Master MSPG925 Generator



(Chess Pattern)

- Use other equipment only after comparing the result with that of the Master equipment.

Input mode	Calibration	Pattern
CVBS IN (Model_#1)	Perform in NTSC B&W Pattern #24	Lattice
Component IN (Model_#6)	Perform in 720p B&W Pattern #24	Lattice
PC Analog IN (Model_#21)	Perform in VESA XGA (1024x768) B&W Pattern #24	Lattice
HDMI IN	Perform in 720p B&W Pattern #24	Lattice

■ Method of Color Calibration (AV)

1. Apply the NTSC Lattice (N0. 3) pattern signal to the AV IN 1 port.
2. Press the Source key to switch to "AV1" mode.
3. Enter Service mode.
4. Select the "ADC" menu.
5. Select the "AV Calibration" menu.
6. In "AV Calibration Off" status, press the "▶" key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the "AV Calibration" status from Failure to Success.

■ Method of Color Calibration (Component)

1. Apply the 720p Lattice (N0. 6) pattern signal to the Component IN 1 port.
2. Press the Source key to switch to "Component1" mode.
3. Enter Service mode.
4. Select the "ADC" menu.
5. Select the "Comp Calibration" menu.
6. In "Comp Calibration Off" status, press the "▶" key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the "Comp Calibration" status from Failure to Success.

■ Method of Color Calibration (PC)

1. Apply the VESA XGA Lattice (N0. 21) pattern signal to the PC IN port.
2. Press the Source key to switch to "PC" mode.
3. Enter Service mode.
4. Select the "ADC" menu.
5. Select the "PC Calibration" menu.
6. In "PC Calibration Off" status, press the "▶" key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the "PC Calibration" status from Failure to Success.


■ Method of Color Calibration (HDMI)

1. Apply the 720p Lattice (N0. 6) pattern signal to the HDMI1/DVI IN port.
2. Press the Source key to switch to "HDMI1" mode.
3. Enter Service mode.
4. Select the "ADC" menu.
5. Select the "HDMI Calibration" menu.
6. In "HDMI Calibration Off" status, press the "▶" key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the "HDMI Calibration" status from Failure to Success.

www.eletronics.com.br

4-4-3. Adjustment


1. Into the Factory Mode.
2. Select **SVC** Menu.
3. Select **ADC/WB** menu.
4. Select **White Balance** menu.



www.eletroniceggeral.com.br

4.5. White Ratio (Balance) Adjustment

1. You can adjust the white ratio in factory mode (1:Calibration, 3:White-Balance).
2. Since the adjustment value and the data value vary depending on the input source, you have to adjust these in CVBS, Component 1 and HDMI 1 modes.
3. The optimal values for each mode are configured by default. It varies with Panel's size and Specification.
 - Equipment : CS-210
 - Pattern: MIK K-7256 #92 "Flat W/B Pattern" as standard
 - Alternate Equipment : CA200& anyone Master supported pattern#92(refer to right photo)
 - Use other Equipment only after comparing the result with that of the Master equipment.
 - Set Aging time : 60 min



Calibration and Manual setting for WB adjustment

- HDMI : Calibration at #24 Chessboard Pattern Manual adjustment at #92 pattern (720p)
- COMP: Calibration at #24 Chessboard Pattern Manual adjustment at #92 pattern (720p)
- CVBS: Calibration at #24 Chessboard Pattern Manual adjustment at #92 pattern (NTSC)



NOTE

If finishing in HDMI mode, adjustment coordinate is almost same in AV/COMP mode.

www.eletronicoagral.com.br

4.6. AV Control Table

Control Item			Cmd1	Cmd2	Cmd3	Value	
General	Power	Power	0x00	0x00	0x00	0x00	
		Off				0x01	
		On				0x02	
	Volume	Direct	0x01	0x00	0x00	(0~100)	
		Up			0x01	0x00	
		Down			0x02	0x00	
	Mute			0x02	0x00	0x00	0x00
		Ch.	Direct	0x04	-		
			Continuous	Up	0x03	0x00	0x01
Down	0x02	0x00					

Control Item			Cmd1	Cmd2	Cmd3	Value			
Input	Source List	TV	TV	0x0a	0x00	0x00	0x00		
		AV	AV1			0x01	0x00		
			AV2				0x01		
			AV3				0x02		
		S-Video	S-Video1			0x02	0x00		
			S-Video2				0x01		
			S-Video3				0x02		
		Component	Component1			0x03	0x00		
			Component2				0x01		
			Component3				0x02		
		PC	PC1			0x04	0x00		
			PC2				0x01		
			PC3				0x02		
		HDMI	HDMI1			0x05	0x00		
			HDMI2				0x01		
			HDMI3				0x02		
				HDMI4				0x03	Not Support
		DVI	DVI1			0x06	0x00		
			DVI2				0x01		
			DVI3				0x02		

Control Item			Cmd1	Cmd2	Cmd3	Value	
PICTURE	Mode	Dynamic(Entertain)		0x0b	0x00	0x00	0x00
		Standard					0x01
		Movie					0x02
		Natural					0x03
		CAL-NIGHT					0x04

4. Troubleshooting

Control Item		Cmd1	Cmd2	Cmd3	Value	
	CAL-DAY				0x05	
	BD Wise				0x06	
	Relax				0x07	Not Support only PDP (2012)
BackLight (CellLight)		0~20	0x01	0x00	(0~20)	
Contrast		0~100	0x02	0x00	(0~100)	
Brightness		0~100	0x03	0x00	(0~100)	
Sharpness		0~100	0x04	0x00	(0~100)	
Color		0~10	0x05	0x00	(0~100)	
Tint	G/R		0x06	0x00	(0~100)	
Advanced Settings	Black Tone	Off	0x07	0x00	0x00	
		Dark			0x01	
		Darker			0x02	
		Darkest			0x03	
	Dynamic Contrast	Off		0x01	0x00	
		Low			0x01	
		Medium			0x02	
		High			0x03	
	Shadow Detail	2 ~ 2		0x02	(-2~-2)	Not Support
	Gamma	-3 ~ 3		0x03	(-3~3)	
	RGB Only Mode	Off		0x05	0x00	
		Red			0x01	
Green				0x02		
Blue				0x03		
Color Space	Auto		0x06	0x00		
	Native			0x01		
	Custom			0x02		
White Balance	R-Offset(LCD)		0x07	(0~50)		
White Balance	G-Offset(LCD)		0x08	(0~50)		
White Balance	B-Offset(LCD)		0x09	(0~50)		
White Balance	R-Gain(LCD)		0x0a	(0~50)		
White Balance	G-Gain(LCD)		0x0b	(0~50)		
White Balance	B-Gain(LCD)		0x0c	(0~50)		
White Balance	Reset(LCD)		0x0d	0x00		
Flesh Tone	-15 ~ 15		0x0e	(-15~15)		
Edge Enhancement	Off		0x0f	0x00		
	On			0x01		

Control Item		Cmd1	Cmd2	Cmd3	Value	
	xvYCC	Off		0x10	0x00	
		On			0x01	
	Motion Lighting	Off		0x11	0x00	
		On			0x01	
	LED Motion Plus	Off	0x0a	0x07	0x00	
		On(Normal)			0x01	
		Cinema			0x02	Not Support
		Ticker			0x03	
	Picture Option	Color Tone	Cool	0x0a	0x00	0x00
			Standard			0x01
Warm1					0x02	
Warm2					0x03	
Digital Noise Filter		Off		0x02	0x00	
		Low			0x01	
		Medium			0x02	
		High			0x03	
		Auto			0x04	
		Auto Visualization			0x05	
MPEG Noise Filter		Off		0x03	0x00	
		Low			0x01	
		Medium			0x02	
		High			0x03	
		Auto			0x04	
HDMI Black Level		Normal		0x04	0x00	
		Low			0x01	
Film Mode		Off		0x05	0x00	
		Auto1			0x01	
		Auto2			0x02	
		Cinema Smooth			0x03	
Auto Motion Plus		Off		0x06	0x00	
		Clear			0x01	
		Standard			0x02	
		Smooth			0x03	
		Custom			0x04	
		Demo			0x05	

4. Troubleshooting

Control Item				Cmd1	Cmd2	Cmd3	Value
Screen Adjustment	Picture Size	16:9	0x0b	0x0a	0x01	0x00	
		Zoom1				0x01	
		Zoom2				0x02	
		Wide Fit				0x03	
		4:3				0x04	
		Screen Fit				0x05	
		Smart View I				0x06	
		Smart View II				0x07	
		Auto Wide				0x08	
		Wide Zoom				0x09	
	Zoom				0x0a		
Reset Picture	Reset Picture		0x0b	0x0b	0x00	0x00	
3D	3D Mode	Off	0x0b	0x0c	0x00	0x00	
		2D ↔ 3D				0x01	
		Side By Side				0x02	
		Top Bottom				0x03	
		Line By Line				0x04	
		Vertical Line				0x05	
		Checker BD				0x06	
		Frame Sequence				0x07	
	3D ↔ 2D	Off			0x01	0x00	
		On				0x01	
	3D View Point				0x02	(-5~5)	
	Depth				0x03	(1~10)	
	3D Auto View	Off			0x05	0x00	
Message Notice					0x01		
On					0x02		

Not Support

Control Item				Cmd1	Cmd2	Cmd3	Value
Sound	Sound Mode	Standard		0x0c	0x00	0x00	0x00
		Music					0x01
		Movie					0x02
		Clear Voice					0x03
		Amplify					0x04
	Equalizer	Balance			0x01	0x00	(0~20)
		100hz				0x01	(0~20)

Control Item		Cmd1	Cmd2	Cmd3	Value
	300hz			0x02	(0~20)
	1khz			0x03	(0~20)
	3khz			0x04	(0~20)
	10khz			0x05	(0~20)
	Reset			0x06	0x00
SRS TruSurround HD (echo)	Off		0x02	0x00	0x00
Virtual Surround (echo)	On				0x01
SRS TruDialog (echo)	Off		0x03	0x00	0x00
Dialog Clarify (X9)	On				0x01
Preferred Language	English		0x04	0x00	0x00
	Spanish				0x01
	French				0x02
	Korean				0x03
	Japanese				0x04
Multi-Track Sound	Mono		0x05	0x00	0x00
	Stereo				0x01
	SAP				0x02
Auto Volume	Off		0x06	0x00	0x00
	ON				0x01
	Night				0x02
Speaker Select	TV Speaker		0x07	0x00	0x00
	External Speaker				0x01
Sound Select	Main		0x08	0x00	0x00
	Sub				0x01
Sound Reset	Sound Reset		0x09	0x00	0x00
3D Audio	Off		0x0a	0x00	0x00
	Low				0x01
	Medium				0x02
	High				0x03
Auto Stereo	Manual		0x0b	0x00	0x00
	Auto				0x01

Not Support
add 2012Not Support
only KOREA
(2012)

4. Troubleshooting

Control Item		Cmd1	Cmd2	Cmd3	Value	
KEY	Key Generation	0x0d	0x00	0x00	refer to table	
OSD	Show/Hide Control	0x0e	0x00	0x00	0x00	add 2012
	Hide				0x01	
Get Status	Power (On/Off)	0xf0	0x00	0x00	0x00	
	Volume(0~100)	0xf0	0x01	0x00	0x00	
	Mute (On/Off)	0xf0	0x02	0x00	0x00	
	Channel Number	0xf0	0x03	0x00	0x00	
	Source (TV/AV/.../HDMI/...)	0xf0	0x04	0x00	0x00	
	Picture Size	0xf0	0x05	0x00	0x00	
	3D (On/Off)	0xf0	0x06	0x00	0x00	
	Picture Mode	0xf0	0x07	0x00	0x00	
	Sound Mode	0xf0	0x08	0x00	0x00	

Key value	Value	
Up	96 (0x60)	
Down	97 (0x61)	
Left	101 (0x65)	
Right	98 (0x62)	
Menu	26 (0x1A)	
Internet	147 (0x93)	Not Support
Enter(OK)	104 (0x68)	
EXIT	45 (0x2D)	

www.electronicaportal.com.br

4.7. Software Upgrade

Software Upgrade can be performed by downloading the latest firmware from samsung.com to a USB memory device.

- Current Version - The software already installed in the TV.

Software is represented as 'Year/Month/Day_Version'.

4-7-1. How to Check the Software Version

■ Use the Main Menu

1. Click the "MENU" key in remote controller.
2. Select "Support" menu.
3. Locate the menu cursor "Software Upgrade" menu.
4. Click the "INFO" key.
 - Check the Main SW and Micom version.



■ Use the Factory Mode

Option	T-NVTE5AKUC-xxxx
Control	T-NVTE5AKUC-xxxx
SVC	E-Manual : NVATSCE-xxxx
Expert	EDID SUCCESS
ADC/WB	HDCP SUCCESS
Advanced	CALIB : AV/COMP/PC/HDMI/
	Option : 32A6AF6D,US,6030,NONE
	FactoryCS : 0x581ff12e

4-7-2. How to Upgrade Software

1. Insert a USB drive containing the firmware upgrade downloaded from samsung.com into the TV.

 **NOTE**

Please be careful not to disconnect the power or remove the USB drive while upgrades are being applied.

2. The TV will turn off and turn on automatically after completing the firmware upgrade.
3. Please check the firmware version after the upgrades are complete.
 - the new version will have a higher number than the older version.

 **NOTE**

- When software is upgraded, video and audio settings you have made will return to their default (factory) settings.
- We recommend you write down your settings before beginning firmware update.

4. After update is completed, restore your previous settings.

■ Main Software Upgrade

1. Store the sw program named "T-NVTE5AKUC" in USB memory stick.



www.eletronicagpral.com.br

2. Click the "MENU" key in Remote Controller.
3. Select "Support - Software Upgrade - By USB" menu.




4. Click the "ENTER" key.
 - Wait for upgrade complete.
 - Check the Software Version.




4.8. Cover-Middle Rear Dimension


■ 40 inch



■ 46 inch




■ 55 inch



www.eletronicagebral.com.br


5. Wiring Diagram

5.1. Wiring Diagram



5.2. Connector

■ Main Board



❶ CN1401_FHD (to Panel)			
1	NC	14	EVEN_TX4+_LVDS
2	GND	15	EVEN_TX4-_LVDS
3	NC	16	EVEN_TX3+_LVDS
4	NC	17	EVEN_TX3-_LVDS
5	NC	18	GND
6	NC	19	EVEN_TXCLK+_LVDS
7	GND	20	EVEN_TXCLK-_LVDS
8	TCON_SDA	21	GND
9	PANEL_I2C_EN	22	EVEN_TX2+_LVDS
10	NC	23	EVEN_TX2-_LVDS
11	NC	24	EVEN_TX1+_LVDS
12	TCON_SCL	25	EVEN_TX1-_LVDS
13	GND	26	EVEN_TX0+_LVDS

❶ CN1401_FHD (to Panel)			
27	EVEN_TX0-_LVDS	40	ODD_TX1-_LVDS
28	GND	41	ODD_TX0+_LVDS
29	ODD_TX4+_LVDS	42	ODD_TX0-_LVDS
30	ODD_TX4-_LVDS	43	GND
31	ODD_TX3+_LVDS	44	GND
32	ODD_TX3-_LVDS	45	GND
33	GND	46	NC
34	ODD_TXCLK+_LVDS	47	Panel_13V_PW
35	ODD_TXCLK-_LVDS	48	Panel_13V_PW
36	GND	49	Panel_13V_PW
37	ODD_TX2+_LVDS	50	Panel_13V_PW
38	ODD_TX2-_LVDS	51	Panel_13V_PW
39	ODD_TX1+_LVDS		

② CN201 (to Powr board)			
1	B5.3V	11	B13V
2	SW_POWER_OUT	12	B13V
3	B5.3V	13	B13V
4	A5.3V	14	PWM_DIMM1_OUT
5	GND	15	GND
6	GND	16	PWM_DIMM2_OUT
7	B12VS	17	OVD_ON_OFF
8	GND	18	PWM_DIMM3_OUT
9	B12VS	19	NC
10	SW_INVERTER	20	PWM_DIMM4_OUT

③ CN1201_F18 (FUNCTION)			
1	IR	10	USB_BT_DM
2	FRAME_SYNC_IN	11	KEY_INPUT1
3	GND	12	GND
4	BT_SYNC	13	KEY_INPUT2
5	A3.3V	14	BT_WAKE
6	GND	15	LED_STB
7	MSCL	16	POWER_DET
8	USB_BT_DP	17	NC
9	MSDA	18	NC

④ CN302 (SPEAKER)			
1	R+	3	L+
2	R-	4	L-

⑤ CN1203(DEBUG)			
1	GND	4	DEBUG_TX
2	DEBUG_RX	5	DEBUG_TX
3	DEBUG_TX	6	GND

⑥ CN502(COMPONENT)			
1	GND	9	COMP2_PR
2	COMP2_Y_CVBS	10	GND
3	IDENT_VIDEO2	11	COMP2_AV2_SL_IN
4	GND	12	COMP2_AV2_SR_IN
5	COMP2_PB	13	GND
6	IDENT_COMP2	14	COMP2_AV2_SR_IN
7	GND	15	COMP2_AV2_SL_IN
8	COMP2_PR		

⑦ CN601_H1 (HDMI1)			
1	HDMI1_RX2+	11	GND
2	GND	12	HDMI1_RXCLK-
3	HDMI1_RX2-	13	HDMI_CEC
4	HDMI1_RX1+	14	GND
5	GND	15	SCL
6	HDMI1_RX1-	16	SDA
7	HDMI1_RX0+	17	GND
8	GND	18	5V
9	HDMI1_RX0-	19	HPD
10	HDMI1_RXCLK+		

⑧ CN602_H2 (HDMI2)			
1	HDMI2_RX2+	11	GND
2	GND	12	HDMI2_RXCLK-
3	HDMI2_RX2-	13	HDMI_CEC
4	HDMI2_RX1+	14	GND
5	GND	15	SCL
6	HDMI2_RX1-	16	SDA
7	HDMI2_RX0+	17	GND
8	GND	18	5V
9	HDMI2_RX0-	19	HPD
10	HDMI2_RXCLK+		

⑨ CN1502_U2 (USB1)			
1	USB_VCC	3	USB_DP
2	USB_DM	4	GND

⑩ CN402(DVI SOUND OUT)			
1	GND	4	NC
2	DVI_SR_OUT	5	NC
3	DVI_SL_OUT	6	NC

⑪ OP301 (OPTICAL)			
1	SPDIF_OUT	3	GND
2	GND		

5.3. Connector Functions

Connector	Function
CN201 ↔ IP CNM803	Supply main power and dimming signal from IP Board to Main Board.
CN1401_FHD ↔ T-CON CNF1	The LVDS signal transferred from Main Board to Panel.

www.eletroniceggeral.com.br

5.4. Cables

Use	LEAD (Main - IP 20P)	LVDS CALBE (Main - Panel 51P)
Code No.	40" : BN39-01475N 46" : BN39-01475H 55" : BN39-01475P	40" : BN96-17116W 46" : BN96-17116X 55" : BN96-22239Z
Image		




NOTE

The part code for some cables may differ depending on your region.

www.electroniccage.com.br

1. Exploded View & Part List

Exploded View



Parts List

No.	Parent	Lvl.	Loc.	Material Code	Description & Specification	SNA	Qty.
1	BN91-09434A	2	PANEL	BN95-00700A	PRODUCT LCD-AMLCD; E6030, 46"3D, Direct-L	SA	1
2	BN91-09577A	2	SP01A	BN96-21669J	ASSY SPEAKER P; 6ohm,4pin,10W,UE6030 55"	SA	1
3	BN95-00700A	3	CB20	BN61-07953A	BRACKET-WALL; UE5000 46",EGI-SECC PL,T1.2	SA	4
4	BN91-09577A	2	P001A	BN44-00552A	DC VSS-LED TV PD BD; PD46CV1_CSM,PSLF930C	SA	1
5	BN91-09812A	2	M0014	BN94-05993A	ASSY PCB MAIN; UN46EH6030FXZP	SA	1
6	BN91-09577A	2		BN61-08046F	HOLDER-SIDE, AV; UE6030,40,UO,HIPS,HIPS,B	SNA	1
7	BN91-09577A	2	FB01A	BN96-23838D	ASSY BOARD P-JOG SWITCH & IR; UN46EH6030,	SA	1
8	BN90-04101A	2	R001	BN63-09753A	COVER-REAR; UE6030,46,UO,HIPS,V0,BK0020	SNA	1
9	BN90-03831A	2	SG01A	BN96-21742A	ASSY GUIDE P-STAND; UE5000,40/46/55,UO,PC	SA	1
10	BN90-03831A	2	SB04A	BN96-21736E	ASSY STAND P-BASE; UE5000,40/46,W/W,ABS,H	SA	1

www.electronicagral.com.br

2. Electrical Parts List

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
			UN46EH6030FXZP (TS01)		
1	S001A	BN90-03831A	ASSY STAND;UEH5000,40/46,UO	1	SNA
.2	SB04A	BN96-21736E	ASSY STAND P-BASE;UE5000,40/46,W/W,ABS,H	1	SA
..3	SCREW	6003-001782	SCREW-TAPTYPE;BH,+,B,M4,L12,ZPC(BLK),SWR	3	SA
..3	SCREW	6003-001785	SCREW-TAPTYPE;FH,+,B,M4,L8,ZPC(BLK),SWRC	6	SA
..3		BN61-04692A	BOSS-PRIMER;#94,clear,35cps	0	SNA
..3	SG01	BN61-08036A	GUIDE-STAND NECK;UE5000,40,PC+G/F 20%,V2	1	SNA
..3		BN61-08105A	BRACKET-STAND BOTTOM;UE5000 40/46",EGI-S	1	SNA
..3	CCM1	BN63-02183D	COVER-SHEET;Rhcm,PE Vinyl,T0.05,680mm,20	0	SNA
..3		BN63-09084A	COVER-STAND, BASE;UE5000,40/46,W/W,ABS,H	1	SNA
..3		BN68-04116A	LABEL-BASE;A/P100G,0.08,20X,70mm,White,O	1	SNA
..3		BN73-00313A	RUBBER-FOOT;UD4000 19,RUBBER,13*13,T2.0,	7	SNA
.2	SG01A	BN96-21742A	ASSY GUIDE P-STAND;UE5000,40/46/55,UO,PC	1	SA
..3	T0524	6902-001063	BAG PE;LDPE,T0.05,W180,L350,TRP,RECYCLE	1	SNA
..3	SG03	BN61-07941A	GUIDE-STAND;UE5000/6000,40/46/55,W/W,PC+	1	SNA
..3		BN68-04027A	MANUAL FLYER-03,STAND GUIDE;U4000(32),SA	1	SNA
..3		BN68-04116B	LABEL-BASE;A/P100G,0.08,20X,70mm,Dark Gr	1	SNA
..3		BN96-12031E	ASSY ACCESSORY-SCREW;10 LCD-TV,6003-0010	1	SNA
..4	SCREW	6003-001782	SCREW-TAPTYPE;BH,+,B,M4,L12,ZPC(BLK),SWR	8	SA
..4	T0524	6902-000341	BAG PE;LDPE,T0.05,L90,W70,TRP,,PE MARK	1	SNA
1	R001A	BN90-04101A	ASSY COVER REAR;UE6030,46,UO	1	SNA
.2		6001-002755	SCREW-MACHINE;BH,+,M3,L6,ZPC(BLK),SWRCH1	6	SA
.2	SCREW	6003-001782	SCREW-TAPTYPE;BH,+,B,M4,L12,ZPC(BLK),SWR	15	SA
.2	T0527	AA68-03539A	LABEL BAR CODE;65X40mm,ART PAPER	1	SNA
.2	R001	BN63-09753A	COVER-REAR;UE6030,46,UO,HIPS,V0,BK0020	1	SNA
1		BN91-09434A	ASSY LCM-AMLCD;BN95-00700A	1	SNA
.2	PANEL	BN95-00700A	PRODUCT LCD-AMLCD;E6030, 46"3D, Direct-L	1	SA
..3		6001-002756	SCREW-MACHINE;BH,+,M3,L6,ZPC(WHT),SWRCH1	4	SA
..3		6001-002757	SCREW-MACHINE;BH,+,M3,L4,ZPC(WHT),SWRCH1	3	SA
..3	T0527	AA68-03539A	LABEL BAR CODE;65X40mm,ART PAPER	1	SNA
..3		BN02-00102B	TAPE FILAMENT;UE7000,#893,0.15,25,50,WHI	0	SNA
..3	CB20	BN61-07953A	BRACKET-WALL;UE5000 46",EGI-SECC PL,T1.2	4	SA
..3		BN63-09395B	COVER-T CON;Y12 F-LED (60Hz/120Hz),CC105	1	SNA
..3		BN63-09888A	GASKET;LTJ460HW09-V,Conductive Fabric,2.	2	SNA
..3		BN68-03216A	LABEL-STICKER;WW,Yupo Polyester,80X40,AV	1	SNA
..3		BN90-04056A	ASSY MISC-BLU;5K 46"	1	SNA
..4		BN02-00043B	TAPE ETC-SHEET FIXING;NNB 32/40/46/55,3M	1	SNA
..4		BN61-07891A	SUPPORT-PLATE;Y12 FULL LED,PC,Clear	4	SNA

Exploded Views and Parts List

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
...4		BN61-08059A	LGP-DIFFUSERS PLATE;46" Diffuser Plate,P	1	SNA
...4		BN61-08161A	HOLDER-LED-PCB;Direct-LED,PC,white	48	SNA
...4		BN63-09222A	SHEET-REFLECTOR;46",F-LED, UXJP 175,SHE	1	SNA
...4		BN63-09226A	SHEET-DIFFUSER;46",F-LED, CK47,SHEET,0.3	1	SNA
...4		BN96-21612B	ASSY MISC P-CHASSIS BOTTOM;Y12 Full LED	1	SNA
....5		BN02-00094A	TAPE PET;Y12 F-LED,MT-PFR,T 0.05,W30,L40	1	SNA
....5		BN02-00102B	TAPE FILAMENT;UE7000,#893,0.15,25,50,WHI	0	SNA
....5	EC13	BN39-01589A	LEAD CONNECTOR;46" Direct wire-harness,F	1	SNA
....5		BN61-08161A	HOLDER-LED-PCB;Direct-LED,PC,white	2	SNA
....5	CC02	BN64-01897A	CHASSIS-BOTTOM;Y12 FULL-LED 46",EGI-SECC	1	SNA
....5		BN96-21487A	ASSY MISC P-SUB PCB;46" Sub PCB,2pin*6ea	1	SNA
...4		BN96-21621A	ASSY FRAME P-MOLD MIDDLE U;Y12 Full LED	1	SNA
....5		BN61-07884A	FRAME-MOLD MIDDLE-U;Y12 F-LED 46",PC+G/F	1	SNA
...4		BN96-22350A	ASSY FRAME P-MOLD MIDDLE D;Y12 Full LED	1	SNA
....5		BN60-00444A	SPACER-PANEL (UD);F-LED 46,MGT-30DG,L101	1	SNA
....5		BN61-07885A	FRAME-MOLD MIDDLE-D;Y12 F-LED 46",PC+G/F	1	SNA
...4		BN96-22351A	ASSY FRAME P-MOLD MIDDLE SIDE;Y12 Full L	2	SNA
....5		BN60-00445A	SPACER-PANEL (LR);F-LED 46,MGT-30DG,L579	2	SNA
....5		BN61-07886A	FRAME-MOLD MIDDLE-SIDE;F-LED 46",PC+G/F1	2	SNA
...4		BN96-24110A	ASSY MISC P-LED BAR;46" Direct_Left_Slid	6	SNA
...4		BN96-24111A	ASSY MISC P-LED BAR;46" Direct_Right_6e	6	SNA
...3	TCON	BN95-00690A	ASSY T CON;LSJ460HW05-E,FHD 60Hz+	1	SA
...4	T0756	AA68-01018A	LABEL-PQS;50mmX,13,WHITE	1	SNA
...4		BN97-06771A	ASSY SMD;BN95-00690A	1	SNA
....5		0202-001477	SOLDER-CREAM;LST309-M,D20~45um,96.5Sn/3A	1	SNA
....5	DS01A	0401-001192	DIODE-SWITCHING;MMBD7000LT1,100V,200mA,S	2	SA
....5		0403-001172	DIODE-ZENER;UDZ6.8B,6.65-6.93V,200MW,SOD	1	SNA
....5	D0254	0404-001314	DIODE-SCHOTTKY;B260A,60V,2000mA,SMA,TP	1	SNA
....5	D0254	0404-001373	DIODE-SCHOTTKY;PD3S160,60V,1000mA,PowerD	2	SNA
....5	T0139	0406-001200	DIODE-TVS;RCLAMP0504F,6/-/-V,150W,SC-70	2	SA
....5		0406-001317	DIODE-TVS;SMAJ14A,15.6/-/17.2V,400W,SMA	1	SNA
....5		0406-001445	DIODE-TVS;RClamp7512N,2.7/2.8/2.9,300W,S	2	SA
....5	Q613	0501-000465	TR-SMALL SIGNAL;MMBT3904,NPN,350mW,SOT-2	6	SA
....5		0502-001331	TR-POWER;NSS30100LT1G,PNP,310mW,SOT-23,T	1	SA
....5		0502-001345	TR-POWER;FCX491A,NPN,1000mW,SOT89,TR,900	2	SA
....5		0502-001346	TR-POWER;FCX591A,PNP,1000mW,SOT89,TR,30/	3	SA
....5		0505-002485	FET-SILICON;FDC658AP,P,-30V,-4A,0.075ohm	1	SA
....5		0505-002826	FET-SILICON;ZXMN6A07F,N,60V,1A,0.4ohm,0.	1	SNA
....5		1201-003130	IC-OP AMP;iML2811SEC,MSOP,TP,8P,3x3mm,SI	1	SA
....5	IC012	1203-006138	IC-POSI.ADJUST REG.;AP1117DGZ-13-89,TO-2	1	SA

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
....5		1203-006989	IC-VOL. GENERATOR;ISL24826,QFN,48P,7x7mm	1	SNA
....5		1203-007191	IC-DC/DC CONVERTER;SM4152LA,QFN,48P,7x7m	1	SNA
....5	IS01	1209-001761	IC-SENSOR;LM75ADP,TSSOP,8P,3.1x3.1mm,PLA	1	SA
....5	SR51	2007-000040	R-CHIP;150ohm,1%,1/10W,TP,1608	1	SNA
....5	DR1	2007-000043	R-CHIP;1Kohm,1%,1/10W,TP,1608	2	SA
....5	PR4	2007-000052	R-CHIP;10Kohm,1%,1/10W,TP,1608	1	SA
....5	R104	2007-000063	R-CHIP;150Kohm,1%,1/10W,TP,1608	1	SNA
....5	ND51C2	2007-000066	R-CHIP;20Kohm,1%,1/10W,TP,1608	2	SNA
....5	KR24	2007-000067	R-CHIP;15Kohm,1%,1/10W,TP,1608	1	SNA
....5	KAR21	2007-000070	R-CHIP;0ohm,5%,1/10W,TP,1608	11	SA
....5	MR166	2007-000119	R-CHIP;560ohm,5%,1/10W,TP,1608	1	SA
....5	R105	2007-000138	R-CHIP;100ohm,5%,1/16W,TP,1005	8	SA
....5	R111	2007-000171	R-CHIP;0ohm,5%,1/16W,TP,1005	15	SA
....5	PFRF2	2007-000219	R-CHIP;1.2Kohm,1%,1/10W,TP,1608	2	SNA
....5		2007-000231	R-CHIP;1.3Kohm,1%,1/10W,TP,1608	2	SA
....5	PPR2	2007-000343	R-CHIP;120ohm,1%,1/10W,TP,1608	1	SNA
....5		2007-000448	R-CHIP;180ohm,1%,1/10W,TP,1608	2	SA
....5	MR9	2007-000455	R-CHIP;18Kohm,1%,1/10W,TP,1608	2	SA
....5	R809	2007-000475	R-CHIP;1Mohm,1%,1/10W,TP,1608	1	SA
....5	PRS34	2007-000516	R-CHIP;2.7Kohm,1%,1/10W,TP,1608	3	SA
....5	R38	2007-000640	R-CHIP;270ohm,1%,1/10W,TP,1608	1	SA
....5	ER13	2007-000669	R-CHIP;2Kohm,1%,1/10W,TP,1608	1	SNA
....5	AR28	2007-000683	R-CHIP;3.3Kohm,1%,1/10W,TP,1608	1	SA
....5	R299	2007-000772	R-CHIP;33Kohm,1%,1/10W,TP,1608	1	SA
....5	HR13	2007-000821	R-CHIP;390ohm,1%,1/10W,TP,1608	1	SNA
....5	S1G0843	2007-000923	R-CHIP;470Kohm,1%,1/10W,TP,1608	1	SA
....5	HR10	2007-000962	R-CHIP;5.1Kohm,1%,1/10W,TP,1608	4	SA
....5	CER42	2007-000999	R-CHIP;510ohm,1%,1/10W,TP,1608	1	SA
....5	AR2	2007-001068	R-CHIP;6.8Kohm,1%,1/10W,TP,1608	1	SA
....5	AHR41	2007-001175	R-CHIP;8.2Kohm,1%,1/10W,TP,1608	3	SA
....5	DR43	2007-001298	R-CHIP;51ohm,5%,1/16W,TP,1005	8	SNA
....5	R3301	2007-001433	R-CHIP;12Kohm,1%,1/10W,TP,1608	2	SA
....5	R1	2007-002425	R-CHIP;1ohm,5%,1/10W,TP,1608	2	SNA
....5		2007-002768	R-CHIP;6.2Kohm,1%,1/10W,TP,1608	3	SA
....5		2007-002797	R-CHIP;560ohm,5%,1/16W,TP,1005	1	SNA
....5		2007-002900	R-CHIP;11Kohm,1%,1/10W,TP,1608	1	SNA
....5	PR24	2007-002970	R-CHIP;56ohm,5%,1/16W,TP,1005	8	SA
....5		2007-003018	R-CHIP;43ohm,5%,1/16W,TP,1005	8	SA
....5	R365	2007-007107	R-CHIP;100Kohm,1%,1/16W,TP,1005	1	SNA
....5		2007-007134	R-CHIP;39Kohm,1%,1/16W,TP,1005	2	SA

Exploded Views and Parts List

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
....5		2007-007136	R-CHIP;4.7Kohm,1%,1/16W,TP,1005	27	SNA
....5	DR4	2007-007142	R-CHIP;10Kohm,1%,1/16W,TP,1005	7	SA
....5		2007-007306	R-CHIP;100ohm,1%,1/16W,TP,1005	14	SNA
....5		2007-007309	R-CHIP;12Kohm,1%,1/16W,TP,1005,0.35	3	SA
....5		2007-007317	R-CHIP;2.2Kohm,1%,1/16W,TP,1005	1	SA
....5		2007-007318	R-CHIP;1Kohm,1%,1/16W,TP,1005	2	SA
....5		2007-008070	R-CHIP;130ohm,1%,1/10W,TP,1608	1	SNA
....5		2007-008117	R-CHIP;2.7Kohm,1%,1/16W,TP,1005	1	SA
....5	S0F1352	2007-008596	R-CHIP;0.1ohm,1%,1/4W,TP,3216	1	SC
....5		2007-008779	R-CHIP;0ohm,1%,1/16W,TP,1005	2	SA
....5	C507	2203-000489	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1005	2	SA
....5	KAC5	2203-001126	C-CER,CHIP;0.68nF,10%,50V,X7R,TP,1608	1	SNA
....5	C627	2203-001697	C-CER,CHIP;0.082nF,5%,50V,NP0,TP,1608	2	SNA
....5	AVC08	2203-002398	C-CER,CHIP;22nF,10%,50V,X7R,TP,1608	1	SNA
....5	AC2	2203-002711	C-CER,CHIP;100nF,10%,25V,X7R,TP,1608	2	SA
....5	AAC1	2203-005249	C-CER,CHIP;100nF,10%,50V,X7R,TP,1608	12	SA
....5	C236	2203-005918	C-CER,CHIP;1000nF,10%,6.3V,X7R,TP,1608	2	SNA
....5	C600	2203-006090	C-CER,CHIP;10000nF,10%,6.3V,X5R,TP,2012	1	SA
....5	C102	2203-006158	C-CER,CHIP;100nF,10%,16V,X7R,TP,1005,0.5	87	SA
....5	AD480	2203-006320	C-CER,CHIP;2200nF,10%,16V,X7R,TP,2012	1	SNA
....5	C125	2203-006361	C-CER,CHIP;10000nF,10%,10V,X5R,TP,2012	3	SC
....5	AD480	2203-006698	C-CER,CHIP;1000nF,10%,25V,X7R,TP,1608,0.	8	SA
....5	AD480	2203-006960	C-CER,CHIP;1000nF,10%,50V,X7R,TP,2012	2	SNA
....5	AD480	2203-007176	C-CER,CHIP;10000nF,10%,16V,X5R,TP,2012,1	1	SNA
....5	AD480	2203-007193	C-CER,CHIP;10000nF,10%,6.3V,X7R,TP,2012	3	SA
....5	AD480	2203-007240	C-CER,CHIP;22000nF,20%,6.3V,X5R,TP,1608,	3	SA
....5	AD480	2203-007306	C-CER,CHIP;10000nF,10%,25V,X5R,TP,2012,1	3	SNA
....5	AD480	2203-007423	C-CER,CHIP;10000nF,10%,35V,X7R,TP,3216	12	SA
....5	AD480	2203-007424	C-CER,CHIP;4700nF,10%,50V,X7R,TP,3216	2	SA
....5		2409-001240	C-ORGANIC,SMD;33uF,20%,25V,LR,TP,7343(1.	1	SNA
....5		2703-003747	INDUCTOR-SMD;22uH,20%,6060,0.135ohm,1300	2	SA
....5		2703-003803	INDUCTOR-SMD;4.7uH,20%,6060,0.031ohm,270	1	SA
....5		2703-003862	INDUCTOR-SMD;10uH,20%,6060,0.065ohm,1900	2	SA
....5		2703-003867	INDUCTOR-SMD;22uH,20%,4040,0.29ohm,720mA	1	SA
....5	DR32	3301-000314	BEAD-SMD;120ohm,1608,TP,120ohm/100MHz	10	SNA
....5		3301-001864	BEAD-SMD;100ohm,1608,TP,55ohm/29MHz,145o	14	SA
....5	T0568	3301-002039	BEAD-SMD;26ohm,1608,TP	1	SA
....5		3601-001038	FUSE-SURFACE MOUNT;125V,3A,FAST-ACTING,C	1	SA
....5	CON1	3708-002157	CONNECTOR-FPC/FFC/PIC;80P,0.5mm,SMD-A,AU	2	SNA
....5	HB01A	3711-005601	HEADER-BOARD TO CABLE;BOX,8P,1R,2mm,SMD-	1	SA

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
....5	HB01A	3711-005925	HEADER-BOARD TO CABLE;BOX,51P,1R,0.5mm,S	1	SA
....5		BN13-00058A	IC ASIC;LPF61B0,SQ60PB,285,3.3,0to+70C,P	1	SA
....5		BN41-01882A	PCB MAIN;2012 FHD 60Hz 3D,FR-4,4,1.2T,17	1	SNA
....5		BN68-02775A	LABEL-SMD;ALL MODELS,8.5,21,COMMON	1	SNA
....5		BN97-06777A	ASSY MICOM;120418_J460H60P0E,2012.04.19	1	SNA
....6	IC112	1103-001195	IC-EEPROM;24C64,64Kbit,8Kx8,SOP,5x4mm,2.	1	SA
..3		BN96-21523A	ASSY OPEN CELL;LSJ460HW05-E,8bit,46 INCH	1	SNA
...4		BN81-07433A	A/S-ADHESIVE-A.C.F(CF);ADHESIVE-A.C.F,1-	1	SNA
...4		BN81-07434A	A/S-ADHESIVE-A.C.F(CP);ADHESIVE-A.C.F,1-	1	SNA
...4		BN81-07446A	A/S-ASSY PCB-SOURCE LEFT;ASSY PCB-SOURCE	1	SNA
...4		BN81-07459A	A/S-ASSY PCB-SOURCE RIGHT;ASSY PCB-SOURC	1	SNA
...4		BN81-07465A	A/S-IC DRIVER GATE;IC DRIVER GATE,1-IC D	1	SNA
...4		BN81-07477A	A/S-IC DRIVER SOURCE;IC DRIVER SOURCE,9-	1	SNA
...4		BN81-07485A	A/S-POLARIZER-C/F;POLARIZER-C/F,4-POLARI	1	SNA
...4		BN81-07493A	A/S-POLARIZER-TFT;POLARIZER-TFT,4-POLARI	1	SNA
..3	TC01A	BN96-23643A	ASSY MISC P-CHASSIS TOP;Y12 F-LED, 46" 3	1	SA
...4		BN60-00442A	SPACER-TOP (UD);Full-LED 46",FG200A,L104	2	SNA
...4		BN60-00443A	SPACER-TOP (LR);Full-LED 46",FG200A,L597	2	SNA
...4		BN60-00446A	SPACER-GASKET;Full-LED,FG200A,L25,t0.2,W	6	SNA
...4		BN60-00474B	SPACER-BLOCK;Full-LED 46",PORON0.4t+DSS7	1	SNA
...4		BN63-07556N	COVER-SHEET;T0C,PO,T0.068,W40mm,100M,DAE	1	SNA
...4		BN63-07556X	COVER-SHEET;F-LED 3D VE,PO-SHEET,T0.068,	2	SNA
...4		BN63-09517A	SHEET-THERMAL;GAP PAD,2.5,W 12,L 45,BLAC	6	SNA
...4	AC157	BN64-02113A	CHASSIS-TOP;Y12 F-LED 46(3D),PC+ABS+G/F1	1	SNA
...4		BN68-04449A	LABEL-STICKER;F-LED (3D),W/W,PET,T0.3,3D	1	SNA
1		BN91-09577A	ASSY SHIELD;UN46EH6030FXZA	1	SNA
.2		6001-002756	SCREW-MACHINE;BH,+,M3,L6,ZPC(WHT),SWRCH1	10	SA
.2		BN02-00102B	TAPE FILAMENT;UE7000,#893,0.15,25,50,WHI	0	SNA
.2		BN39-01475H	LEAD CONNECTOR-POWER CABLE;E6K/7K/8K_55"	1	SA
.2	P001A	BN44-00552A	DC VSS-LED TV PD BD;PD46CV1_CSM,PSLF930C	1	SA
.2		BN61-08046F	HOLDER-SIDE, AV;UE6030,40,UO,HIPS,HIPS,B	1	SNA
.2		BN67-00364A	RUBBER;UE32EH5000,RUBBER,10X10,9T,10X10	1	SNA
.2	FL06	BN96-17116X	ASSY CABLE P-FFC;UN46EH5000,FFC,439mm,51	1	SA
.2	SP01A	BN96-21669J	ASSY SPEAKER P;6ohm,4pin,10W,UE6030 55"	1	SA
.2	FB01A	BN96-23838D	ASSY BOARD P-JOG SWITCH & IR;UN46EH6030,	1	SA
1	M0017	BN91-09812A	ASSY CHASSIS;BN91-09522T;UN46EH6030FXZP	1	SNA
.2	M0014	BN94-05993A	ASSY PCB MAIN;UN46EH6030FXZP	1	SA
..3	T0756	AA68-01018A	LABEL-PQS;50mmX,13,WHITE	1	SNA
..3		BN97-06807G	ASSY SMD;UN40EH6030F	1	SNA
...4		0202-001477	SOLDER-CREAM;LST309-M,D20~45um,96.5Sn/3A	3	SNA

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
...4		0403-001785	DIODE-ZENER;NZH5V1B,4.94/5.2V,500mW,SOD-	1	SA
...4		0403-001797	DIODE-ZENER;NZH3V0B,2.85/3.15V,500mW,SOD	1	SNA
...4	D0254	0404-001404	DIODE-SCHOTTKY;BAT721C,40V,200mA,SOT-23,	1	SA
...4	T0139	0406-001200	DIODE-TVS;RCLAMP0504F,6/-V,150W,SC-70	2	SA
...4	T0139	0406-001271	DIODE-TVS;RCLAMP0524P,6/-V,150W,SLP251	1	SNA
...4	SD3	0407-000114	DIODE-SWITCHING;KDS184,80V,100mA,SOT-23,	1	SNA
...4	Q101	0501-000445	TR-SMALL SIGNAL;KTC3875S-Y,NPN,150mW,SOT	8	SC
...4	CEQ2	0505-000110	FET-SILICON;2N7002,N,60V,115mA,7.5ohm,0.	4	SA
...4	Q409	0505-002560	FET-SILICON;AO6415,P,-20V,-3.3A,0.15ohm,	1	SA
...4		1006-001509	IC-DRIVER/RECEIVER;MAX3222ECPWR,TSSOP,20	1	SA
...4	IC112	1103-001310	IC-EEPROM;2Kbit,256x8,SOIC,8Z30,5x4mm,2.	1	SNA
...4		1103-001531	IC-EEPROM;S-24C256CI-J8T1U4,256Kbit,32Kx	1	SA
...4		1105-002161	IC-DDR3 SDRAM;K4B2G1646C-HCH9,1333 DDR3	2	SNA
...4		1201-003333	IC-POWER AMP;NTP-7412S,MLF,48P,7x7mm,DUA	1	SNA
...4		1203-004364	IC-VOL. DETECTOR;RT9818C-42PV,SOT-23,3P,	1	SA
...4		1203-006017	IC-VOL. DETECTOR;RT9824GJ8,TSOT23,8P,2.9	1	SA
...4	T0087	1203-006109	IC-POSI.FIXED REG.;S-1206B33-M3T1G,SOT-2	1	SA
...4	T0087	1203-006130	IC-POSI.FIXED REG.;S-1172B25-U5T1G,SOT-8	1	SA
...4	T0087	1203-006135	IC-POSI.FIXED REG.;AP1117D-33-GZ-13-89,T	1	SA
...4	T0087	1203-006136	IC-POSI.FIXED REG.;AP1117D-18-GZ-13-89,T	1	SA
...4	IC012	1203-006138	IC-POSI.ADJUST REG.;AP1117DGZ-13-89,TO-2	1	SA
...4		1203-006684	IC-DC/DC CONVERTER;TPS54327DDAR,HSOP8,8P	1	SNA
...4		1203-007080	IC-DC/DC CONVERTER;AOZ1051PI,SO-8,8P,4.9	2	SA
...4		1204-003369	IC-DECODER;LFBGA,585P,20.2x20.2mm,PLASTI	1	SA
...4		1205-003834	IC-ETHERNET CONTROLLER;RTL8201E-VC-GRT,Q	1	SA
...4		1205-004447	IC-SWITCH;TPS2051CDBVR,SOT23-5,5P,3x1.65	2	SA
...4		1405-001271	VARISTOR;35V,20Vdc,5A,1.0x0.5x0.6mm,TP,1	17	SA
...4	R105	2007-000138	R-CHIP;100ohm,5%,1/16W,TP,1005	27	SA
...4	AR49	2007-000140	R-CHIP;1Kohm,5%,1/16W,TP,1005	7	SA
...4	AVR73	2007-000142	R-CHIP;2.7Kohm,5%,1/16W,TP,1005	2	SNA
...4	R319	2007-000143	R-CHIP;4.7Kohm,5%,1/16W,TP,1005	64	SA
...4	R104	2007-000148	R-CHIP;10Kohm,5%,1/16W,TP,1005	40	SA
...4	R102	2007-000149	R-CHIP;12Kohm,5%,1/16W,TP,1005	2	SA
...4	MR36	2007-000153	R-CHIP;22Kohm,5%,1/16W,TP,1005	4	SNA
...4	MR13	2007-000157	R-CHIP;47Kohm,5%,1/16W,TP,1005	6	SNA
...4	R123	2007-000159	R-CHIP;56Kohm,5%,1/16W,TP,1005	1	SA
...4	DR39	2007-000162	R-CHIP;100Kohm,5%,1/16W,TP,1005	6	SA
...4	MR16	2007-000168	R-CHIP;470Kohm,5%,1/16W,TP,1005	1	SNA
...4	R509	2007-000170	R-CHIP;1Mohm,5%,1/16W,TP,1005	1	SA
...4	R111	2007-000171	R-CHIP;0ohm,5%,1/16W,TP,1005	4	SA

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
...4	HDR17	2007-000172	R-CHIP;10ohm,5%,1/16W,TP,1005	2	SNA
...4	R338	2007-000173	R-CHIP;22ohm,5%,1/16W,TP,1005	6	SA
...4	MR39	2007-000242	R-CHIP;1.5Kohm,5%,1/16W,TP,1005	1	SNA
...4	VR8	2007-000256	R-CHIP;1.6Kohm,1%,1/10W,TP,1608	1	SA
...4	PR6	2007-000583	R-CHIP;22Kohm,1%,1/10W,TP,1608	1	SA
...4	S0F0522	2007-000691	R-CHIP;3.3Mohm,5%,1/10W,TP,1608	1	SA
...4	R726	2007-000695	R-CHIP;3.3ohm,5%,1/10W,TP,1608	4	SNA
...4	R124	2007-000775	R-CHIP;33Kohm,5%,1/16W,TP,1005	1	SNA
...4	DR37	2007-000932	R-CHIP;470ohm,5%,1/16W,TP,1005	5	SA
...4	S1G0843	2007-001125	R-CHIP;68Kohm,1%,1/10W,TP,1608	1	SA
...4	OTR1	2007-001292	R-CHIP;33ohm,5%,1/16W,TP,1005	8	SA
...4	R16	2007-001313	R-CHIP;330ohm,5%,1/16W,TP,1005	2	SNA
...4	HR10	2007-001320	R-CHIP;1.8Kohm,5%,1/16W,TP,1005	2	SA
...4	R326	2007-001325	R-CHIP;3.3Kohm,5%,1/16W,TP,1005	1	SNA
...4	MR316	2007-002796	R-CHIP;510ohm,5%,1/16W,TP,1005	2	SA
...4		2007-007008	R-CHIP;300ohm,5%,1/16W,TP,1005	1	SNA
...4	DR4	2007-007142	R-CHIP;10Kohm,1%,1/16W,TP,1005	3	SA
...4		2007-007156	R-CHIP;1ohm,5%,1/16W,TP,1005	17	SA
...4		2007-007306	R-CHIP;100ohm,1%,1/16W,TP,1005	1	SNA
...4		2007-007315	R-CHIP;3.9Kohm,1%,1/16W,TP,1005	1	SNA
...4		2007-007317	R-CHIP;2.2Kohm,1%,1/16W,TP,1005	1	SA
...4		2007-007318	R-CHIP;1Kohm,1%,1/16W,TP,1005	17	SA
...4		2007-007463	R-CHIP;1.1Kohm,1%,1/16W,TP,1005	2	SA
...4		2007-007517	R-CHIP;240ohm,1%,1/16W,TP,1005	2	SNA
...4		2007-007538	R-CHIP;56Kohm,1%,1/16W,TP,1005	1	SA
...4		2007-007617	R-CHIP;2.49Kohm,1%,1/10W,TP,1608	1	SA
...4		2007-007671	R-CHIP;11Kohm,1%,1/16W,TP,1005	2	SA
...4		2007-007697	R-CHIP;2.4Kohm,1%,1/16W,TP,1005	1	SNA
...4	MR11	2007-008015	R-CHIP;75ohm,1%,1/16W,TP,1005	3	SA
...4		2007-008117	R-CHIP;2.7Kohm,1%,1/16W,TP,1005	1	SA
...4		2007-008275	R-CHIP;30Kohm,1%,1/16W,TP,1005	2	SNA
...4		2007-008309	R-CHIP;37.4ohm,1%,1/16W,TP,1005	1	SNA
...4		2007-008649	R-CHIP;220ohm,1%,1/16W,TP,1005	1	SNA
...4		2007-008779	R-CHIP;0ohm,1%,1/16W,TP,1005	2	SA
...4		2011-001427	R-NETWORK;0ohm,5%,1/16W,L,CHIP,8P,TP,2.0	4	SA
...4		2011-001449	R-NETWORK;22ohm,5%,1/16W,L,4P,TP,1010	3	SA
...4		2011-001519	R-NETWORK;33OHM,5%,1/16W,L,CHIP,4P,TP,1.	2	SA
...4		2011-001587	R-NETWORK;100ohm,5%,1/16W,L,CHIP-V,4P,TP	2	SA
...4	PC43	2203-000233	C-CER,CHIP;0.1nF,5%,50V,C0G,TP,1005	6	SA
...4	DC54	2203-000278	C-CER,CHIP;0.01nF,0.5pF,50V,C0G,TP,1005	5	SA

Exploded Views and Parts List

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
...4	DC1	2203-000386	C-CER,CHIP;0.015nF,5%,50V,C0G,TP,1005	2	SA
...4	C254	2203-000438	C-CER,CHIP;1nF,10%,50V,X7R,TP,1005	6	SA
...4	C507	2203-000489	C-CER,CHIP;2.2nF,10%,50V,X7R,TP,1005	3	SA
...4	AD480	2203-000530	C-CER,CHIP;2.7nF,10%,50V,X7R,TP,1005,-	1	SNA
...4	V1233	2203-000575	C-CER,CHIP;220nF,10%,25V,X7R,TP,2012	4	SA
...4	MC9	2203-000627	C-CER,CHIP;0.022nF,5%,50V,C0G,TP,1005	1	SNA
...4	AD480	2203-000714	C-CER,CHIP;3.3nF,10%,50V,X7R,TP,1005	8	SA
...4	DC25	2203-000812	C-CER,CHIP;0.033nF,5%,50V,C0G,TP,1005	2	SA
...4	AD480	2203-000995	C-CER,CHIP;0.047nF,5%,50V,C0G,TP,1005	3	SA
...4	AD480	2203-001412	C-CER,CHIP;0.03nF,5%,50V,NP0,TP,1005	5	SNA
...4	AD480	2203-002285	C-CER,CHIP;10nF,10%,50V,X7R,TP,1005	12	SNA
...4	AC2	2203-002711	C-CER,CHIP;100nF,10%,25V,X7R,TP,1608	4	SA
...4	C151	2203-003039	C-CER,CHIP;0.008nF,0.25pF,50V,C0G,TP,100	2	SA
...4	AAC1	2203-005249	C-CER,CHIP;100nF,10%,50V,X7R,TP,1608	12	SA
...4	VC37	2203-006048	C-CER,CHIP;100nF,10%,10V,X7R,TP,1005	112	SA
...4	AD480	2203-006126	C-CER,CHIP;47nF,10%,16V,X7R,TP,1005	1	SNA
...4	JC10	2203-006324	C-CER,CHIP;2200nF,10%,10V,X5R,TP,1608	4	SA
...4	C802	2203-006348	C-CER,CHIP;1000nF,10%,25V,X5R,TP,1608,0.	1	SA
...4	C125	2203-006361	C-CER,CHIP;10000nF,10%,10V,X5R,TP,2012	21	SC
...4	AD480	2203-006427	C-CER,CHIP;4700nF,10%,16V,X5R,TP,2012	2	SA
...4	HE4	2203-006474	C-CER,CHIP;22000nF,20%,6.3V,X5R,TP,2012	12	SA
...4	HDC11	2203-006562	C-CER,CHIP;1000nF,10%,10V,X5R,TP,1005	8	SNA
...4	AD480	2203-006824	C-CER,CHIP;4700nF,10%,10V,X5R,TP,1608,-	1	SNA
...4	AD480	2203-006842	C-CER,CHIP;0.47nF,5%,50V,C0G,TP,1005	3	SNA
...4	C23	2203-006890	C-CER,CHIP;10000nF,20%,6.3V,X5R,TP,1608	33	SNA
...4	AD480	2203-007176	C-CER,CHIP;10000nF,10%,16V,X5R,TP,2012,1	6	SNA
...4	AD480	2203-007513	C-CER,CHIP;10000nF,10%,10V,X5R,TP,1608,0	3	SA
...4		2503-001051	C-NETWORK;100nFx4,20%,16V,2012	1	SA
...4	T0052	2703-000158	INDUCTOR-SMD;1uH,10%,2012,.4ohm,50mA,45,	2	SA
...4		2703-001938	INDUCTOR-SMD;56nH,5%,1005,1.5ohm,200mA,1	2	SA
...4	T0052	2703-003149	INDUCTOR-SMD;2.2uH,20%,5050,0.057ohm,310	3	SA
...4		2703-003930	INDUCTOR-SMD;4.7uH,20%,5050,0.067ohm,230	4	SA
...4	X202	2801-003773	CRYSTAL-SMD;12MHz,30ppm,28-AAN,20pF,50oh	1	SA
...4	X202	2801-004734	CRYSTAL-SMD;25.000000MHz,20ppm,28-AAN,12	1	SA
...4	T0568	3301-002039	BEAD-SMD;26ohm,1608,TP	50	SA
...4		3701-001784	CONNECTOR-HDMI;19P,2ROW,FEMALE,SMD-S,AU	2	SA
...4		3707-001106	CONNECTOR-OPTICAL;STRAIGHT W/L,SPDIF	1	SA
...4	HB01A	3711-005925	HEADER-BOARD TO CABLE;BOX,51P,1R,0.5mm,S	1	SA
...4		3711-007585	CONNECTOR-HEADER;BOX,4P,1R,2.5mm,ANGLE-D	1	SA
...4		3711-007587	CONNECTOR-HEADER;BOX,18P,2R,2mm,ANGLE-DI	1	SA

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
...4	EH01	3711-007742	HEADER-BOARD TO CABLE;BOX,20P,2R,2mm,ANG	1	SA
...4		3722-003225	JACK-USB;4P/1C,Au,BLK,SMD-A(DIP),A	1	SA
...4		3722-003226	JACK-PHONE;7P/1C,SN,BLK	1	SA
...4		3722-003229	JACK-MODULAR;8P/8C W/L,Y,STRAIGHT,N,Au,1	1	SA
...4		3722-003439	JACK-PHONE;4P/1C,SN,BLK	1	SA
...4		3722-003546	JACK-PIN;5P+Screw hole,NI+SN,G,Y/BLU/RED	1	SA
...4	ET01	BN40-00225A	TUNER;DTVD20FVL084A,DTVD20FVL084A,VSBHal	1	SA
...4		BN41-01894A	PCB MAIN;FR-4,4,1.2T,192*141,1	1	SNA
...4		BN68-02775A	LABEL-SMD;ALL MODELS,8.5,21,COMMON	1	SNA
...4		BN97-06820A	ASSY MICOM;T-NVTE5AKUC-1001.3,2012.05.07	1	SNA
....5		1107-002047	IC-NAND FLASH;K9F2G08U0C-S,2Gbit,256Mx8b	1	SNA
....5	T0527	AA68-03540A	LABEL-MICOM;ART PAPE,7X6mm	1	SNA
....5		BN46-00262A	S/W-E-MANUAL;NVATSCE-1003,2012.05.09,ZA,	1	SNA
....5		BN46-00267A	S/W MICOM;T-NVTE5AKUC-1004.0,2012.05.14,	1	SNA
...4		BN97-06824A	ASSY MICOM;T-NVTE5AKUS-1008,2012.05.21	1	SNA
....5		1107-002076	IC-NOR FLASH;W25Q40BVSSIP,4Mbit,SOP,8P,5	1	SNA
..3		BN97-06895A	ASSY DRM-KEY CODE-ASS'Y;COM_005,TV,-,Gen	1	SNA
...4		BN46-00109H	KEY CODE-CERTIFI;MAC,TV/AV,General	1	SNA
..3	T0066	BP62-00017A	HEAT SINK-ES;SP-50L2HX,A6063S,T2.0,26.2,	1	SNA
1		BN92-10898N	ASSY BOX;UE6030,46,LO	1	SNA
.2	T0077	BH68-00329D	LABEL BAR CODE-02;NO CE,NO WT'Y,MPRII,LA	1	SNA
.2		BN69-07935B	BOX-SET;46UE6030-SS,CB,A-01,SW2,YEL,W122	1	SNA
1		BN92-10899D	ASSY P/MATERIAL;UN46EH6030GX	1	SNA
.2	T0524	6902-000958	BAG PE;HDPE/NITRON,T0.015/T0.3,W1300,L80	1	SNA
.2	M040	6922-000013	BAND PP;PP,W18,L2300/L2900,TRP	1	SNA
.2		BH69-00418A	BAG WRAPPING;LDPE,762,1828M,SAMEX FACTOR	1	SNA
.2		BN68-02422B	LABEL-WARNING SHIPPING;ALL MODEL,A/P 100	1	SNA
.2		BN69-06769A	PACKING-INNER PAD;CB,3.0,100,2133.6,LED	1	SNA
.2		BN69-07799A	CUSHION-SET;46UE6030-SS,EPS	1	SNA
.2		BN74-00008D	TAPE-OPP MASKING;OPP,T0.05,W75,L800M,CLR	3	SNA
1	ACCE1	BN92-10902E	ASSY ACCESSORY;UN40EH6030FXZP	1	SNA
.2	ACCE2	BN96-21958R	ASSY ACCESSORY-CABLE;UN40/46/55EH6030FXZ	1	SNA
..3	T0268	3903-000599	CBF-POWER CORD;DT,UL/CSA,LP-11L,125V,5A,	1	SA
..3	T0685	4301-000103	BATTERY-ALKALINE;1.5V,750mAH,LR03,10.5x4	2	SNA
..3		6902-001340	BAG PE;LDPE,T0.05,W250,L350,TRP,RECYCLE	1	SNA
..3	REMO2	AA59-00601A	REMOCON;TM1240,44Key,3V,America,PDP490	1	SA
..3		BN61-05491A	HOLDER-WIRE STAND;UB7000 46inch,NYRON	1	SNA
.2	ACCE4	BN96-21959J	ASSY ACCESSORY-MANUAL;UN40/46/55EH6030FX	1	SNA
..3		6801-002047	CARD INFORMATION;ENG/FRA/SPA/POR,W/P 80g	1	SNA
..3		6902-000476	BAG PE;LDPE,T0.03,W250,L350,TRP,Recycle,	1	SNA

Exploded Views and Parts List

Level	Loc.	Part Code	Description & Specification	Qty.	SA/SNA
..3		AA68-03242L	LEAFLET-08,SAFETY GUIDE;comm,Samsung,Eng	1	SNA
..3	T0527	BN68-00513A	LABEL-E,PASS;ALL MODEL,YUPO(110G),50X15,	1	SNA
..3		BN68-04204B	MANUAL FLYER-02,3D GLASSES GUIDE;SSG-410	1	SNA
..3		BN68-04458C	MANUAL USERS-02;UE6030,SAMSUNG,Spa,MEXIC	1	SNA
..3		BP68-00263E	LEAFLET-03,WARRANTY CARD;comm,Samsung,En	1	SNA
.2	3DGLA	BN96-22902A	ASSY ACCESSORY 3D GLASSES;SSG-4100GB,IN-	1	SA
1		BN92-10903N	ASSY LABEL;UN46EH6030FXZP	1	SNA
.2		BN68-04454B	LABEL-STICKER;UE6R,ZA,PET,T0.05,38,140,E	1	SNA
.2	T0527	BP68-00052B	LABEL-00,RATING;FPTV,PET,T0.05,93,73	1	SNA

www.eletronicaoperal.com.br