



LED TV

Chassis : U8MA

Model : UN40H6203AG
UN46H6203AG

SERVICE Manual

LED TV



UN**H6203AG

Contents

1. Precautions
2. Product specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. Wiring Diagram

Contents

1. Precautions	1-1
1-1. Safety Precautions	1-1
1-1-1. Warnings.....	1-1
1-1-2. Servicing the LED TV	1-1
1-1-3. Fire and Shock Hazard	1-1
1-1-4. Product Safety Notices	1-2
1-2. Servicing Precautions.....	1-3
1-2-1. General Servicing Precautions	1-3
1-3. Static Electricity Precautions	1-4
1-4. Installation Precautions	1-5
2. Product Specifications.....	2-1
2-1. Product information	2-1
2-2. Product specification	2-2
2-2-1. Detailed Specifications	2-2
2-2-2. Feature & Specifications.....	2-7
2-3. Accessories	2-8
2-4. Viewing the Functions	2-9
3. Disassembly and Reassembly	3-1
3-1. Disassembly and Reassembly	3-1
4. Troubleshooting	4-1
4-1. Troubleshooting.....	4-1
4-1-1. Previous Check	4-1
4-1-2. Simple flow chart of malfunction.....	4-3
4-2. How to Check Fault Symptom.....	4-4
4-2-1. NO Power	4-4
4-3. Factory Mode Adjustments	4-6
4-3-1. Detail Factory Option	4-6
4-3-2. Entering Factory Mode	4-7
4-3-3. Factory Data	4-8
4-4. White Balance	4-21
4-4-1. Calibration	4-21
4-4-2. Service Adjustment.....	4-21
4-4-3. Adjustment.....	4-22
4-5. RS-232C.....	4-23
4-6. AV Control Tab	4-24
4-7. Software Upgrade.....	4-30
4-7-1. How to Check the Software Version	4-30
4-7-2. How to Upgrade Software.....	4-31

5. Wiring Diagram5-1
5-1. Wiring Diagram.....5-1
5-2. Connector5-2
5-3. Connector Functions5-5



**This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.**

**© 2014 Samsung Electronics Co.,Ltd.
All rights reserved.
Printed in Korea**

1. Precautions

1-1. Safety Precautions

Follow these safety, servicing and ESD precautions to prevent damage and to protect against potential hazards such as electrical shock.

1-1-1. Warnings



For continued safety, do not attempt to modify the circuit board.
Disconnect the AC power and DC power jack before servicing.


1-1-2. Servicing the LED TV

1. When servicing the LED TV, Disconnect the AC line cord from the AC outlet.
2. It is essential that service technicians have an accurate voltage meter available at all times. Check the calibration of this meter periodically.

1-1-3. Fire and Shock Hazard

Before returning the monitor to the user, perform the following safety checks:

1. Inspect each lead dress to make certain that the leads are not pinched or that hardware is not lodged between the chassis and other metal parts in the monitor.
2. Inspect all protective devices such as nonmetallic control knobs, insulating materials, cabinet backs, adjustment and compartment covers or shields, isolation resistor/capacitor networks, mechanical insulators, etc.
3. Leakage Current Hot Check:




Do not use an isolation transformer during this test.

Use a leakage current tester or a metering system that complies with American National Standards Institute (ANSI C101.1, Leakage Current for Appliances), and Underwriters Laboratories (UL Publication UL1410, 59.7).

4. With the unit completely reassembled, plug the AC line cord directly into a 120V AC outlet. With the unit's AC switch first in the ON position and then OFF, measure the current between a known earth ground (metal water pipe, conduit, etc.) and all exposed metal parts, including: metal cabinets, screwheads and control shafts.
The current measured should not exceed 0.5 milliamp.
Reverse the power-plug prongs in the AC outlet and repeat the test.

1-1-4. Product Safety Notices

Some electrical and mechanical parts have special safetyrelated characteristics which are often not evident from visual inspection. The protection they give may not be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by  on schematics and parts lists. A substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire and/or other hazards. Product safety is under review continuously and new instructions are issued whenever appropriate.

1-2. Servicing Precautions



An electrolytic capacitor installed with the wrong polarity might explode.



Before servicing units covered by this service manual, read and follow the Safety Precautions section of this manual.



If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions, always follow the safety precautions.

1-2-1. General Servicing Precautions

1. Always unplug the unit's AC power cord from the AC power source and disconnect the DC Power Jack before attempting to: (a) remove or reinstall any component or assembly, (b) disconnect PCB plugs or connectors, (c) connect a test component in parallel with an electrolytic capacitor.
2. Some components are raised above the printed circuit board for safety. An insulation tube or tape is sometimes used. The internal wiring is sometimes clamped to prevent contact with thermally hot components. Reinstall all such elements to their original position.
3. After servicing, always check that the screws, components and wiring have been correctly reinstalled. Make sure that the area around the serviced part has not been damaged.
4. Check the insulation between the blades of the AC plug and accessible conductive parts (examples: metal panels, input terminals and earphone jacks).
5. Insulation Checking Procedure: Disconnect the power cord from the AC source and turn the power switch ON. Connect an insulation resistance meter (500 V) to the blades of the AC plug. The insulation resistance between each blade of the AC plug and accessible conductive parts (see above) should be greater than 1 megohm.
6. Always connect a test instrument's ground lead to the instrument chassis ground before connecting the positive lead; always remove the instrument's ground lead last.

1-3. Static Electricity Precautions

Some semiconductor (solid state) devices can be easily damaged by static electricity. Such components are commonly called Electrostatically Sensitive Devices (ESD). Examples of typical ESD are integrated circuits and some field-effect transistors. The following techniques will reduce the incidence of component damage caused by static electricity.

1. Immediately before handling any semiconductor components or assemblies, drain the electrostatic charge from your body by touching a known earth ground. Alternatively, wear a discharging wrist-strap device. To avoid a shock hazard, be sure to remove the wrist strap before applying power to the monitor.
2. After removing an ESD-equipped assembly, place it on a conductive surface such as aluminum foil to prevent accumulation of an electrostatic charge.
3. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ESDs.
4. Use only a grounded-tip soldering iron to solder or desolder ESDs.
5. Use only an anti-static solder removal device. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ESDs.
6. Do not remove a replacement ESD from its protective package until you are ready to install it. Most replacement ESDs are packaged with leads that are electrically shorted together by conductive foam, aluminum foil or other conductive materials.
7. Immediately before removing the protective material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.



Be sure no power is applied to the chassis or circuit and observe all other safety precautions.

8. Minimize body motions when handling unpackaged replacement ESDs. Motions such as brushing clothes together, or lifting your foot from a carpeted floor can generate enough static electricity to damage an ESD.

1-4. Installation Precautions



1. For safety reasons, more than a people are required for carrying the product.
2. Keep the power cord away from any heat emitting devices, as a melted covering may cause fire or electric shock.
3. Do not place the product in areas with poor ventilation such as a bookshelf or closet. The increased internal temperature may cause fire.
4. Bend the external antenna cable when connecting it to the product. This is a measure to protect it from being exposed to moisture. Otherwise, it may cause a fire or electric shock.
5. Make sure to turn the power off and unplug the power cord from the outlet before repositioning the product. Also check the antenna cable or the external connectors if they are fully unplugged. Damage to the cord may cause fire or electric shock.
6. Keep the antenna far away from any high-voltage cables and install it firmly. Contact with the highvoltage cable or the antenna falling over may cause fire or electric shock.
7. When installing the product, leave enough space (0.4m) between the product and the wall for ventilation purposes. A rise in temperature within the product may cause fire.
8. If an equipment is provided with a replaceable battery, and if replacement by an incorrect type could result in an explosion (for example, with some lithium batteries), the following applies:

**CAUTION**

- Risk of explosion if battery is replaced by an incorrect type dispose of used batteries according to the instructions.
- Do not dispose of batteries in a fire.
- Do not short circuit, disassemble or overheat the batteries.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Do not be exposed to excessive heat such as sunshine, fire or the like.

2. Product Specifications

2-1. Product information

Model	UN**H6203AG		
Front View	 <p>* W : Width H : High D : Depth</p>		
Detail View			
Front Color	Black		
Dimensions (W x H x D)	40"	Body	927.5 X 548.0 X 93.2 mm
		With stand	927.5 X 607.2 X 227.6 mm
	46"	Body	1060.0 X 622.5 X 96.3 mm
		With stand	1060.0 X 681.8 X 227.6 mm
Weight	40"	Body	8.9 kg
		With stand	10.9 kg
	46"	Body	11.3 kg
		With stand	13.3 kg
Panel Type	Anti Glare		
Internal Memory	4GB		
DDR	768MB (512+256)		
Feature	2D(But, 3D support only latin america models)/Smart Hub/DLNA/Full browsing		

2-2. Product specification

2-2-1. Detailed Specifications


NOTE

Design and specifications are subject to change without prior notice.

Item		UN**H6203AGXPR
General Information	Product	LED
	Series	6
	Country	PARAGUAY
Display	Inch	40" / 46"
	Resolution	1,920 x 1,080
	Ultra Clear Panel	N/A
Video	Picture Engine	HyperReal Engine
	Clear Motion Rate	240
	Dynamic Contrast Ratio	Mega Contrast
	Micro Dimming	No
	Precision Black (Local Dimming)	N/A
	Wide Color Enhancer (Plus)	Yes
	Wide Color Gamut	N/A
	Color Accuracy	N/A
	Auto Depth Enhancer	N/A
	Film Mode	Yes
	Natural Mode Support	Yes
Audio	Dolby MS10 / MS110	Dolby MS10
	DTS Studio Sound / DNSe+	DTS Studio Sound
	DTS Premium Sound / DTS Premium Sound 5.1	DTS Premium Sound 5.1
	3D Sound	Yes
	Auto Volume Leveler	Yes
	Sound Output (RMS)	10W x 2
	Speaker Type	Down Firing + Full Range
	Woofer	N/A
Smart TV	Smart Hub	Yes
	Samsung SMART TV	Yes
	On TV	No
	Movies & TV Shows	No
	Multimedia	No
	Apps	Yes
	News On	No
	Game	No

Item		UN**H6203AGXPR
Smart TV	My Space	No
	Social	N/A
	Fitness	No
	Kids	No
	Multi-Screen (Dual / Quad Screen)	No
	Skype™ on Samsung TV	N/A
	Web Browser	Yes
	Search	Yes
Smart Interaction	Voice Interaction	No
	Voice Control	No
	Camera Built-in	No
	Face recognition	No
	Motion control	No
Smart Convergence	Contents Streaming	Yes
	Screen Mirroring	Yes
	Samsung SMART View	No
	Smart Home	No
	Wake On LAN	No
	WiDi	N/A
Tuner/Broadcasting	DTV Tuner	ISDB-T
	Analog Tuner	Yes (Trinorma)
	MHP / MHEG / HbbTV / ACAP / GINGA / OHTV	GINGA (UY)
Connectivity	HDMI	2
	USB	2
	Component In (Y/Pb/Pr)	1
	Composite In (AV)	1 (Common Use for Component Y)
	Ethernet (LAN)	Yes
	Headphone	No
	Audio Out (Mini Jack)	Yes
	Digital Audio Out (Optical)	1
	PC In (D-sub)	N/A
	PC/DVI Audio In (Mini Jack)	N/A
	RF In (Terrestrial / Cable input)	1/1/0
	Ex-Link (RS-232C)	No
	IR Out	No
	CI Slot	No
	Scart	No
	MHL CE 3.0	No

2. Product specifications

Item		UN**H6203AGXPR
Connectivity	One Connect (Jack)	No
	WiFi Direct	Yes
	MHL	No
	Dongle Ready (3G / LTE)	N/A
	HDMI 1.4 3D Auto Setting	No
	HDMI 1.4 A/Return Ch. Support	No
	InstaPort S (HDMI quick switch)	No
	Wireless LAN Adapter Support	No
	Wireless LAN Built-in	Yes
	Anynet+ (HDMI-CEC)	N/A
Design	Design	17.9mm
	Bezel Type	NNB
	Slim Type	Normal
	Front Color	Black
	Light Effect (Deco)	No
	Stand Type	Square
	Swivel (Left/Right)	No
	Camera Type	N/A
Additional Feature	Samsung 3D	Yes
	3D Converter	Yes
	Instant On	N/A
	N-KIT	N/A
	Quad Core+	N/A
	Accessibility	Yes(Zoom)
	Digital Clean View	Yes
	Auto Channel Search	Yes
	Auto Power Off	Yes
	Clock&On/Off Timer	Yes
	Sleep Timer	Yes
	BD Wise Plus	Yes
	Caption (Subtitle)	Yes
	ConnectShare™ (USB 2.0)	Movie
	AC/DC TV	N/A
	Sports Mode	Basic
	Screen Capture	N/A
	Sound Capture	N/A
	Embedded POP	Yes
	EPG	Yes

Item		UN**H6203AGXPR
Additional Feature	Extended PVR	N/A
	Game Mode	Yes
	History	N/A
	Multiroom Compatible	N/A
	OSD Language	Local Languages
	Picture-In-Picture	Yes
	USB HID Support	Yes
	Smart Evolution Support	N/A
	TV SoundConnect	N/A
	Teletext (TTXT)	No
	Time Shift	N/A
	Analog Clean View	No
	Triple Protector	N/A
	GUI	Golden Bridge
Eco Feature	Eco Mark	N/A
	Eco Label	No
	Eco Sensor	Yes
	Energy Efficiency Class	N/A
	Mercury Content	0.0mg
	Lead Presence	Yes
Accessory	3D Active Glasses (Included)	Yes
	Remote Controller Model	TM1250A
	Batteries (for Remote Control)	Yes
	Samsung Smart Touch Control (Included)	No
	Electric Stand Support	N/A
	Electric Wall Mount Support	N/A
	Ultra Slim Wall Mount Supported	No
	Mini Wall Mount Supported	Yes
	Vesa Wall Mount Supported	Yes
	Floor Stand Support	No
	TV Camera (Included)	No
	IR Extender Cable (Included)	No
	Network Speaker (Included)	No
	Wireless Keyboard (Included)	No
	Wireless LAN Adaptor (Included)	No
	User Manual	Yes
	E-Manual	Yes
	ANT-Cable	No

2. Product specifications

Item		UN**H6203AGXPR
Accessory	Power Cable	Yes
	Slim Gender Cable	No

2-2-2. Feature & Specifications


■ Feature

- Digital-TV, RF, 2-HDMI, 1-Component, 1-A/V, 2-USB2.0, LAN, WiFi
- PIP
- CMR 240
- Dolby Digital Plus Pulse, DTS Premium Sound 5.1, DTS Studio Sound

■ Specifications


Model	UN**H6203AG	
Item	Description	
Screen Size (Diagonal)	40 inch	46 inch
LCD Panel	FHD 120Hz	
Scanning Frequency	Horizontal : 31 kHz ~ 80 kHz Vertical : 56 Hz ~ 75 Hz	
Display Resolution	1920 X 1080	
Input Signal	Analog 0.7 Vp-p ± 5% positive at 75Ω, internally terminated	
Input Sync Signal	H/V Separate, TTL, P. or N.	
Maximum Pixel Clock Rate	138 MHz	
AC Power Voltage & Frequency	AC 110-120V 60Hz	
Environmental Considerations	Operating Temperature : 50°F ~ 104°F (10°C ~ 40°C) Operating Humidity : 10% ~ 80%, non-condensing Storage Temperature : -4°F ~ 113°F (-20°C ~ 45°C) Storage Humidity : 5% ~ 95%, non-condensing	
Sound (Output)	10W X 2	
Note : 2D(But, 3D support only latin america models)/Smart Hub/DLNA/Full browsing		

2-3. Accessories

 **NOTE**


- The items' colors and shapes may vary depending on the model.
- Cables not included in the package contents can be purchased separately.
- The part code for some accessories may differ depending on your region.

Product	Code. No	Product	Code. No
• Remote Control	BN59-01178K	• Samsung 3D Active Glasses	BN96-31824A
• Batteries (AAA x 2)	4301-000103	• User Manual	BN68-06348B
• Power Cord	3903-000851		

Image	Product	Code. No
	• Holder-Wire stand	BN61-08370A

2-4. Viewing the Functions

■ The Remote Control



3. Disassembly and Reassembly

This section of the service manual describes the disassembly and reassembly procedures for the LED TV.



This LED TV contains electrostatically sensitive devices. Use caution when handling these components.

3-1. Disassembly and Reassembly














- 1. Disconnect the LED TV from the power source before disassembly.
- 2. Follow these directions carefully; never use metal instruments to pry apart the cabinet.
- 3. If there is no additional coment, it is same for all inches.

■ 40" / 46"

Description	Picture Description	Screws
1 Remove screws from the Stand.		 6003-001782
Remove stand.		

3. Disassembly and Reassemble

Description	Picture Description	Screws
<p>2 Remove the screws of rear-cover. (In this step, Two types of screws are used.)</p> <ul style="list-style-type: none"> • 40" : 11EA / 4EA • 46" : 14EA / 6EA 		<p>Torque : 9~11Kgf.cm.</p>  <p>6003-001782</p>
<p>3 Remove the rear-cover.</p>		<p>Torque : 7~8Kgf.cm.</p>  <p>6003-002755</p>
<p>4 Remove 14 screws of main board and IP board and Panel.</p>		<p>Torque : 7~8Kgf.cm</p>  <p>6001-003016</p>




Description	Picture Description	Screws
5 Remove the speakers and power cables.		
		
6 Remove the LVDS cable and Panel drive cable.		
		
7 Completed disassembly. • Panel		




NOTE

Reassembly procedures are in the reverse order of disassembly procedures.

■ Jog function

Description	Picture Description
1 Check the 2 locking holders.	
2 press both holders.	
3 remove the function assy.	

 **NOTE**

Reassembly procedures are in the reverse order of disassembly procedures.

When you want to ignore the funtion key actions

Option

Control

Debug

SVC





ADC/WB

Advanced







Config Option

0 : New Function (Naviagtion) Key → Default
1 : Old Function (Touch) Key
2 : Do not work Function key

■ PTC(Plastic Top Chassis)


Description	Picture Description
1 Place monitor face up on cushioned table.	
2 remove the T-CON Cover.	 
3 first spread the PTC upper.	

3. Disassembly and Reassemble

Description	Picture Description
<div>4</div> <div>Spread the both sides of PTC upper (marked "▽") by use the tool.</div> <div><div><div>!</div><div>CAUTION</div></div><div>Do not scratch on both side by use tool. Gate Cof will be damaged.</div></div> <div></div>	<div><div>OK</div></div> <div><div>NG</div></div>
<div>5</div> <div>Apart left and right sides of PTC.</div>	
<div>6</div> <div>Raise up the PTC bottom.</div>	
<div>7</div> <div>Disassembly is complete.</div>	





 **NOTE**


Reassembly procedures are in the reverse order of disassembly procedures.

4. Troubleshooting

4-1. Troubleshooting

4-1-1. Previous Check

1. Check the various cable connections first.
 - Check to see if there is a burnt or damaged cable.
 - Check to see if there is a disconnected or loose cable connection.
 - Check to see if the cables are connected according to the connection diagram.
2. Check the power input to the Main Board.



3. How to distinguish if the problem is caused by **Main Board** or **T CON**

- No Video

If the problem is No Video but BLU is on and Indication LED is blinking repeatedly and faster than normal booting, replace the T-CON board.

- Distorted Picture

Check the inner patterns.

- For All mode

NT14M	FRC Post	Picture	Problem
OK	OK	NG	Main Board or Signal Source
NG	OK	NG	Main Board
NG	NG	NG	Main Board or LVDS cable or T CON or Panel

- Only for HDMI mode (additional check)

HDMI	Picture	Problem
OK	NG	There is no problems after HDMI IC check HDMI source or HDMI jack.
NG	NG	There is no problems before HDMI IC check X12 pattern or LVDS cable or T CON

■ How to check inner pattern?

1. Enter the service mode → Choose 'SVC' → Check the 'internal pattern.'

2. Enter 'Service Mode.'

- If you do not have Factory remote control



- If you have Factory remote control




3. Choose 'SVC → Test pattern'.



4. Check inner patterns.

4-1-2. Simple flow chart of malfunction



4-2. How to Check Fault Symptom


4-2-1. NO Power


Note

Refer to the next page to check the location such a CN201 or IC201 SVC Manual mentioned.

Symptom	<ul style="list-style-type: none"> The LEDs on The front panel do not work when connecting The power cord. The SMPS relay does not work when connecting The power cord. The units appears to be dead.
Major checkpoints	<p>The IP relay or the LEDs on the front panel does not work when connecting the power cord if the cables are improperly connected or the Main Board or SMPS is not functioning. In this case, check the following:</p> <ul style="list-style-type: none"> Check the internal cable connection status inside the unit. Check the fuses of each part. Check the output voltage of SMPS. Replace the Main Board.
Diagnostics	<pre> graph TD Q1[Power indicator LED is on?] -- No --> A1[Check the power cord connection.] Q1 -- Yes --> Q2[Check the backlight on, when 18 PIN cable unconnected ?] Q2 -- No --> A2[Change 18p cable. Change Main Power Ass'y.] Q2 -- Yes --> Q3[Check 'Power input of Main Ass'y' ? - BD206/201/213 : A13V] Q3 -- No --> A2 Q3 -- Yes --> Q4[Check 'Power IC output of Main Ass'y' ? - IC206 : A3.3V - IC201 : B5V - IC208 : B3.3V - ic204 : DDR_B1.5V] Q4 -- No --> A3[Change the Main Ass'y.] Q4 -- Yes --> Q5[Check Input power of 'T CON Board' ? - F1(T CON) : B13V] Q5 -- No --> A4[Reconnect or Change. the LVDS cable.] Q5 -- Yes --> Q6[Check Power of 'T CON Board'. - BD1(T CON) : Panel_12V - B1.1V(T CON-TP) : FT1_1.1V_PW] Q6 -- No --> A5[Change the T CON Board.] Q6 -- Yes --> A6[Please, Contact tech support.] </pre>
Caution	Make sure to disconnect the power before working on the IP Board.

■ Location of Parts



4-3. Factory Mode Adjustments

4-3-1. Detail Factory Option



NOTE

If you replace the main board with new one, please change the factory option as well.
The options you must change are "**Type**".

■ UN**H6203AGXPR

Inches		40"	46"
PANEL	Vendor	SDC	SDC
	Code	BN95-01160A	BN95-01161A
	Spec.	CY-DF400CSLV1V	CY-DF460CSLV1V
SMPS BOARD	Vendor	SEM	SEM
	Code	BN44-00765A	BN44-00766A
	Spec.	L40HV1_ESM	L46HV1_ESM
MAIN BOARD	Chassis Ass'y	BN91-13241A	BN91-13241F
	PBA Ass'y	BN94-07765Q	BN94-07765U
Byte	Item		
0	Factory Reset	-	-
1	Type	40A1AF0D	46A1AF0D
2	Local set	PAR_DTV	PAR_DTV
3	SW Model	H6203	H6203
4	BOM Model	6203	6203
5	Tuner	ISDB-T	ISDB-T
6	Ch table	NONE	NONE

4-3-2. Entering Factory Mode

To enter 'Service Mode' Press the remote -control keys in this sequence :

- If you do not have Factory remote control



- If you have Factory remote control



- Buttons operations within Service Mode

Menu	Full Menu Display / Move to Parent Menu
Direction Keys ▲/▼	Item Selection by Moving the Cursor
Direction Keys ◀/▶	Data Increase / Decrease for the Selected Item
Source	Cycles through the active input source that are connected to the unit

HOW to enter the Advanced menu (Picture)

- Cursor move to 'Advanced'. →
- Push the '0' button 4 times. →
- You can see the 'Picture' menu.

- If you don't have Factory remote control, can't control some menus. (Expert, Advanced menu)

Option	T-NT14MAKUC-xxxx
Control	T-NT14MAKUCSS-xxxx
Debug	BT Version :*****
SVC	E-Manual : NMATSCH-1.****
ADC/WB	Blaster Version : 258401-258403-300001
Advanced	EDID SUCCESS
	CALIB : AV/COMP/PC/HDMI/
	Option : 50R1AF0D,US,6203,NONE (Vary by inches)
	DTP-SDAL-NT14M-MAIN-****.****
	RFS : "NT14M *****" K/2 2014-0*_*
	KERNEL : 107.1272,/ Onboot : 00**
	DTP-DTVTD-****
	Backend[FOX-FT2] Panel[120Hz]
	TCON Version : ****
	Model : UN**H6203
	Wired MAC SUCCESS
	Wireless MAC SUCCESS
	WIFI :ATH6KL (5.0.0.99_****)
	C/Nf/W/M/D/HO PO AO /S/ N/
	Factory Data Ver : 191 /EERC Ver :77
	Smart control : ****
	DTP-BP-HAL-4718
	DTP-BP-HW- 4718
	DTP-BP-APP-4718-02
	POP-FLA-14-HD_SMART-**
	Date of purchase : mm/dd/yyyy

4-3-3. Factory Data

■ Option

Factory Menu Name	Data	Range
Factory Reset	-	
Type	40A1AF0D 46A1AF0D	
Local Set	PAR_DTV	
SW Model	H6203	
BOM Model	6203	
TUNER	ISDB-T	
Ch Table	NONE	
MRT Option		
Front Color	U-S-C-53	
Lvds Format	JEIDA	
Language_Arabic	US	
Region	USA	
PnP Language	ENG_US	
WIFI REGION	S	
OTN Support	ON	
OTA Support	OFF	
MediaPlay DLNA	...	
TTX	OFF	
China HD	OFF	
NT Conversion	OFF	
Num of DTV DECODER	1	
Num of AV	1	
Num of COMP	1	
Num of HDMI	2	
Num of SCART	0	
Num of USB Port	2	
Num of USB 3.0	0	
Num of RVU	0	
Num of Display	2	
Num of IPTV	0	
Num of RUI	0	
Num of PVR RECORD	0	
TOOLS Support	40	
LNA Support	OFF	

Factory Menu Name	Data	Range
24Px4 Support	OFF	
BD Wise Support	OFF(H6203 ON)	
Data Service Support	OFF	
JAVA Data Service Support	OFF	
PVR Support	OFF	
CI Support	OFF	
LEDMotionPlus Support	ON	
Natural Mode Support	ON	
Relax Mode Support	OFF	
HDMI/DVI SEL	2	
Select LED/PDP	LCD	
Wall Mount	OFF	
HV Flip	HV Filp	
FRC HV Flip	0	
Light Effect	OFF	
e-Pop Default	ON	
CAMERA Support	OFF	
NETWORK Support	Int-Wifi	
EcoSensor Support	ON	
3D Support	OFF	
BT Support	OFF	
BT ADDRESS	Not support	
HP LINE	LineOut	
Smart Control Support	OFF	
Motion Recog	OFF	
Voice Recog	OFF	
Virtual Remocon color	1	
Local Dimming Panel	OFF	
Wifi Vendor	QCA	
Engineer Option		
Type Of PANEL KEY	None	
5 Way Function Key	R_BACK	
Contents Bar	OFF	
Cable Modulation	QAM	
Standby led on/off	OFF	
Recognition Support	OFF	
IF AGC	0	

4. Troubleshooting

Factory Menu Name	Data	Range
D AGC	0	
PH BW	0	
FQ BW	0	
PH RATE	0	
PD EN	0	
PEQ Inx	0	
WF Scale		
WF Type	0	
Num of Network Stream	1	
DP V Size	0	
Backend Device		
BT_AUDIO_ON_OFF	OFF	
Config_AV_PATH		
USING_PSI_UPDATE		
ECO Stanby	OFF	
Fast Logo Delay	0	
Num of PANEL KEY		
Panel Detail	0	
Panel Init Time	250	
Tcon Init Time	460	
WRITE MAC Address		

■ Control

Factory Menu Name	Data	Range
EDID		
EDID ON/OFF	OFF	
EDID WRITE ALL	...	
EDID WRITE PC	...	
EDID WRITE HDMI	...	
EDID WRITE HDMI1	...	
EDID WRITE HDMI2	...	
EDID WRITE HDMI3	...	
EDID WRITE HDMI4	...	
EDID Ver	...	
EDID Port		
EDID WRITE DVI	...	
Sub Option		

Factory Menu Name	Data	Range
RS-232 Jack	UART	Debug/UART
Serial Log On/Off	OFF	ON/OFF
Watchdog	OFF	
FRC Monitoring	OFF	
Checksum	0x0000	
Fast Boot in Production	ON	
UART ENABLE	OFF	
Eeprom Reset		
EER Reset	0	
NVR All Clear	OFF	
ECO IC TYPE	MC8121	
Info Link Server Type	development	
Info Link Country	None	
TTX Group	...	
Visual Test	...	
MediaPlay DB	...	
OPTION_SWU		
OPTION_NUM		
RF Remocon Support	OFF	
CCD mode	...	
DPMS Support	OFF	
Num of IPTV CIP	0	
Num of CI	0	
Num of HYBRID TV	0	
T-CON Device		
BOARD CONTROL	OFF	
RM		
PSA		
LMK threshold	4	
Low threshold	10	
High threshold	15	
CSB	ON	
CLB	ON	
EEPG Enable	0	
Last Screen	OFF	
App Resume	OFF	
BP PMS Reset	1	

4. Troubleshooting

Factory Menu Name	Data	Range
F Anet Thread	2	
ACM_MC	OFF	
Support MiniBrowser	ON	
HotkeyList	Basic_Smart	
UNIQUE TRIPLET	ON	
PDP Option		
Pixel Shift Test	OFF	
Logic SW		
Panel Temperature		
LOGIC Waveform Day		
Logic Check Sum		
MRT		
SAPC Timer		
APC Speed		
Hotel Option		
Hospitality Mode	OFF	
Power On		
MyChannel		
Menu OSD		
Operation		
Music Mode		
External Source		
Eco Solution		
Cloning		
Shop Option		
Shop Mode	OFF	
Exhibition Mode	OFF	
3D Cube	OFF	
Asia Option		
Unbalance		
AF Level adjust		
TX Power Level		
Mono Last Memory		
H Shaking		
SOUND		
Carrier_Mute	ON	
High Devi	OFF	

Factory Menu Name	Data	Range
Speaker Delay Normal	10	
SPDIF PCM Gain	-9 dB	
FM M Prescale	48	
FM Prescale	0x00h	
AM Prescale	0x32h	
NICAM Prescale	0x48h	
BTSC Mono Prescale	15	
BTSC stereo Prescale	29	
BTSC SAP Prescale	29	
A2Ident High Thld	36	
A2Ident Low Thld	9	
Pilot Level High Thld	0x0Fh	
Pilot Level Low Thld	0x08h	
Carrier2 Amp High Thld	4	
Carrier2 Amp Low Thld	3	
Carrier2 SNR High THR	16	
Carrier2 SNR Low THR	80	
Sig Error On	35	
Sig Error Off	41	
Amp Model	TAS5745	
Amp Volume	0xc9h	
Amp Scale	0x35h	
Amp Check Sum	0x00480W60	
Woofer Type	0	
Woofer Volume	0xcbh	
Woofer Scale	0x8ah	
Woofer Check Sum	NONE	
Woofer Local EQ Checksum	0	
Speaker EQ	ON	
PEQ Test	Ready	
Lacal Speaker EQ	0	
Local EQ Checksum	0	
SRS Tuning Parm	0	
Subwoofer Support	0	
India Sound	OFF	
AudioDock BT delay	50	
Wall Filter Type	0	

4. Troubleshooting

Factory Menu Name	Data	Range
Bottom CheckSum	0	
Bottom Local Checksum	0	
Lipsync Inx	2	
Lipsync checkSum	NG	
Lipsync USB Test	Ready	
Lipsync BT Checksum	NG	

■ Debug

Factory Menu Name	Data	Range
Spread Spectrum		
LVDS Spread	ON	
LVDS Period	20K	20K/30K/40K
LVDS Amplitude	1.5	0.5/1.0/1.5/2.0/2.5/3.0
DDR Spread	OFF	
DDR Period	20K	20K/30K/40K
DDR Amplitude	1.5	0.5/1.0/1.5/2.0/2.5/3.0
HD SSC ON/Off	OFF	
HD SSC Value	1	
LVDS SSC ON/OFF	OFF	
LVDS SSC Value	0	
DDR SSC ON/OFF	OFF	
DDR SSC Value	1	
FRC Vx1 SSC ON/OFF	OFF	
FRC LVDS SSC ON/OFF	OFF	
FRC LVDS SSC MRR	10	
FRC LVDS SSC MFR	1	
FRC Vx1 SSC Period	0	
FRC Vx1 SSC Modulation	0	
FRC DDR SSC ON/OFF	ON	
FRC DDR SSC MRR	15	
FRC DDR SSC MFR	1	
FRC DDR SSC Period	0	
FRC DDR SSC Modulation	0	
DDR Margin		
A CTRL_OFFSET_0_3	0	
A CTRL_OFFSET_D	0	
B CTRL_OFFSET_0_3	0	

Factory Menu Name	Data	Range
B CTRL_OFFSET_D	0	
MICOM POWER OFF	OFF	
RF Mute Time	6ms	
CI +1.3	OFF	
FRC		
Tuner Margin	10	
MPEG Margin	100	
H.264 Margin	100	
CAM Wait Time		
TS Clock delay	0	
TCON_TEMP_READ	0	
TEMP LAST	60	
DCC VERSION	0x3447	
DCC CHK SEL	0	
DCC CHECK LOCAL	0	
DCC CHECK TOTAL	0	
MultiACC Checksum	0	
IIC Bus Stop	OFF	
Tuner Status		
Cert Option	SHOW	
RM_BIST_DTV	0	
RM_BIST_ATV	0	
Voice Debug	OFF	

■ SVC

Factory Menu Name	Data	Range
Self Test(for HW)		
Loop Back		
CPU		
DDR		
FLASH		
EEPROM		
HDMI Switch IC		
HDMI Switch IC		
USB HUB IC		
WIFI		
LVDS		

4. Troubleshooting

Factory Menu Name	Data	Range
T-CON/FRC		
PCB Test		
MOIP		
App Self Test		
Device Self Test		
EcoSensor		
BT		
EXT Sound Inspection		
Woofer Sound Inspection		
ATV CH Inspection		
DTV CH Inspection		
Satellite CH Inspection		
UHD OSD TEST		
Aging Line Test		
Tweeter Sound Inspection		
Info		
SVC Info		
LOG(View Log)		
ER Count		
Panel Display Time		
Factory Entry Number		
Factory Execution History		
Factory Reset History		
Upgrade		
T-CON Usb Download		
T-CON CheckSum		
Logic Usb D/L		
SUBMICOM UPGRADE		
BT UPGRADE		
BT FREPAIRING		
Function Upgrade		
FRC3D FW UPGRADE		
FRC3D LD UPGRADE		
Camera Upgade		
Mic Upgrade		
CPLD USB Download		
JP MICOM UPGRADE		

Factory Menu Name	Data	Range
DP MICOM UPGRADE		
Jump UPGRADE		
IR Blaster Upgrade		
IR Blaster delay time		
CPLD Download		
LDC PROFILE UPGRADE		
Pic Data USB Update		
Audio Data USB Update		
Eco Data USB Upate		
SC ADK Upgrade		
SC MBR Upgrade		
Reset		
App Reset	0	
EEPROM Rst	0	
SPI Flash Reset	Failure	
OPTION_HDMI		
DVI/HDMI SOUND	Auto	
HDMI HOT PLUG	Disable	
HOTPLUG SWITCHING	boot	
HOTPLUG DURATION	1200ms	
CLK TERM DURATION	1200ms	
HDMI FLT CNT SIG	100ms	
HDMI FLT CNT LOS	100ms	
UNSTABLE BAN CNT	5000ms	
HDMI ROBIN	ON	
HDMI Callback	OFF	
HDMI CTS Thld	8	
HDMI CTS Cnt1	1	
HDMI EQ	Auto	
HDMI Write Type	Combine	
HDMI Switch	NONE	
DVI SET TIME	300ms	
HDMI Sync	DE	
HDMI 3D DET	0	
HOTPLUG OFF HOLD TIME		
HDMI Stable Count	1	
HDCP UPDATE SPI		

4. Troubleshooting

Factory Menu Name	Data	Range
SPI VERSION	0	
DVB CI		
TS Clock delay TC	0	
TS Clock delay S	0	
CI Control Buf ON	ON	
TS Clock delay CPU	-1	
Test Pattern		
Pattern Sel	OFF	
Logic Pattern Sel		
Logic Level Sel		
FRC Pre Test Pattern	0	
FRC Post Test Pattern	0	
SOC TCON Test Pattern	0	
SOC TCON Pattern Level	255	
SOC TCON FRC Pattern	0	
HDMI WB Pattern	OFF	
HDMI Pattern Sel	0	
Parma Pre Test Pattern	0	
Parma Port Test Pattern	0	
FRC OSD PRE PATTERN	0	
FRC OSD POST PATTERN	0	
Other Setting		
Delete S/N	0	
IPERF	stopped	
Expert		
CAL Data Backup		
CAL Data Restore		
ATV IF AGC SPEED		
Auto Power	LAST POWER	LAST POWER/ALWAYS ON/ALWAYS OFF
SVC Panel	ORIGINAL	

■ ADC/WB

Factory Menu Name	Data	Range
ADC		
AV Calibration		
Comp Calibration		
PC Calibration		
HDMI Calibration		
ADC Result		
1st_Y_GH	0	
1st_Y_GL	0	
1st_Cb_BH	0	
1st_Cb_BL	0	
1st_Cr_RH	0	
1st_Cr_RL	0	
2nd_R_L	134	
2nd_G_L	134	
2nd_B_L	134	
2nd_R_H	49	
2nd_G_H	49	
2nd_B_H	49	
White Balance		
R-Offset	128	
G-Offset	128	
B-Offset	128	
R-Gain	128	
G-Gain	128	
B-Gain	128	
WB-W2_R_Offset		
WB_W2_B_Offset		
WB_W2_R_Gain		
WB_W2_B_Gain		
WB-N_R_Offset		
WB_W2_N_Offset		
WB_W2_N_Gain		
WB_W2_N_Gain		
MGA		
MGA On/Off	OFF	
R1_Gain		

4. Troubleshooting

Factory Menu Name	Data	Range
G1_Gain		
B1_Gain		
R2_Gain		
G2_Gain		
B2_Gain		
R3_Gain		
G3_Gain		
B3_Gain		
R4_Gain		
G4_Gain		
B4_Gain		
R5_Gain		
G5_Gain		
B5_Gain		
R6_Gain		
G6_Gain		
B6_Gain		
R7_Gain		
G7_Gain		
B7_Gain		
R8_Gain		
G8_Gain		
B8_Gain		
R9_Gain		
G9_Gain		
B9_Gain		
R10_Gain		
G10_Gain		
B10_Gain		

4-4. White Balance

4-4-1. Calibration

1. Into the Factory Mode.
2. Select **ADC/WB** menu.
3. Select **ADC** menu.

Option	AV Calibration
Control	Comp Calibration
Debug	HDMI Calibration
SVC	
ADC/WB	
Advanced	


4-4-2. Service Adjustment

You must perform Calibration in the Lattice Pattern before adjusting the White Balance.

■ Color Calibration

- Adjust Specification

Source	Setting Mode	Pattern	Use Equipment
HDMI	1280 x 720@60 Hz	Pattern #24 (Chess Pattern)	CA210 & Master MSPG925 Generator



(Chess Pattern)

- Use other equipment only after comparing the result with that of the Master equipment.

Input mode	Calibration	Pattern
CVBS IN (Model_#1)	Perform in NTSC B&W Pattern #24	Lattice
Component IN (Model_#6)	Perform in 720p B&W Pattern #24	Lattice
HDMI IN	Perform in 720p B&W Pattern #24	Lattice

Method of Color Calibration (AV)

1. Apply the NTSC Lattice (N0. 3) pattern signal to the AV IN 1 port.
2. Press the Source key to switch to “AV1” mode.
3. Enter Service mode.
4. Select the “ADC” menu.
5. Select the “AV Calibration” menu.
6. In “AV Calibration Off” status, press the “▶” key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the “AV Calibration” status from Failure to Success.

Method of Color Calibration (Component)

1. Apply the 720p Lattice (N0. 6) pattern signal to the Component IN 1 port.
2. Press the Source key to switch to “Component1” mode.
3. Enter Service mode.
4. Select the “ADC” menu.
5. Select the “Comp Calibration” menu.
6. In “Comp Calibration Off” status, press the “▶” key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the “Comp Calibration” status from Failure to Success.

Method of Color Calibration (HDMI)

1. Apply the 720p Lattice (N0. 6) pattern signal to the HDMI1/DVI IN port.
2. Press the Source key to switch to “HDMI1” mode.
3. Enter Service mode.
4. Select the “ADC” menu.
5. Select the “HDMI Calibration” menu.
6. In “HDMI Calibration Off” status, press the “▶” key to perform Calibration.
7. When Calibration is complete, it returns to the high-level menu.
8. You can see the change of the “HDMI Calibration” status from Failure to Success.

4-4-3. Adjustment


9. Into the Factory Mode.
10. Select **ADC/WB** menu.
11. Select **White Balance** menu.

Option			
Control			
Debug			
SVC			
ADC/WB	White Balance	(Low Light) Sub Brightness R offset G offset B offset	(Hight Light) Sub Contrast R gain G gain B gain
Advanced			

4-5. RS-232C

• RS232C Control

- Port : COM#(Serial)
- Baud rate : 9600
- Data Bit : 8 bit
- Parity : None
- Stop Bits : 1
- Flow Control : None



• Description of RS232C

Pin#	Name	Full Name	Pin#	Name	Full Name	Pin#	Name	Full Name
1	CD	Carrier Detect	4	DTR	Data Terminal Ready	7	RTS	Request To Send
2	RxD	Received Data	5	GND	Signal Ground	8	CTS	Clear To Send
3	TxD	Transmitted Data	6	DSR	Data Set Ready	9	RI	Ring Indicator

4-6. AV Control Tab

Control Item				Cmd1	Cmd2	Cmd3	Value
General	Power	Power		0x00	0x00	0x00	0x00
		Off					0x01
		On					0x02
	Volume	Direct		0x01	0x00	0x00	(0~100)
		Up				0x01	0x00
		Down				0x02	0x00
	Mute			0x02	0x00	0x00	0x00
		Ch.	Direct	0x04	-		
			Continuous	0x03	0x00	0x01	0x00
			Down			0x02	0x00

Control Item				Cmd1	Cmd2	Cmd3	Value
Input	Source List	TV	TV	0x0a	0x00	0x00	0x00
			AV			0x01	0x00
		AV	AV1				0x01
			AV2				0x01
			AV3				0x02
		S-Video	S-Video1			0x02	0x00
			S-Video2				0x01
			S-Video3				0x02
		Component	Component1			0x03	0x00
			Component2				0x01
			Component3				0x02
		PC	PC1			0x04	0x00
			PC2				0x01
			PC3				0x02
		HDMI	HDMI1			0x05	0x00
			HDMI2				0x01
			HDMI3				0x02
			HDMI4				0x03
		DVI	DVI1			0x06	0x00
			DVI2				0x01
			DVI3				0x02

Control Item				Cmd1	Cmd2	Cmd3	Value
PICTURE	Mode	Dynamic(Entertain)		0x0b	0x00	0x00	0x00
		Standard					0x01
		Movie					0x02
		Natural					0x03

Control Item				Cmd1	Cmd2	Cmd3	Value
PICTURE	Mode	CAL-NIGHT					0x04
		CAL-DAY					0x05
		BD Wise					0x06
		Relax					0x07
	BackLight (CellLight)		0~20		0x01	0x00	(0~20)
	Contrast		0~100		0x02	0x00	(0~100)
	Brightness		0~100		0x03	0x00	(0~100)
	Sharpness		0~100		0x04	0x00	(0~100)
	Color		0~10		0x05	0x00	(0~100)
	Tint	G/R			0x06	0x00	(0~100)
	Advanced Settings	Black Tone	Off		0x07	0x00	0x00
			Dark				0x01
			Darker				0x02
			Darkest				0x03
		Dynamic Contrast	Off			0x01	0x00
			Low				0x01
			Medium				0x02
			High				0x03
		Shadow Detail	-2 ~ 2			0x02	(-2~2)
		Gamma	-3 ~ 3			0x03	(-3~3)
		RGB Only Mode	Off			0x05	0x00
			Red				0x01
			Green				0x02
			Blue				0x03
		Color Space	Auto			0x06	0x00
			Native				0x01
			Custom				0x02
		White Balance	R-Offset(LCD)			0x07	(0~50)
		White Balance	G-Offset(LCD)			0x08	(0~50)
		White Balance	B-Offset(LCD)			0x09	(0~50)
		White Balance	R-Gain(LCD)			0x0a	(0~50)
		White Balance	G-Gain(LCD)			0x0b	(0~50)
		White Balance	B-Gain(LCD)			0x0c	(0~50)
		White Balance	Reset(LCD)			0x0d	0x00
		Flesh Tone	-15 ~ 15			0x0e	(-15~15)
		Edge Enhancement	Off			0x0f	0x00

New function of 12"
(only PDP TV)

Control Item				Cmd1	Cmd2	Cmd3	Value
PICTURE		xvYCC	On				0x01
			Off			0x10	0x00
		Motion Lighting	On				0x01
			Off			0x11	0x00
		LED Motion Plus	On				0x01
			Off		0x0a	0x07	0x00
			On(Normal)				0x01
			Cinema				0x02
			Ticker				0x03
	Picture Option	Color Tone	Cool		0x0a	0x00	0x00
			Standard				0x01
			Warm1				0x02
			Warm2				0x03
		Digital Noise Filter	Off			0x02	0x00
			Low				0x01
			Medium				0x02
			High				0x03
			Auto				0x04
			Auto Visualization				0x05
		MPEG Noise Filter	Off			0x03	0x00
			Low				0x01
			Medium				0x02
			High				0x03
			Auto				0x04
		HDMI Black Level	Normal			0x04	0x00
			Low				0x01
		Film Mode	Off			0x05	0x00
			Auto1				0x01
			Auto2				0x02
			Cinema Smooth				0x03
		Auto Motion Plus	Off			0x06	0x00
			Clear				0x01
			Standard				0x02
			Smooth				0x03
			Custom				0x04

Change Normal → Standard mode

New function of 12" (only PDP TV)

Control Item				Cmd1	Cmd2	Cmd3	Value
PICTURE			Demo				0x05
	Screen Adjustment	Picture Size	16:9	0x0b	0x0a	0x01	0x00
			Zoom1				0x01
			Zoom2				0x02
			Wide Fit				0x03
			4:3				0x04
			Screen Fit				0x05
			Smart View I				0x06
			Smart View II				0x07
			Auto Wide				0x08
			Wide Zoom				0x09
	Zoom					0x0a	
	Reset Picture		Reset Picture		0x0b	0x0b	0x00
	3D	3D Mode	Off	0x0b	0x0c	0x00	0x00
			2D → 3D				0x01
			Side By Side				0x02
			Top Bottom				0x03
			Line By Line				0x04
			Vertical Line				0x05
			Checker BD				0x06
			Frame Sequence				0x07
		3D → 2D	Off			0x01	0x00
			On				0x01
		3D View Point				0x02	(-5~5)
		Depth				0x03	(1~10)
		3D Auto View	Off			0x05	0x00
			Message Notice				0x01
			On				0x02
Control Item				Cmd1	Cmd2	Cmd3	Value
Sound	Sound Mode	Standard		0x0c	0x00	0x00	0x00
		Music					0x01
		Movie					0x02
		Clear Voice					0x03
		Amplify					0x04

New function of 12" (only DVB TV)

New function of 12"
(only DVB TV)

4. Troubleshooting

Control Item				Cmd1	Cmd2	Cmd3	Value
Sound	Equalizer	Balance			0x01	0x00	(0~20)
		100hz				0x01	(0~20)
		300hz				0x02	(0~20)
		1khz				0x03	(0~20)
		3khz				0x04	(0~20)
		10khz				0x05	(0~20)
		Reset				0x06	0x00
	SRS TruSurround HD (echo)	Off			0x02	0x00	0x00
	Virtual Surround (echo)	On					0x01
	SRS TruDialog (echo)	Off			0x03	0x00	0x00
	Dialog Clarify (X9)	On					0x01
	Preferred Language	English			0x04	0x00	0x00
		Spanish					0x01
		French					0x02
		Korean					0x03
		Japanese					0x04
	Multi-Track Sound	Mono			0x05	0x00	0x00
		Stereo					0x01
		SAP					0x02
	Auto Volume	Off			0x06	0x00	0x00
		ON					0x01
		Night					0x02
	Speaker Select	TV Speaker			0x07	0x00	0x00
		External Speaker					0x01
	Sound Select	Main			0x08	0x00	0x00
		Sub					0x01
	Sound Reset	Sound Reset			0x09	0x00	0x00
	3D Audio	Off			0x0a	0x00	0x00
		Low					0x01
		Medium					0x02
		High					0x03

New function of 12"

Control Item			Cmd1	Cmd2	Cmd3	Value
KEY	Key Generation		0x0d	0x00	0x00	refer to table
OSD	Show/Hide Control	Show	0x0e	0x00	0x00	0x00
		Hide				0x01
Get Status	Power (On/Off)		0xf0	0x00	0x00	0x00
	Volume(0~100)		0xf0	0x01	0x00	0x00
	Mute (On/Off)		0xf0	0x02	0x00	0x00
	Channel Number		0xf0	0x03	0x00	0x00
	Source (TV/AV/.../HDMI/...)		0xf0	0x04	0x00	0x00
	Picture Size		0xf0	0x05	0x00	0x00
	3D (On/Off)		0xf0	0x06	0x00	0x00
	Picture Mode		0xf0	0x07	0x00	0x00
	Sound Mode		0xf0	0x08	0x00	0x00

New function of 12"

Key value	Value
Up	96 (0x60)
Down	97 (0x61)
Left	101 (0x65)
Right	98 (0x62)
Menu	26 (0x1A)
Internet	147 (0x93)
Enter(OK)	104 (0x68)
EXIT	45 (0x2D)

4-7. Software Upgrade

Software Upgrade can be performed by downloading the latest firmware from samsung.com to a USB memory device.


- Current Version - The software already installed in the TV.

Software is represented as 'Year/Month/Day_Version'.

4-7-1. How to Check the Software Version

■ Use the Main Menu

1. Click the "MENU" key in remote controller.
2. Select "Support" menu.
3. Locate the menu cursor "Software Upgrade" menu.
4. Click the "INFO" key.
 - Check the Main SW and Micom version.



■ Use the Factory Mode

Option
Control
Debug
SVC
ADC/WB
Advanced

```
T-NT14MAKUC-xxxx
T-NT14MAKUCSS-xxxx
BT Version :*****
E-Manual : NMATSCH-1.****
Blaster Version : 258401-258403-300001
EDID SUCCESS
CALIB : AV/COMP/PC/HDMI/
Option : 50R1AF0D,US,6203,NONE (Vary by inches)
```

```
DTP-SDAL-NT14M-MAIN-****-****
RFS : "NT14M *****" K/2 2014-0*-.**
KERNEL : 107.1272,/ Onboot : 00**
DTP-DTVTD-****
Backend[FOX-FT2] Panel[120Hz]
TCON Version : ****
```

4-7-2. How to Upgrade Software

1. Insert a USB drive containing the firmware upgrade downloaded from samsung.com into the TV.



NOTE

Please be careful not to disconnect the power or remove the USB drive while upgrades are being applied.

2. The TV will turn off and turn on automatically after completing the firmware upgrade.
3. Please check the firmware version after the upgrades are complete.
 - the new version will have a higher number than the older version.



NOTE

- When software is upgraded, video and audio settings you have made will return to their default (factory) settings.
- We recommend you write down your settings before beginning firmware update.

4. After update is completed, restore your previous settings.

■ Main Software Upgrade

1

Store the sw program named "**T-NT14MAKUC**" in USB memory stick.

2

Click the "**MENU**" key in Remote Controller.

3

Select "**Support - Software Update - Update Now**" menu.

4

- Click the "**ENTER**" key.
- Wait for upgrade complete.
 - Check the Software Version.

■ Sub Software Upgrade

USB Download

1. After Main Software upgrade, Enter the Factory menu by below method.

– Factory Remocon

- Click the Remocon button continuedly. (Info key+ Factory key)



– Nomal Remocon

- ① Turn off the TV. → ② Click the Remocon button continuedly.



2. Select the “SVC”.

Option
Control
SVC
Expert
ADC/WB
Advanced

3. Select the “SUBMICOM UPGRADE”.

Test pattern		DCC CHK SEL	0
Panel Display Time	1Hr	DCC CHECK LOCAL	0x0
Tuner Status		DCC CHECK TOTAL	
T-CON Usb Download	Failure	Fuction Upgrade	off
T-CON CheckSum	Error	Smart Hub Reset	off
Tuner Margin	10	WIFI ER COUNT	0
TS Clock delay	0	BT ER COUNT	0
SUBMICOM UPGRADE	off	Debug Log Down	
BT ADDRESS	0000	MulitACC Checksum	Error
BT UPGRADE		SVC Info	
BT FREEPAIRING	ON	TS Clock delay TC	0
SVC Reset		TS Clock delay S	0
TCON_TEMP READ	0.00	CAL Data Backup
TEMP LAST	60.00	CAL Data Restore
DCC VERSION	0x0		

4. Click the “→” remocon key.


SUBMICOM UPGRADE	Wait
-------------------------	-------------

- Wait for upgrade complete.
- Check the Software version.


5. Wiring Diagram

5-1. Wiring Diagram

■ 40" / 46"



5-2. Connector



1 CN1401_FHD							
1	NC	14	EVEN_TX4+	27	EVEN_TX0-	40	ODD_TX1-
2	GND	15	EVEN_TX4-	28	GND	41	ODD_TX0+
3	FRC_SDA	16	EVEN_TX3+	29	ODD_TX4+	42	ODD_TX0-
4	FRC_PWM1	17	EVEN_TX3-	30	ODD_TX4-	43	GND
5	FRC_SCL	18	GND	31	ODD_TX3+	44	GND
6	FRC_PWM3	19	EVEN_TXCLK-	32	ODD_TX3-	45	GND
7	FRC_PWM2	20	EVEN_TXCLK+	33	GND	46	FRC_PWM4
8	TCON_SDA	21	GND	34	ODD_TXCLK+	47	PANEL_13V_PW
9	PANEL_I2C_EN	22	EVEN_TX2+	35	ODD_TXCLK-	48	PANEL_13V_PW
10	BT_SYNC	23	EVEN_TX2-	36	GND	49	PANEL_13V_PW
11	UPDATE_CHK	24	EVEN_TX1+	37	ODD_TX2+	50	PANEL_13V_PW
12	TCON_SCL	25	EVEN_TX1-	38	ODD_TX2-	51	PANEL_13V_PW
13	GND	26	EVEN_TX0+	39	ODD_TX1+		

② CN1402 (to LAN)

1	LAN_TXD+	5	GND
2	GND	6	LAN_RXD-
3	LAN_TXD-	7	NC
4	LAN_RXD+	8	GND

③ CN502(to Component&AV)

1	GND	9	TEST_PR
2	COMP2_Y_CVBS	10	GND
3	INDENT_VIEDO2	11	COMP2_AV2_SL_IN
4	GND	12	TEST_SL
5	COMP2_PB	13	GND
6	INDENT_COMP2	14	COMP2_AV2_SR_IN
7	GND	15	TEST_SR
8	COMP2_PR		

④ CN302(to Speaker)

1	R+	3	L+
2	R-	4	L-

⑤ CN1201_FUN(to Function/IR)

1	IR	14	A5V
2	GND	15	LED_STB
3	GND	16	BT_WAKE
4	FRAME_SYNC_IN	17	GND
5	A3.3V	18	POWER_DET
6	BT_SYNC	19	NC
7	MSCL	20	BT_RESET
8	GND	21	GND
9	MSDA	22	WIFI_DP
10	USB_BT_DP	23	WIFI_DM
11	KEY_INPUT1	24	B5V_DC_PW
12	USB_BT_DM	25	WIFI_WOL
13	KEY_INPUT2	26	WIFI_RESET

⑥ CN401_OPT(to Optical Jack)

1	SPDIF_OUT	3	GND
2	B5V_DC_PW		

⑦ CN1502(USB2)

1	B5V_USB2_PW	3	USB2_DP
2	USB2_DM	4	GND

⑧ CN1501(USB1)

1	B5V_USB1_PW	3	USB1_DP
2	USB1_DM	4	GND

⑨ CN2402_IRB (IRB) : It's depend on Country.

1	GND	5	NC
2	B3.3V_PW	6	IRB_JACK_ID
3	NC	7	GND
4	NC		

⑩ CN304 (HEADPHONE & LR OUT)

1	GND	4	TEST_SL
2	HP_LINE_SL_OUT	5	TEST_SR
3	HP_LINE_SR_OUT	6	IDENT_HP

⑪ CN601 (to HDMI1)

1	HDMI1_RX2+	11	GND
2	GND	12	HDMI1_RXCLK-
3	HDMI1_RX2-	13	CEC
4	HDMI1_RX1+	14	NC
5	GND	15	HDMI1_SCL_DDC
6	HDMI1_RX1-	16	HDMI1_SDA_DDC
7	HDMI1_RX0+	17	GND
8	GND	18	HDMI1_5V
9	HDMI1_RX0-	19	HDMI1_HOT_PLUG
10	HDMI1_RXCLK+		

5. Wiring Diagram

12 CN602 (to HDMI2)			
1	HDMI2_RX2+	11	GND
2	GND	12	HDMI2_RXCLK-
3	HDMI2_RX2-	13	CEC
4	HDMI2_RX1+	14	ARC2_SIGLE
5	GND	15	HDMI2_SCL_DDC
6	HDMI2_RX1-	16	HDMI2_SDA_DDC
7	HDMI2_RX0+	17	GND
8	GND	18	HDMI2_5V
9	HDMI2_RX0-	19	HDMI2_HOT_PLUG
10	HDMI2_RXCLK+		

13 CN201(to Power board)			
1	FRC_PWM4	10	SW_INVERTER
2	NC	11	A13V_PW
3	GND	12	OVD_LEVEL
4	GND	13	A13V_PW
5	A13V_PW	14	OVD_ON_OFF
6	GND	15	GND
7	A13V_PW	16	PWM_DIM
8	SW_POWER_OUT	17	FRC_PWM3
9	A13V_PW	18	FRC_PWM2

5-3. Connector Functions

Connector	Function
CN201 ↔ CNM803	Supply main power and dimming signal from IP board to Main Board.
CN1401 ↔ CON3	The LVDS signal transfered from Main Board to Panel.