

PHILIPS

39" LCD TV


Service Manual

39HFL5784L/F7 (Serial No.: DS1)

© 2013 Funai Electric Co., Ltd.

All rights reserved. No part of this manual may be reproduced, copied, transmitted, disseminated, transcribed, downloaded or stored in any storage medium, in any form or for any purpose without the express prior written consent of Funai. Furthermore, any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

Information in this document is subject to change without notice. Funai reserves the right to change the content herein without the obligation to notify any person or organization of such changes.

FUNAI with the  design is a registered trademark of Funai Electric Co., Ltd and may not be used in any way without the express written consent of Funai. All other trademarks used herein remain the exclusive property of their respective owners. Nothing contained in this manual should be construed as granting, by implication or otherwise, any license or right to use any of the trademarks displayed herein. Misuse of any trademarks or any other content in this manual is strictly prohibited. Funai shall aggressively enforce its intellectual property rights to the fullest extent of the law.

IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all P&F Equipment. The service procedures recommended by P&F and described in this service manual are effective methods of performing service operations. Some of these service special tools should be used when and as recommended.

It is important to note that this service manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. P&F could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, P&F has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by P&F must first use all precautions thoroughly so that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

<p>The LCD panel is manufactured to provide many years of useful life. Occasionally a few non active pixels may appear as a tiny spec of color. This is not to be considered a defect in the LCD screen.</p>

TABLE OF CONTENTS

Specifications	1-1
Important Safety Precautions	2-1
Standard Notes for Servicing	3-1
Cabinet Disassembly Instructions	4-1
Electrical Adjustment Instructions	5-1
How to Initialize the LCD TV	6-1
Firmware Renewal Mode	7-1
Hotel TV Mode	8-1
Troubleshooting	9-1
Block Diagrams	10-1
Schematic Diagrams / CBA and Test Points	11-1
Wiring Diagram	12-1
Exploded Views	13-1
Parts List	14-1

SPECIFICATIONS

< TUNER / NTSC >

ANT. Input ----- 75 Ω Unbal., F type

Description	Condition	Unit	Nominal	Limit
1. AFT Pull-In Range	---	MHz	± 2.3	± 2.1
2. Synchronizing Sens.	TV.ch.4	dB μ V	18	20
	CA.ch.31	dB μ V	18	20
	CA.ch.87	dB μ V	18	23

< TUNER / ATSC >

Description	Condition	Unit	Nominal	Limit
1. Received Freq. Range (-28dBm)	---	kHz	---	± 100
2. ATSC Dynamic Range (min / max)	ch.4	dBm	---	-76/0
	ch.10	dBm	---	-76/0
	ch.41	dBm	---	-76/+4

< LCD PANEL >

Description	Condition	Unit	Nominal	Limit
1. Native Pixel Resolution	Horizontal	pixels	1920	---
	Vertical	pixels	1080	---
2. Brightness (w / filter)	---	cd/m ²	270	---
3. Viewing Angle	Horizontal	°	-88 to 88	---
	Vertical	°	-88 to 88	---

< VIDEO >

Description	Condition	Unit	Nominal	Limit
1. Over Scan	Horizontal	%	5	5 \pm 5
	Vertical	%	5	5 \pm 5
2. Color Temperature	---	°K	12000	---
	x		0.272	$\pm 5\%$
	y		0.278	$\pm 5\%$
	<Measurement condition> Input signal: HDMI1 Raster (40/80IRE) 1080i@60 Measurement point: Screen center Measuring instrument: Made of KONICA MINOLTA Luminance meter CA-310 Aging time: 60min. (100IRE Raster HDMI 1080i@60) MODE setting of TV: Shipment setting Ambient temperature: 25°C \pm 5°C			
3. Resolution (composite video)	Horizontal	line	400	---
	Vertical	line	350	---

< AUDIO >

All items are measured across 8 Ω load at speaker output terminal with L.P.F.

Description	Condition	Unit	Nominal	Limit
1. Audio MAX Output (ATSC 0dBfs)	Lch/Rch	W	8.0/8.0	7.0/7.0
2. Audio Distortion (NTSC)	500mW: Lch/Rch	%	0.5/0.5	2.0/2.0

IMPORTANT SAFETY PRECAUTIONS

Prior to shipment from the factory, our products are strictly inspected for recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.


Safety Precautions for LCD TV Circuit

1. **Before returning an instrument to the customer**, always make a safety check of the entire instrument, including, but not limited to, the following items:

- a. Be sure that no built-in protective devices are defective and have been defeated during servicing. (1) Protective shields are provided on this chassis to protect both the technician and the customer. Correctly replace all missing protective shields, including any removed for servicing convenience. (2) When reinstalling the chassis and/or other assembly in the cabinet, be sure to put back in place all protective devices, including but not limited to, nonmetallic control knobs, insulating fishpapers, adjustment and compartment covers/shields, and isolation resistor/capacitor networks. **Do not operate this instrument or permit it to be operated without all protective devices correctly installed and functioning. Servicers who defeat safety features or fail to perform safety checks may be liable for any resulting damage.**
- b. Be sure that there are no cabinet openings through which an adult or child might be able to insert their fingers and contact a hazardous voltage. Such openings include, but are not limited to, (1) spacing between the Liquid Crystal Panel and the cabinet mask, (2) excessively wide cabinet ventilation slots, and (3) an improperly fitted and/or incorrectly secured cabinet back cover.


- c. **Antenna Cold Check** - With the instrument AC plug removed from any AC source, connect an electrical jumper across the two AC plug prongs. Place the instrument AC switch in the on position. Connect one lead of an ohmmeter to the AC plug prongs tied together and touch the other ohmmeter lead in turn to each tuner antenna input exposed terminal screw and, if applicable, to the coaxial connector. If the measured resistance is less than 1.0 megohm or greater than 5.2 megohm, an abnormality exists that must be corrected before the instrument is returned to the customer. Repeat this test with the instrument AC switch in the off position.

- d. **Leakage Current Hot Check** - With the instrument completely reassembled, plug the AC line cord directly into a 120 V AC outlet. (Do not use an isolation transformer during this test.) Use a leakage current tester or a metering system that complies with American National Standards Institute (ANSI) C101.1 Leakage Current for Appliances and Underwriters Laboratories (UL) 1410, (50.7). With the instrument AC switch first in the on position and then in the off position, measure from a known earth ground (metal water pipe, conduit, etc.) to all exposed metal parts of the instrument (antennas, handle brackets, metal cabinet, screw heads, metallic overlays, control shafts, etc.), especially any exposed metal parts that offer an electrical return path to the chassis. Any current measured must not exceed 0.5 milli-ampere. Reverse the instrument power cord plug in the outlet and repeat the test.



ANY MEASUREMENTS NOT WITHIN THE LIMITS SPECIFIED HEREIN INDICATE A POTENTIAL SHOCK HAZARD THAT MUST BE ELIMINATED BEFORE RETURNING THE INSTRUMENT TO THE CUSTOMER OR BEFORE CONNECTING THE ANTENNA OR ACCESSORIES.

2. Read and comply with all caution and safety-related notes on or inside the receiver cabinet, on the receiver chassis, or on the Liquid Crystal Panel.

3. **Design Alteration Warning** - Do not alter or add to the mechanical or electrical design of this TV receiver. Design alterations and additions, including, but not limited to circuit modifications and the addition of items such as auxiliary audio and/or video output connections, might alter the safety characteristics of this receiver and create a hazard to the user. Any design alterations or additions will void the manufacturer's warranty and may make you, the servicer, responsible for personal injury or property damage resulting therefrom.
4. **Hot Chassis Warning** -
 - a. Some TV receiver chassis are electrically connected directly to one conductor of the AC power cord and maybe safety-serviced without an isolation transformer only if the AC power plug is inserted so that the chassis is connected to the ground side of the AC power source. To confirm that the AC power plug is inserted correctly, with an AC voltmeter, measure between the chassis and a known earth ground. If a voltage reading in excess of 1.0 V is obtained, remove and reinsert the AC power plug in the opposite polarity and again measure the voltage potential between the chassis and a known earth ground.
 - b. Some TV receiver chassis normally have 85V AC(RMS) between chassis and earth ground regardless of the AC plug polarity. This chassis can be safety-serviced only with an isolation transformer inserted in the power line between the receiver and the AC power source, for both personnel and test equipment protection.
 - c. Some TV receiver chassis have a secondary ground system in addition to the main chassis ground. This secondary ground system is not isolated from the AC power line. The two ground systems are electrically separated by insulation material that must not be defeated or altered.
5. Observe original lead dress. Take extra care to assure correct lead dress in the following areas: a. near sharp edges, b. near thermally hot parts-be sure that leads and components do not touch thermally hot parts, c. the AC supply, d. high voltage, and, e. antenna wiring. Always inspect in all areas for pinched, out of place, or frayed wiring. Check AC power cord for damage.
6. Components, parts, and/or wiring that appear to have overheated or are otherwise damaged should be replaced with components, parts, or wiring that meet original specifications. Additionally, determine the cause of overheating and/or damage and, if necessary, take corrective action to remove any potential safety hazard.
7. **Product Safety Notice** - Some electrical and mechanical parts have special safety-related characteristics which are often not evident from visual inspection, nor can the protection they give necessarily be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by a  on schematics and in parts lists. Use of a substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire, and/or other hazards. The product's safety is under review continuously and new instructions are issued whenever appropriate. Prior to shipment from the factory, our products are strictly inspected to confirm they comply with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

Precautions during Servicing

- A.** Parts identified by the **▲** symbol are critical for safety.
Replace only with part number specified.
- B.** In addition to safety, other parts and assemblies are specified for conformance with regulations applying to spurious radiation. These must also be replaced only with specified replacements.
Examples: RF converters, RF cables, noise blocking capacitors, and noise blocking filters, etc.
- C.** Use specified internal wiring. Note especially:
 - 1) Wires covered with PVC tubing
 - 2) Double insulated wires
 - 3) High voltage leads
- D.** Use specified insulating materials for hazardous live parts. Note especially:
 - 1) Insulation Tape
 - 2) PVC tubing
 - 3) Spacers
 - 4) Insulators for transistors.
- E.** When replacing AC primary side components (transformers, power cord, etc.), wrap ends of wires securely about the terminals before soldering.
- F.** Observe that the wires do not contact heat producing parts (heat sinks, oxide metal film resistors, fusible resistors, etc.)
- G.** Check that replaced wires do not contact sharp edged or pointed parts.
- H.** When a power cord has been replaced, check that 11~13 lb (5~6 kg) of force in any direction will not loosen it.
- I.** Also check areas surrounding repaired locations.
- J.** Use care that foreign objects (screws, solder droplets, etc.) do not remain inside the set.
- K.** When connecting or disconnecting the internal connectors, first, disconnect the AC plug from the AC supply outlet.
- L.** When installing parts or assembling the cabinet parts, be sure to use the proper screws and tighten certainly.

Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions. Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

1. Clearance Distance

When replacing primary circuit components, confirm specified clearance distance (d) and (d') between soldered terminals, and between terminals and surrounding metallic parts. (See Fig. 1)

Table 1: Ratings for selected area

AC Line Voltage	Region	Clearance Distance (d), (d')
110 to 130 V	U.S.A. or Canada	≥ 3.2 mm (0.126 inches)

Note: This table is unofficial and for reference only. Be sure to confirm the precise values.




Fig. 1

2. Leakage Current Test

Confirm the specified (or lower) leakage current between B (earth ground, power cord plug prongs) and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.) is lower than or equal to the specified value in the table below.

Measuring Method: (Power ON)

Insert load Z between B (earth ground, power cord plug prongs) and exposed accessible parts. Use an AC voltmeter to measure across both terminals of load Z . See Fig. 2 and following table.




Fig. 2

Table 2: Leakage current ratings for selected areas


AC Line Voltage	Region	Load Z	Leakage Current (i)	Earth Ground (B) to:
110 to 130 V	U.S.A. or Canada	$0.15 \mu F$ CAP. & $1.5 k\Omega$ RES. Connected in parallel	$i \leq 0.5$ mA rms	Exposed accessible parts

Note: This table is unofficial and for reference only. Be sure to confirm the precise values.


STANDARD NOTES FOR SERVICING

Circuit Board Indications


1. The output pin of the 3 pin Regulator ICs is indicated as shown.



2. For other ICs, pin 1 and every fifth pin are indicated as shown.




3. The 1st pin of every male connector is indicated as shown.



Pb (Lead) Free Solder

Pb free mark will be found on PCBs which use Pb free solder. (Refer to figure.) For PCBs with Pb free mark, be sure to use Pb free solder. For PCBs without Pb free mark, use standard solder.




Pb free mark

How to Remove / Install Flat Pack-IC

1. Removal

With Hot-Air Flat Pack-IC Desoldering Machine:

1. Prepare the hot-air flat pack-IC desoldering machine, then apply hot air to the Flat Pack-IC (about 5 to 6 seconds). (Fig. S-1-1)




2. Remove the flat pack-IC with tweezers while applying the hot air.
3. Bottom of the flat pack-IC is fixed with glue to the CBA; when removing entire flat pack-IC, first apply soldering iron to center of the flat pack-IC and heat up. Then remove (glue will be melted). (Fig. S-1-6)
4. Release the flat pack-IC from the CBA using tweezers. (Fig. S-1-6)

CAUTION:


1. The Flat Pack-IC shape may differ by models. Use an appropriate hot-air flat pack-IC desoldering machine, whose shape matches that of the Flat Pack-IC.
2. Do not supply hot air to the chip parts around the flat pack-IC for over 6 seconds because damage to the chip parts may occur. Put masking tape around the flat pack-IC to protect other parts from damage. (Fig. S-1-2)

3. The flat pack-IC on the CBA is affixed with glue, so be careful not to break or damage the foil of each pin or the solder lands under the IC when removing it.




With Soldering Iron:

1. Using desoldering braid, remove the solder from all pins of the flat pack-IC. When you use solder flux which is applied to all pins of the flat pack-IC, you can remove it easily. (Fig. S-1-3)



2. Lift each lead of the flat pack-IC upward one by one, using a sharp pin or wire to which solder will not adhere (iron wire). When heating the pins, use a fine tip soldering iron or a hot air desoldering machine. (Fig. S-1-4)





3. Bottom of the flat pack-IC is fixed with glue to the CBA; when removing entire flat pack-IC, first apply soldering iron to center of the flat pack-IC and heat up. Then remove (glue will be melted). (Fig. S-1-6)
4. Release the flat pack-IC from the CBA using tweezers. (Fig. S-1-6)

With Iron Wire:



1. Using desoldering braid, remove the solder from all pins of the flat pack-IC. When you use solder flux which is applied to all pins of the flat pack-IC, you can remove it easily. (Fig. S-1-3)
2. Affix the wire to a workbench or solid mounting point, as shown in Fig. S-1-5.
3. While heating the pins using a fine tip soldering iron or hot air blower, pull up the wire as the solder melts so as to lift the IC leads from the CBA contact pads as shown in Fig. S-1-5.
4. Bottom of the flat pack-IC is fixed with glue to the CBA; when removing entire flat pack-IC, first apply soldering iron to center of the flat pack-IC and heat up. Then remove (glue will be melted). (Fig. S-1-6)
5. Release the flat pack-IC from the CBA using tweezers. (Fig. S-1-6)

Note: When using a soldering iron, care must be taken to ensure that the flat pack-IC is not being held by glue. When the flat pack-IC is removed from the CBA, handle it gently because it may be damaged if force is applied.



2. Installation

1. Using desoldering braid, remove the solder from the foil of each pin of the flat pack-IC on the CBA so you can install a replacement flat pack-IC more easily.
2. The "●" mark on the flat pack-IC indicates pin 1. (See Fig. S-1-7.) Be sure this mark matches the pin 1 on the PCB when positioning for installation. Then presolder the four corners of the flat pack-IC. (See Fig. S-1-8.)
3. Solder all pins of the flat pack-IC. Be sure that none of the pins have solder bridges.



Instructions for Handling Semi-conductors



Electrostatic breakdown of the semi-conductors may occur due to a potential difference caused by electrostatic charge during unpacking or repair work.

1. Ground for Human Body

Be sure to wear a grounding band ($1\text{ M}\Omega$) that is properly grounded to remove any static electricity that may be charged on the body.

2. Ground for Workbench

Be sure to place a conductive sheet or copper plate with proper grounding ($1\text{ M}\Omega$) on the workbench or other surface, where the semi-conductors are to be placed. Because the static electricity charge on clothing will not escape through the body grounding band, be careful to avoid contacting semi-conductors with your clothing.



CABINET DISASSEMBLY INSTRUCTIONS


Screw Torque Specification

Ref. No.	Part Number	Part Name	Tightening Torque
L7	GBHP3100	SCREW P-TIGHT (3X10 BIND HEAD+)	4.3±0.9lb-in
L23	GBJS3060	SCREW S-TIGHT (M3X6 BIND HEAD+)	
L24	GBHS3060	S-TIGHT SCREW (M3X6 BIND HEAD+BLACK)	
SSK1	1ESA34649	STAND SCREW KIT (DOUBLE SEMS SCREW M4X20 + BLK)	(approx. 8.7±0.9lb-in)*
SSK2	2ESA00308	STAND SCREW KIT (SECURITY SCREW M4X20)	

* For reference

1. Disassembly Flowchart

This flowchart indicates the disassembly steps for the cabinet parts and the CBA in order to gain access to items to be serviced. When reassembling, follow the steps in reverse order. Bend, route and dress the cables as they were.



2. Disassembly Method

Step/ Loc. No.	Part	Fig. No.	Removal	Note
[1]	Stand Assembly	D1	3(S-1)	---
[2]	Rear Cover	D1	5(S-2), 5(S-3)	---

Step/ Loc. No.	Part	Fig. No.	Removal	Note
[3]	Power Supply CBA	D2 D5	5(S-4), CN501, CN601, CN1001	---
[4]	Smart Link CBA Unit	D2 D5	3(S-5), CN1601, RF Cable	---
[5]	Digital Main CBA Unit	D2 D5	4(S-6), CN3105, CN3801, CN3906, Jack Holder	---
[6]	Stand Bracket	D3	2(S-7)	---
[7]	Speaker	D3	-----	---
[8]	Bottom Cover L	D3	(S-8), (S-9)	---
[9]	Bottom Cover R	D3	(S-10), (S-11)	---
[10]	LCD Panel Assembly	D3	-----	---
[11]	Front Cabinet	D4	10(S-12)	1
[12]	Function CBA Unit	D4 D5	Sensor Lens, Shield Plate, Control Plate	1

↓ ↓ ↓ ↓ ↓
 (1) (2) (3) (4) (5)

Note:

- (1) Order of steps in procedure. When reassembling, follow the steps in reverse order. These numbers are also used as the Identification (location) No. of parts in figures.
- (2) Parts to be removed or installed.
- (3) Fig. No. showing procedure of part location
- (4) Identification of parts to be removed, unhooked, unlocked, released, unplugged, unclamped, or desoldered.
P = Spring, L = Locking Tab, S = Screw, H = Hex Screw, CN = Connector
e.g. 2(S-2) = two Screws of (S-2),
2(L-2) = two Locking Tabs of (L-2)
- (5) Refer to the following "Reference Notes in the Table."

Important precautions concerning the LCD Panel Assembly:

1. When you disassemble/re-assemble the Front Cabinet or Function CBA Unit

- Be careful not to break the hooks. If you pull with too much force, the hooks may be damaged.
- Be careful not to scratch the display panel when assembling.
- Be careful not to scratch the rear frame when disassembling/re-assembling or when tightening the screws.
- Make sure the Shield Plate is placed properly.
- The Function CBA Unit and Sensor Lens are fixed in place by the hooks. Make sure these hooks are not damaged. Make sure the Function CBA Unit and Sensor Lens are securely in place when re-assembling.
- The screw tightening torque must be 6.1lb-in (7kgf-cm).
- Make sure the tact switches operate normally after replacing the Front Cabinet, Function CBA Unit, Sensor Lens, or Shield Plate.
- Make sure to replace the Control Plate to a new one when replacing the Front Cabinet.






Fig. D1







Fig. D4

***1: Make sure to read all the precautions on page 4-2 when you disassemble/re-assemble the Front Cabinet or Function CBA Unit.**

TV Cable Wiring Diagram



ELECTRICAL ADJUSTMENT INSTRUCTIONS

General Note: “CBA” is abbreviation for “Circuit Board Assembly.”

Note: Electrical adjustments are required after replacing circuit components and certain mechanical parts. It is important to perform these adjustments only after all repairs and replacements have been completed. Also, do not attempt these adjustments unless the proper equipment is available.

Test Equipment Required

1. Remote control unit
2. Color Analyzer, CA-310 (KONICA MINOLTA Luminance meter) or measuring instrument as good as CA-310.

How to set up the service mode

1. Turn the power on.
2. Wait for the TV to go to Live mode.
3. Press [RC5 Guest], [0], [6], [2], [5], [9], [6] and [RECALL/INFO] on setup remote control in this order. The following screen will appear.


"*" differs depending on the models.

[current]			
File code:	***_***_***_*		
Total checksum:	Push "0" key		
Panel-Option code:	**_***_***_***_***		
	__***_***_***	White Balance	
Press "POWER" key to exit.			
Tuner:	*****	TotalWatchTime:	*****
HDMI UART:	****	SystemTime:	**.*.*
EDID:	Push "0" key	Lightsensor:	**
Pro:Idiom:	Push "0" key		

1. Purity Check Mode

This mode cycles through full-screen displays of red, green, blue, and white to check for non-active pixels.

1. Enter the service mode.
2. Each time the [7] button on the remote control unit is pressed, the display changes as follows.




3. To cancel or to exit from the Purity Check Mode, press [BACK/PP] button.

2. VCOM Adjustment

Test Point	Adj. Point
Screen	[CH + or -] buttons
M. EQ.	Spec.
Color analyzer	See below

Figure



1. Set the color analyzer at the zero point calibration and bring the optical receptor pointing at the center of the LCD-Panel.
Note: The optical receptor must be set perpendicularly to the LCD Panel surface.
2. Enter the service mode.
3. Press [2] button on the remote control unit.
4. Press [CH + or -] buttons on the remote control unit so that the color analyzer value becomes minimum.
5. To cancel or to exit from the VCOM Adjustment, press [BACK/PP] button.

The White Balance Adjustment should be performed when replacing the LCD Panel or Digital Main CBA.


3. White Balance Adjustment

Purpose: To mix red and blue beams correctly for pure white.

Symptom of Misadjustment: White becomes bluish or reddish.

ITEM	SPECIFICATION
Color temperature	$x = 0.272 \pm 0.005$ $y = 0.278 \pm 0.005$
Input Signal	Internal pattern (30/80% raster)
Measurement point	Screen center
M. EQ.	CA-310 (KONICA MINOLTA Luminance meter) or measuring instrument as good as CA-310.
Aging time	60min. (100IRE Raster HDMI 1080i@60)
MODE setting of TV	Shipment setting
Ambient temperature	$25^{\circ}\text{C} \pm 5^{\circ}\text{C}$


1. Operate the unit for more than 60 minutes.
2. Enter the service mode.
3. Press [VOL -] button three times on the remote control unit to select "Drive setting" mode. "Drive" appears in the screen.
4. Set the color analyzer at the CHROMA mode and zero point calibration. Bring the optical receptor pointing at the center of the LCD-Panel.




Note: The optical receptor must be set perpendicularly to the LCD Panel surface.

5. Press [3] button to select the "HDB" for High Drive Blue adjustment. ("HDB" appears in the screen.)
6. Press [home/MENU] button. The internal Raster signal appears in the screen. ("Internal (Single)"

appears in the upper right of the screen as shown below.)



7. Press [CH + or -] buttons to adjust the color temperature becomes 12000°K ($x = 0.272$ / $y = 0.278 \pm 0.005$).
8. Press [1] button to select the "HDR" for High Drive Red adjustment ("HDR" appears in the screen.) and press [CH + or -] buttons to adjust the color temperature.
9. If necessary, adjust the "HDB" or "HDR" again.
10. Press [9] button to select the "LDB" for Low Drive Blue adjustment ("LDB" appears in the screen.) and press [CH + or -] buttons to adjust the color temperature.



11. Press [7] button to select the "LDR" for Low Drive Red adjustment ("LDR" appears in the screen.) and press [CH + or -] buttons to adjust the color temperature.
12. Press [8] button to select the "LDG" for Low Drive Green adjustment ("LDG" appears in the screen.) and press [CH + or -] buttons to adjust the color temperature.
13. If necessary, adjust the "LDB", "LDR" or "LDG" again.
14. Press [VOL -] button to shift to the "Debugging Message" mode.
If there is no message under "[WB]" section, this adjustment completes.
If "Drive settings are NG. Retry." is displayed, repeat above steps from 5. to 13. Then check "Debugging Message" again. If "Drive settings are NG. Retry." is displayed, replace the LCD Panel or Digital Main CBA.
15. To cancel or to exit from the White Balance Adjustment, press [BACK/PP] button.

HOW TO INITIALIZE THE LCD TV

The purpose of initialization is to place the set in a new out of box condition. The customer will be prompted to select a language and program channels after the set has been initialized.

To put the program back at the factory-default, initialize the LCD TV using the following procedure.

Note: Disconnect any device from the USB Port before you conduct on this procedure.

1. Turn the power on.
2. Enter the service mode.
3. Press [RC5 GUEST] button on the set up remote control unit.
4. Press [RECALL/INFO] button to proceed with the self check mode.
5. Make sure to confirm the "INITIALIZED : OK" appear in the green screen.
6. Unplug the AC Cord and plug it back on again.

Note: To cancel the service mode, press [⏻] button on the set up remote control unit.

FIRMWARE RENEWAL MODE

This section enables the upgrading of the TV software via IP, USB or RF. It also allows the configuration of the Auto Update feature to enable the TV to be automatically upgraded.

Note: Auto Update feature is only available with IP or RF upgrade.

System	Source	IP
	Type	USB
Setting	Version Check	RF
Applications	Execute	
Upgrades		
Factory Default		

- Source: "IP", "USB", "RF" – This function allows you to select the Source from which the TV Upgrade data will be received.

Note: The USB source is bidirectional (TV can read from the USB or write to the USB), but IP and RF sources are read only.

Like the TV Clone function, the RF option requires a GNA installed in the property head end to broadcast the data to the TVs. For more information, contact your P&F sales representative.

System	Source	All
	Type	Software
Setting	Version Check	Assets
Applications	Execute	Clone
Upgrades		P:I Key
Factory Default		

- Upgrade Type: "All", "Software", "Assets", "Clone", "P:I Key"
- This section allows you to select the type of software to be upgraded to the TV. (all 5 upgrade types are available if you select USB as source)
 - If set to ALL, then all elements (Software, Assets, Clone and P:I Keys) will be upgraded, based on their version and the version check setting.
 - If set to Software, the Stand-By MCU, SPI MCU and the SOC will be upgraded.
 - If set to Assets, the slideshow graphic assets will be upgraded.

- If set to Clone, Setup menu settings and channel map elements will be upgraded.
- If set to P:I Key, the TV will attempt to switch mode to FTG or PPV, provided that the correct key for its serial number is present.

Of these, only the Assets and Clone types are bidirectional. The All, Software, and P:I Key types are read only. If either Assets or Clone is selected, an additional menu item, Direction, appears.

System	Source	To TV
	Type	From TV
Setting	Direction	
Applications	Version Check	
Upgrades	Execute	
Factory Default		

- Direction:
 - "To TV" (reads data from the USB, copies it to the TV)
 - "From TV" (reads data from the TV, copies it to the USB)

System	Source	Off
	Type	On
Setting	Direction	
Applications	Version Check	
Upgrades	Execute	
Factory Default		

- Version Check: "On", "Off" - If set to Yes, this feature causes the TV to perform a version check of the TV upgrade software to ensure that only a newer version will be installed.

System	Source	Start
	Type	
Setting	Direction	
	Version Check	
Applications	Execute	
Upgrades		
Factory Default		

- **Start** - This function will initiate the TV upgrading process.

System	Source	Off
	RF Channel	10Min
Setting	Version Check	30Min
	Execute	1Hour
Applications	Auto Update	4Hour
Upgrades		
Factory Default		

- **Auto Update:** “4 Hour”, “1 Hour”, “30 Min”, “10 Min” - When TV goes into standby, Auto Update will automatically check for new TV upgrades and upgrade the TV software and/or clone data after 4 hour, 1 hour, 30 min or 10 min if newer versions are found. Like all previous RF download functions, this too requires a GNA to be installed in the property head end.

System	Source	
	RF Channel	
Setting	Version Check	
	Execute	87 . 1
Applications	Auto Update	
Upgrades		
Factory Default		

- **RF Channel Number.**
Indicates major. Minor channel where upgrading data is available.

HOTEL TV MODE

Capturing a Clonefile (TV to USB)

- All TV Setup menu settings and the TV channel map will be copied from the TV to the attached USB storage device.
- Any existing clone data on the USB storage device will be overwritten.
- All the key input and the shutdown timers will be invalid during the cloning process.
- Audio and Video will be muted during the cloning process.

How to capture a clone file from the TV to a USB storage device

1. Insert a USB storage device into the TV USB port. (It must have sufficient free space to hold a TV clone file - about 5 MB.)
2. Press the [HOME/MENU] button on the set up remote control to enter the setup menu.
3. Scroll down to and select "Upgrades".
4. Select "Source" and select "USB" then press the [OK] button.
5. Select "Type" and select "Clone" then press the [OK] button.
6. Select "Direction" and select "from TV" then press the [OK] button.
7. Select "Execute" and select "Start" then press the [OK] button.
8. After the successful completion, "Upgrade Completed! Press OK to continue" message appears on screen.

Note: Upon successful completion at Step 8, make sure to press the [OK] button once. If [OK] button is pressed twice, the cloning process will restart.

Installing a Clonefile (USB to TV)


- All TV Setup menu settings and the TV channel map will be copied from the USB storage device to the TV.
- All the key input and shutdown timers will be invalid during the cloning process.
- Audio and Video will be muted during the cloning process.
- If any illegal data is encountered in the clonefile, the cloning process will be aborted.
- After the successful completion of the cloning process, the new set of values will be adopted by the TV.

How to install a clone file from a USB storage device to the TV

1. Insert the USB flashdrive containing the clonefile into the TV USB port
2. Press the [HOME/MENU] button on the set up remote control to enter the setup menu.
3. Scroll down to and select "Upgrades".
4. Select "Source" and select "USB" then press the [OK] button.
5. Select "Type" and select "Clone" then press the [OK] button.
6. Select "Direction" and select "To TV" then press the [OK] button.
7. Select "Execute" and select "Start" then press the [OK] button.
8. After the successful completion, "Upgrade Completed! Press OK to continue" message appears on screen.
9. After pressing OK, the TV will restart and initialize with the new values.

Status menu screen (optional)

1. Turn the power on.
2. Press the [RC5 SETUP] and [RECALL/INFO] button on the set up remote control in this order to display the status menu.
You can switch the screen by using [▶] or [◀] button as shown below.




3. Press the [BACK/PP] button to exit the status menu.


TROUBLESHOOTING

[Power Supply Section]


FLOW CHART NO.1




FLOW CHART NO.2




FLOW CHART NO.3




FLOW CHART NO.4



FLOW CHART NO.5




FLOW CHART NO.6




[Video Signal Section]


FLOW CHART NO.1



FLOW CHART NO.2




FLOW CHART NO.3




[Audio Signal Section]

FLOW CHART NO.1




BLOCK DIAGRAMS


1. System Control Block Diagram




2. Video/Audio Block Diagram




3. Digital Signal Process Block Diagram



4. LED Backlight Drive Block Diagram



5. Power Supply Block Diagram



SCHEMATIC DIAGRAMS / CBA AND TEST POINTS

Standard Notes

WARNING

Many electrical and mechanical parts in this chassis have special characteristics. These characteristics often pass unnoticed and the protection afforded by them cannot necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts that have these special safety characteristics are identified in this manual and its supplements; electrical components having such features are identified by the mark “▲” in the schematic diagram and the parts list. Before replacing any of these components, read the parts list in this manual carefully. The use of substitute replacement parts that do not have the same safety characteristics as specified in the parts list may create shock, fire, or other hazards.

Notes:

1. Do not use the part number shown on these drawings for ordering. The correct part number is shown in the parts list, and may be slightly different or amended since these drawings were prepared.
2. All resistance values are indicated in ohms ($K = 10^3$, $M = 10^6$).
3. Resistor wattages are 1/4W or 1/6W unless otherwise specified.
4. All capacitance values are indicated in μF ($P = 10^{-6} \mu F$).
5. All voltages are DC voltages unless otherwise specified.

LIST OF CAUTION, NOTES, AND SYMBOLS USED IN THE SCHEMATIC DIAGRAMS ON THE FOLLOWING PAGES:

1. CAUTION:

CAUTION: FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE ONLY WITH SAME TYPE_A,_V FUSE.

ATTENTION: UTILISER UN FUSIBLE DE RECHANGE DE MÊME TYPE DE_A,_V.

2. CAUTION:

Fixed Voltage (or Auto voltage selectable) power supply circuit is used in this unit.


If Main Fuse (F602) is blown, first check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply. Otherwise it may cause some components in the power supply circuit to fail.

3. Note:

1. Do not use the part number shown on the drawings for ordering. The correct part number is shown in the parts list, and may be slightly different or amended since the drawings were prepared.
2. To maintain original function and reliability of repaired units, use only original replacement parts which are listed with their part numbers in the parts list section of the service manual.

4. Voltage indications on the schematics are as shown below:

Plug the TV power cord into a standard AC outlet.:




5. How to read converged lines

1-D3
 ↑ Distinction Area
 Line Number
 (1 to 3 digits)

Examples:

1. "1-D3" means that line number "1" goes to the line number "1" of the area "D3".
2. "1-B1" means that line number "1" goes to the line number "1" of the area "B1".



6. Test Point Information

⊙ : Indicates a test point with a jumper wire across a hole in the PCB.

□→ : Used to indicate a test point with a component lead on foil side.

⊗ : Used to indicate a test point with no test pin.


● : Used to indicate a test point with a test pin.

The reference number of parts on Schematic Diagrams/CBA can be retrieved by application search function.

Power Supply 1 Schematic Diagram

CAUTION !

Fixed voltage (or Auto voltage selectable) power supply circuit is used in this unit. If Main Fuse (F602) is blown, check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply. Otherwise it may cause some components in the power supply circuit to fail.




CAUTION ! : For continued protection against risk of fire,
replace only with same type 2.5A, 250V fuse.


ATTENTION : Utiliser un fusible de rechange de même type de 2.5A, 250V.

NOTE:


The voltage for parts in hot circuit is measured using hot GND as a common terminal.



Power Supply 2 Schematic Diagram




Function Schematic Diagram



Digital Main 1 Schematic Diagram

*1 NOTE:
The order of pins shown in this diagram is different from that of actual IC3101.
IC3101 is divided into eight and shown as IC3101 (1/8) ~ IC3101 (8/8) in this Digital Main Schematic Diagram Section.




Digital Main 2 Schematic Diagram

***1 NOTE:**

The order of pins shown in this diagram is different from that of actual IC3101.

IC3101 is divided into eight and shown as IC3101 (1/8) ~ IC3101 (8/8) in this Digital Main Schematic Diagram Section.



4


3



1

Digital Main 5 Schematic Diagram

*1 NOTE:
The order of pins shown in this diagram is different from that of actual IC3101.
IC3101 is divided into eight and shown as IC3101 (1/8) ~ IC3101 (8/8) in this Digital Main Schematic Diagram Section.




Digital Main 6 Schematic Diagram


***1 NOTE:**

The order of pins shown in this diagram is different from that of actual IC3101.

IC3101 is divided into eight and shown as IC3101 (1/8) ~ IC3101 (8/8) in this Digital Main Schematic Diagram Section.



Digital Main 7 Schematic Diagram




Digital Main 8 Schematic Diagram

***1 NOTE:**


The order of pins shown in this diagram is different from that of actual IC3101.

IC3101 is divided into eight and shown as IC3101 (1/8) ~ IC3101 (8/8) in this Digital Main Schematic Diagram Section.




Digital Main 9 Schematic Diagram

*1 NOTE:
The order of pins shown in this diagram is different from that of actual IC3101.
IC3101 is divided into eight and shown as IC3101 (1/8) ~ IC3101 (8/8) in this Digital Main Schematic Diagram Section.




Digital Main 10 Schematic Diagram




Digital Main 11 Schematic Diagram


*2 NOTE:
The order of pins shown in this diagram is different from that of actual IC3501.



Smart Link 1 Schematic Diagram




Smart Link 2 Schematic Diagram



Power Supply CBA Top View

CAUTION !
Fixed voltage (or Auto voltage selectable) power supply circuit is used in this unit.
If Main Fuse (F602) is blown , check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply.
Otherwise it may cause some components in the power supply circuit to fail.




4A 125V

CAUTION ! : For continued protection against risk of fire,
replace only with same type 4A, 125V fuse.

ATTENTION : Utiliser un fusible de rechange de même type de 4A, 125V.


Because a hot chassis ground is present in the power supply circuit, an isolation transformer must be used when repairing.
Also, in order to have the ability to increase the input slowly, when troubleshooting this type of power supply circuit, a variable isolation transformer is required.

NOTE:
The voltage for parts in hot circuit is measured using hot GND as a common terminal.




Power Supply CBA Bottom View

CAUTION !
Fixed voltage (or Auto voltage selectable) power supply circuit is used in this unit.
If Main Fuse (F602) is blown , check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply.
Otherwise it may cause some components in the power supply circuit to fail.


 **CAUTION ! :** For continued protection against risk of fire,
replace only with same type 4A, 125V fuse.
ATTENTION : Utiliser un fusible de rechange de même type de 4A, 125V.

Because a hot chassis ground is present in the power supply circuit, an isolation transformer must be used when repairing.
Also, in order to have the ability to increase the input slowly, when troubleshooting this type of power supply circuit, a variable isolation transformer is required.


NOTE:
The voltage for parts in hot circuit is measured using hot GND as a common terminal.




WIRING DIAGRAM



EXPLODED VIEWS




Packing





Some Ref. Numbers
are not in sequence.


MECHANICAL PARTS LIST

PRODUCT SAFETY NOTE: Products marked with a  have special characteristics important to safety. Before replacing any of these components, read carefully the product safety notice in this service manual. Don't degrade the safety of the product through improper servicing.


NOTE: Parts that are not assigned part numbers (-----) are not available.

Ref. No.	Description	Part No.
A3	REAR COVER A37TZUH	1EM128495
A4-1	BOTTOM COVER R A3AT0UH	1EM030208
A4-2	BOTTOM COVER L A3AT0UH	1EM030209
A13	JACK HOLDER A37QZUH	1EM335217
A15 	RATING LABEL A37TZUH	-----
A16	LOGO LABEL A37QZUH	-----
A17	ENERGY GUIDE LABEL A37TZUH	-----
AC601 	AC CORD W/O A GND WIRE UL/CSA/3160/NO/BLACK	WAC312LTE001
B10	STAND BRACKET A3AT0UH	1EM127821
B17	WALL_MOUNT_BRACKET A11N0UH	1EM434637
B18	WALL_MOUNT_COVER A2170UT	1EM332137
B23	WIRE LABEL A3AF0UT	-----
CL3101	FFC WIRE ASSEMBLY 9PIN 9PIN/WHITE/240MM	WX1A3AT0S106
CL3701	FFC WIRE ASSEMBLY 23PIN 23PIN/WHITE/158MM	WX1A37TZS101
CL3801	WIRE ASSEMBLY 4PIN 4PIN/395MM&110MM	WX1A3AT0C301
L7	SCREW P-TIGHT 3X10 BIND HEAD+	GBHP3100
L23	SCREW S-TIGHT M3X6 BIND HEAD+	GBJS3060
L24	S-TIGHT SCREW M3X6 BIND HEAD+BLACK	GBHS3060
SA1	39D STAND ASSEMBLY A3ATZUH	1EM031045
SP3801	SPEAKER MAGNETIC 8OHM/8W S0310F15	DS08110XQ003
SP3802	SPEAKER MAGNETIC 8OHM/8W S0310F15	DS08110XQ003
SSK1	STAND SCREW KIT A3AT0UH(DOUBLE SEMS SCREW M4X20 + BLK)	1ESA34649
SSK2	STAND SCREW KIT(SEcurity) A3ATZUH(SEcurity SCREW M4X20 A3ATZUH)	2ESA00308
PACKING		
S1	CARTON A37TYUH	2EMC00067
S3	STYROFOAM TOP A3AT0UH	1EM030605A
S4	STYROFOAM BOTTOM A3AT0UH	1EM030606
S6	SET BAG A31PBUH	2EMC00084
S7	SERIAL NO. LABEL A17FZUH	-----
S10	PAD A3AT0UH	2EMC00176
ACCESSORIES		
X1	POLYETHYLENE BAG HDPE 180X340XT0.03	1EM435579
X6	QUICK START GUIDE A37TYUH	2EMN00058
X19	WARRANTY SHEET A17FZUH	1EMN29039
X20	SECURITY SCREW KIT A17FZUH	1EM332298
X21	SECURITY TAPE KIT A17FZUH	1EM332299
X22	WARNING MESSAGE FLIER A3AU2UH	2EMN00059A

LCD PANEL ASSEMBLY

Ref. No.	Description	Part No.
LCD1 	LCD PANEL ASSEMBLY	U30T2P2
	Consists of the following	
A1	FRONT CABINET A3ATAMA	2EMM00092
A6	CONTROL PLATE A31F0UT	1EM334317
A9	SENSOR LENS A3AF0UT	1EM334258
A21	BLIND LABEL A3AU0UH	-----
B12	SHIELD PLATE A3AF0UT	1EM334260
CL3011	FFC WIRE ASSEMBLY 51PIN(W/SHIELD) 51P/FFC/SHIELD/644MM	WX1A37TZP401
L7	SCREW P-TIGHT 3X10 BIND HEAD+	GBHP3100
	LCD MODULE	-----

ELECTRICAL PARTS LIST

PRODUCT SAFETY NOTE: Products marked with a  have special characteristics important to safety. Before replacing any of these components, read carefully the product safety notice in this service manual. Don't degrade the safety of the product through improper servicing.

NOTES:

- Parts that are not assigned part numbers (-----) are not available.
- Tolerance of Capacitors and Resistors are noted with the following symbols.

C.....±0.25% D.....±0.5% F.....±1%
 G.....±2% J.....±5% K.....±10%
 M.....±20% N.....±30% Z.....+80/-20%

DIGITAL MAIN CBA UNIT

Ref. No.	Description	Part No.
	DIGITAL MAIN CBA UNIT	A37TZMMA-001
IC3101	IC MAIN PH1 MN2WS0251A	QSCA0R0MS049
IC3102	IC NAND FLASH 2GB K9F2G08U0C-SCB0	NSCA0R0SM038
IC3103	16KBIT EEPROM M24C16-WMN6TP	NSZBA0TSS259
IC3501	IC PRO_IDIOM LG1001	NSCA0R0GS003
IC3504	IC ANALOG MULTIPLEXERS HCF4053M013TR	NSZBA0SSS002
IC3505	LOGIC IC TC7SH04FU	QSZBA0TTS201
IC3506	IC MICON SSOP20 WT51F516-UG320WT	NSCA0TWTLT006
IC3601	IC DCDC CONVERTER MP2303ADN-C258/ SOIC8	NSCA0T09M013
IC3602	IC SYSTEM POWER AN34043AA	QSCA0T0MS048
IC3603	IC DCDC CONVERTER MP2482DN-LF-Z/ SOIC8/	NSCA0T09M005
IC3605	IC DCDC CONVERTER MP2303ADN-C258/ SOIC8	NSCA0T09M013
IC3606	IC DCDC CONVERTER MP2303ADN-C258/ SOIC8	NSCA0T09M013
IC3607	IC DCDC CONVERTER MP2303ADN-C258/ SOIC8	NSCA0T09M013
IC3701	IC USB HIGH-SIDE SW NCP380HSN05AAT1G	NSCA0T0MT007
IC3801	IC D-CLASS AUDIO POWER AMPLIFI TPA3110D2PWPR	NSCA0T0TY073
IC3902	IC ETHERNET RTL8201FL-VB-CG	NSCA0R0R004
TU3001	TUNER UNIT U9001UH	U9001UH
	When you replace one of the below ICs on this CBA, replace with the one that has the same part number. Do not mix ICs with different part number.	
IC3401	IC 2GB DDR3 SDRAM K4B2G1646E-BCK0	NSCA0R0SM054
IC3402	IC 2GB DDR3 SDRAM K4B2G1646E-BCK0	NSCA0R0SM054
	or	
IC3401	IC 2GB DDR3 SDRAM H5TQ2G63DFR-PBC/ FBGA	NSCA0R0HY034
IC3402	IC 2GB DDR3 SDRAM H5TQ2G63DFR-PBC/ FBGA	NSCA0R0HY034

SMART LINK CBA UNIT

Ref. No.	Description	Part No.
	SMART LINK CBA UNIT	A37TZMSL-001
IC1151	IC VIDEO SWITCH TSSOP-PW/14PIN	NSCA0T0TY104
IC1401	IC HEX BUFFER TSSOP/14PIN	NSCA0TNXP032
IC1501	IC MICON MC9S12XS64CAE/LQFP64	NSCA0RFSC001
IC1502	IC FSK RECEIVER SSOP20 NJM2295A	QSCA0T0JR021

FUNCTION CBA UNIT

Ref. No.	Description	Part No.
	FUNCTION CBA UNIT	A3ATZMSW-001

POWER SUPPLY CBA

Ref. No.	Description	Part No.
	POWER SUPPLY CBA Consists for the following	A37TZMPW-001
CAPACITORS		
C602	SAFTY CAP. 2200pF/250V KX	CA2E222MR101
C604	CAP METALLIZED FILM 0.22μF/275V/K	CTA224PKR001
C605	CAP ELE 220μF/200V/M85	CEB2210S6016
C606	CERAMIC CAP. 680pF/2kV	CA3D681PAN04
C607	CHIP CERAMIC CAP. B K 1200pF/50V	CHD1JK30B122
C608	CHIP CERAMIC CAP.(1608) B K 0.033μF/50V	CHD1JK30B333
C609	CHIP CERAMIC CAP. B K 0.068μF/50V	CHD1JK30B683
C610	CHIP CERAMIC CAP. B K 1500pF/50V	CHD1JK30B152
C611	CAP ELE 220μF/200V/M85	CEB2210S6016
C612	CAP CERAMIC HV 1500PF 1kV B K	CA3A152TE006
C614	CAP METALLIZED FILM 0.22μF/275V/K	CTA224PKR001
C623	CHIP CERAMIC CAP.(1608) B K 4.7μF/6.3V	CHD0KK30B475
C650	CAP CERAMIC HV 2200pF/1kV B K	CA3A222TE006
C651	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C652	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C653	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C654	ELECTROLYTIC CAP. 470μF/16V M(105C)	CE1CMASTH471
C655	ELECTROLYTIC CAP. 470μF/16V M(105C)	CE1CMASTH471
C656	ELECTROLYTIC CAP. 10μF/50V M(105C)	CE1JMASTH100
C660	CHIP CERAMIC CAP.(1608) B K 0.1μF/50V	CHD1JK30B104
C667	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C668	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C1001	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C1002	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105
C1102	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C1103	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105
C1104	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105
C1105	CHIP CERAMIC CAP.(1608) B K 0.047μF/25V	CHD1EK30B473
C1106	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105
C1107	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1108	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105
C1109	CHIP CERAMIC CAP.(1608) B K 1000pF/50V	CHD1JK30B102
C1110	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105
C1112	ELECTROLYTIC CAP SK100M470VZZP50R	CE2AMASTH470
C1113	ELECTROLYTIC CAP SK100M470VZZP50R	CE2AMASTH470
C1115	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1116	CHIP CERAMIC CAP.(3216) X7R K 1.0μF/100V	CA2A105MR080
C1117	CHIP CERAMIC CAP.(3216) X7R K 1.0μF/100V	CA2A105MR080
C1119	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1202	ELECTROLYTIC CAP. 470μF/25V M(105C)	CE1EMASTH471
C1203	CHIP CERAMIC CAP.(1608) B K 1μF/25V	CHD1EK30B105

Ref. No.	Description	Part No.
C1204	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1205	CHIP CERAMIC CAP(1608) B K 0.047µF/25V	CHD1EK30B473
C1206	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1207	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1208	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1209	CHIP CERAMIC CAP(1608) B K 1000pF/50V	CHD1JK30B102
C1210	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1212	ELECTROLYTIC CAP SK100M470YZZP50R	CE2AMASTH470
C1213	ELECTROLYTIC CAP SK100M470YZZP50R	CE2AMASTH470
C1215	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1216	CHIP CERAMIC CAP(3216) X7R K 1.0µF/100V	CA2A105MR080
C1217	CHIP CERAMIC CAP(3216) X7R K 1.0µF/100V	CA2A105MR080
C1219	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1302	ELECTROLYTIC CAP. 470µF/25V M(105C)	CE1EMASTH471
C1303	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1304	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1305	CHIP CERAMIC CAP(1608) B K 0.047µF/25V	CHD1EK30B473
C1306	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1307	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1308	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1309	CHIP CERAMIC CAP(1608) B K 1000pF/50V	CHD1JK30B102
C1310	CHIP CERAMIC CAP(1608) B K 1µF/25V	CHD1EK30B105
C1312	ELECTROLYTIC CAP SK100M470YZZP50R	CE2AMASTH470
C1313	ELECTROLYTIC CAP SK100M470YZZP50R	CE2AMASTH470
C1315	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
C1316	CHIP CERAMIC CAP(3216) X7R K 1.0µF/100V	CA2A105MR080
C1317	CHIP CERAMIC CAP(3216) X7R K 1.0µF/100V	CA2A105MR080
C1319	CHIP CERAMIC CAP. B K 2200pF/50V	CHD1JK30B222
CONNECTORS		
CN501	FFC CONNECTOR IMSA-9615S-23A-PP-A	JC96J23ER007
CN601▲	CONNECTOR S2P3-VH (LF)(SN)	JCVHC02JG002
CN1001	PH CONNECTOR TOP 6P B6B-PH-K-S (LF)(SN)	J3PHC06JG029
DIODES		
D601	DIODE 1N5406BH	NDL1001N5406
D602	DIODE 1N5406BH	NDL1001N5406
D603	DIODE 1N5406BH	NDL1001N5406
D604	DIODE 1N5406BH	NDL1001N5406
D605	ZENER DIODE MM5Z6V2B	ND1BMM5Z6V2B
D606	DIODE FAST RECOVERY SMD GR1J-TR	ND1Z00GR1JTR
D607A▲	ZENER DIODE SMD TFZVTR27B	QD1B00TFZV27
D608▲	DIODE ZENER 1ZB36BB	NDWZ0001ZB36
D609A▲	DIODE SCHOTTKY SMD RB520SM-30 T2R	QD1ZRB520SM3
D610	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D621	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D623	ZENER DIODE MM5Z30B	ND1B0MM5Z30B
D650	DIODE SCHOTTKY SB3150BH	NDWZ000SB3150
D651	DIODE SCHOTTKY SB3150BH	NDWZ000SB3150
D652▲	DIODE ZENER 1ZB30BB	NDWZ0001ZB30
D653	DIODE SCHOTTKY SB3A0BH	NDWZ000SB3A0
D654▲	DIODE ZENER 1ZB20BB	NDWZ0001ZB20
D655	DIODE SCHOTTKY SB3A0BH	NDWZ000SB3A0
D656	DIODE FAST RECOVERY RS1BJTD	ND1Z0RS1BJTD
D657	ZENER DIODE MM5Z11B	ND1B0MM5Z11B
D659	DIODE SCHOTTKY SB3150BH	NDWZ000SB3150
D660	IC SHUNT REGULATOR SL431A-AT	NSZBA0TAUK01
D661	RES CHIP 1608 1/10W F 4.30K kΩ	RTW4301HH008
D1101	DIODE SCHOTTKY SMD SK210TD	ND1Z0SK210TD
D1103	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D1104	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D1105	ZENER DIODE SMD TFZVTR24B	QD1B00TFZV24
D1201	DIODE SCHOTTKY SMD SK210TD	ND1Z0SK210TD
D1203	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400

Ref. No.	Description	Part No.
D1204	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D1205	ZENER DIODE SMD TFZVTR24B	QD1B00TFZV24
D1301	DIODE SCHOTTKY SMD SK210TD	ND1Z0SK210TD
D1303	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D1304	SWITCHING DIODE 1SS400 TE61	QD1Z001SS400
D1305	ZENER DIODE SMD TFZVTR24B	QD1B00TFZV24
ICS		
IC601▲	IC PHOTOCOUPLER TLP781F(D4-FUNBL F)	QPEL781FBLLF
IC1101	IC LED BACKLIGHT CONTROLLER BD9488F-GE2/SOP/18P	QSCA0T0RM418
IC1201	IC LED BACKLIGHT CONTROLLER BD9488F-GE2/SOP/18P	QSCA0T0RM418
IC1301	IC LED BACKLIGHT CONTROLLER BD9488F-GE2/SOP/18P	QSCA0T0RM418
COILS		
L601▲	LINE FILTER JLB24136	LLEG0Z0XB032
L602▲	LINE FILTER JLB24136	LLEG0Z0XB032
L1101	COIL POWER INDUCTORS DIP RP1315BNP-101M/100µH	LLF1010SF013
L1102	CHIP INDUCTOR BK1608HS220-T	LLC220NTU017
L1201	COIL POWER INDUCTORS DIP RP1315BNP-101M/100µH	LLF1010SF013
L1202	CHIP INDUCTOR BK1608HS220-T	LLC220NTU017
L1301	COIL POWER INDUCTORS DIP RP1315BNP-101M/100µH	LLF1010SF013
L1302	CHIP INDUCTOR BK1608HS220-T	LLC220NTU017
TRANSISTORS		
Q601▲	FET MOS TK10A50D(LS1FN3 QM	QEEZTK10A50D
Q602▲	NPN TRANSISTOR SMD 2SC5344SY	NQZY2SC5344S
Q621	CHIP TRANSISTOR KTC3875S-Y-RTK/P	NQ1YKTC3875S
Q650	CHIP TRANSISTOR KTC3875S-Y-RTK/P	NQ1YKTC3875S
Q653	CHIP TRANSISTOR KTC3875S-Y-RTK/P	NQ1YKTC3875S
Q1101	FET MOS SMD AP18T10AGH-HF	NF2Z18T10AGH
Q1102	FET MOS SMD AP18T10AGH-HF	NF2Z18T10AGH
Q1201	FET MOS SMD AP18T10AGH-HF	NF2Z18T10AGH
Q1202	FET MOS SMD AP18T10AGH-HF	NF2Z18T10AGH
Q1301	FET MOS SMD AP18T10AGH-HF	NF2Z18T10AGH
Q1302	FET MOS SMD AP18T10AGH-HF	NF2Z18T10AGH
RESISTORS		
R601▲	RES. CARBON FILM J 1/2W J 1.2M Ω	RCX2125T1003
R603	RES CHIP 3216 1/4W J 560k Ω	RRX4564HH034
R604	RES CHIP 3216 1/4W J 560k Ω	RRX4564HH034
R606	RES CHIP 3216 1/4W J 120 Ω	RRX4121HH034
R607	RES CHIP 3216 1/4W J 120 Ω	RRX4121HH034
R608	RES CHIP 3216 1/4W J 1.5k Ω	RRX4152HH034
R609	RES CHIP 1608 1/10W J 100 Ω	RRXA101HH013
R611▲	METAL OXIDE RES. 2W J 0.3 Ω	RN02R30ZU001
R612	RES CHIP 3216 1/4W J 3.9k Ω	RRX4392HH034
R613	RES CHIP 3216 1/4W J 270 Ω	RRX4271HH034
R614	RES CHIP 3216 1/4W J 560k Ω	RRX4564HH034
R619	METAL OXIDE FILM RES. 1W J 100k Ω	RN01104ZU001
R621	RES CHIP 1608 1/10W J 560 Ω	RRXA561HH013
R622	RES CHIP 1608 1/10W 0 Ω	RRXA000HH014
R623	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R651▲	RES CHIP 1608 1/10W J 1.0 Ω	RRXA1R0HH013
R652	RES CHIP 1608 1/10W F 100k Ω	RTW1003HH008
R653	RES CHIP 1608 1/10W 0 Ω	RRXA000HH014
R654	RES CHIP 3216 1/4W J 180 Ω	RRX4181HH034
R655	RES CHIP 3216 1/4W J 180 Ω	RRX4181HH034
R656	RES CHIP 1608 1/10W F 82.0k Ω	RTW8202HH008
R657	RES CHIP 3216 1/4W J 3.9k Ω	RRX4392HH034
R658	RES CHIP 1608 1/10W J 2.7k Ω	RRXA272HH013
R659	RES CHIP 1608 1/10W F 22.0k Ω	RTW2202HH008
R660	RES CHIP 1608 1/10W F 2.70k Ω	RTW2701HH008

Ref. No.	Description	Part No.
R661	RES CHIP 1608 1/10W F 15.0k Ω	RTW1502HH008
R663	RES CHIP 3216 1/4W J 4.7k Ω	RRXA4472HH034
R668	RES CHIP 1608 1/10W J 47k Ω	RRXA473HH013
R669	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R677	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R694	RES CHIP 1608 1/10W J 15k Ω	RRXA153HH013
R1101	RES CHIP 1608 1/10W F 22.0k Ω	RTW2202HH008
R1102	RES CHIP 1608 1/10W F 9.10k Ω	RTW9101HH008
R1103	RES CHIP 1608 1/10W F 9.10k Ω	RTW9101HH008
R1104	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R1105	RES CHIP 1608 1/10W J 1.0k Ω	RRXA102HH013
R1106	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R1107	RES CHIP 1608 1/10W J 100k Ω	RRXA104HH013
R1108	RES CHIP 1608 1/10W J 100k Ω	RRXA104HH013
R1109	RES CHIP 1608 1/10W J 120 Ω	RRXA121HH013
R1110	RES CHIP 1608 1/10W J 120 Ω	RRXA121HH013
R1111	RES CHIP 1608 1/10W F 240k Ω	RTW2403HH008
R1112	RES CHIP 1608 1/10W F 33.0k Ω	RTW3302HH008
R1113	RES CHIP 1608 1/10W F 3.00k Ω	RTW3001HH008
R1114	RES CHIP 1608 1/10W F 100k Ω	RTW1003HH008
R1115	METAL OXIDE FILM RES. 2W J 0.18 Ω	RN02R18ZU001
R1116	RES CHIP 1608 1/10W J 200 Ω	RRXA201HH013
R1117	RES CHIP 1608 1/10W J 10 Ω	RRXA100HH013
R1118	RES CHIP 1608 1/10W J 33 Ω	RRXA330HH013
R1119	RES CHIP 1608 1/10W F 160k Ω	RTW1603HH008
R1120	RES CHIP 1608 1/10W 0 Ω	RRXA000HH014
R1121	RES CHIP 1608 1/10W F 10.0k Ω	RTW1002HH008
R1122	RES CHIP 3216 1/4W J 1.1k Ω	RRXA112HH034
R1123	RES CHIP 3216 1/4W J 1.5k Ω	RRXA152HH034
R1124	RES CHIP 1608 1/10W J 1.0k Ω	RRXA102HH013
R1125	RES CHIP 1608 1/10W J 51 Ω	RRXA510HH013
R1126	RES CHIP 3216 1/4W F 1.00 Ω	RT1R00RYL007
R1127	RES CHIP 3216 1/4W F 1.00 Ω	RT1R00RYL007
R1201	RES CHIP 1608 1/10W F 22.0k Ω	RTW2202HH008
R1202	RES CHIP 1608 1/10W F 9.10k Ω	RTW9101HH008
R1203	RES CHIP 1608 1/10W F 9.10k Ω	RTW9101HH008
R1204	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R1205	RES CHIP 1608 1/10W J 1.0k Ω	RRXA102HH013
R1206	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R1207	RES CHIP 1608 1/10W J 100k Ω	RRXA104HH013
R1208	RES CHIP 1608 1/10W J 100k Ω	RRXA104HH013
R1209	RES CHIP 1608 1/10W J 120 Ω	RRXA121HH013
R1210	RES CHIP 1608 1/10W J 120 Ω	RRXA121HH013
R1211	RES CHIP 1608 1/10W F 240k Ω	RTW2403HH008
R1212	RES CHIP 1608 1/10W F 33.0k Ω	RTW3302HH008
R1213	RES CHIP 1608 1/10W F 3.00k Ω	RTW3001HH008
R1214	RES CHIP 1608 1/10W F 100k Ω	RTW1003HH008
R1215	METAL OXIDE FILM RES. 2W J 0.18 Ω	RN02R18ZU001
R1216	RES CHIP 1608 1/10W J 200 Ω	RRXA201HH013
R1217	RES CHIP 1608 1/10W J 10 Ω	RRXA100HH013
R1218	RES CHIP 1608 1/10W J 33 Ω	RRXA330HH013
R1219	RES CHIP 1608 1/10W F 160k Ω	RTW1603HH008
R1220	RES CHIP 1608 1/10W 0 Ω	RRXA000HH014
R1221	RES CHIP 1608 1/10W F 10.0k Ω	RTW1002HH008
R1222	RES CHIP 3216 1/4W J 1.1k Ω	RRXA112HH034
R1223	RES CHIP 3216 1/4W J 1.5k Ω	RRXA152HH034
R1224	RES CHIP 1608 1/10W J 1.0k Ω	RRXA102HH013
R1225	RES CHIP 1608 1/10W J 51 Ω	RRXA510HH013
R1226	RES CHIP 3216 1/4W F 1.00 Ω	RT1R00RYL007
R1227	RES CHIP 3216 1/4W F 1.00 Ω	RT1R00RYL007
R1301	RES CHIP 1608 1/10W F 22.0k Ω	RTW2202HH008
R1302	RES CHIP 1608 1/10W F 9.10k Ω	RTW9101HH008
R1303	RES CHIP 1608 1/10W F 9.10k Ω	RTW9101HH008

Ref. No.	Description	Part No.
R1304	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R1305	RES CHIP 1608 1/10W J 1.0k Ω	RRXA102HH013
R1306	RES CHIP 1608 1/10W J 10k Ω	RRXA103HH013
R1307	RES CHIP 1608 1/10W J 100k Ω	RRXA104HH013
R1308	RES CHIP 1608 1/10W J 100k Ω	RRXA104HH013
R1309	RES CHIP 1608 1/10W J 120 Ω	RRXA121HH013
R1310	RES CHIP 1608 1/10W J 120 Ω	RRXA121HH013
R1311	RES CHIP 1608 1/10W F 240k Ω	RTW2403HH008
R1312	RES CHIP 1608 1/10W F 33.0k Ω	RTW3302HH008
R1313	RES CHIP 1608 1/10W F 3.00k Ω	RTW3001HH008
R1314	RES CHIP 1608 1/10W F 100k Ω	RTW1003HH008
R1315	METAL OXIDE FILM RES. 2W J 0.18 Ω	RN02R18ZU001
R1316	RES CHIP 1608 1/10W J 200 Ω	RRXA201HH013
R1317	RES CHIP 1608 1/10W J 10 Ω	RRXA100HH013
R1318	RES CHIP 1608 1/10W J 33 Ω	RRXA330HH013
R1319	RES CHIP 1608 1/10W F 160k Ω	RTW1603HH008
R1320	RES CHIP 1608 1/10W 0 Ω	RRXA000HH014
R1321	RES CHIP 1608 1/10W F 10.0k Ω	RTW1002HH008
R1322	RES CHIP 3216 1/4W J 1.1k Ω	RRXA112HH034
R1323	RES CHIP 3216 1/4W J 1.5k Ω	RRXA152HH034
R1324	RES CHIP 1608 1/10W J 1.0k Ω	RRXA102HH013
R1325	RES CHIP 1608 1/10W J 51 Ω	RRXA510HH013
R1326	RES CHIP 3216 1/4W F 1.00 Ω	RT1R00RYL007
R1327	RES CHIP 3216 1/4W F 1.00 Ω	RT1R00RYL007
MISCELLANEOUS		
B19	HEAT SINK PNL A31T0UH	1EM439707
BC601	BEAD INDUCTORS B29 RID 2.3X7.5X7.5T	LLEF0S0XM002
BC602	BEAD INDUCTORS B29 RID 2.3X7.5X7.5T	LLEF0S0XM002
BC603	BEAD INDUCTORS B29 RID 2.3X7.5X7.5T	LLEF0S0XM002
BC604	BEAD INDUCTORS B29 RID 2.3X7.5X7.5T	LLEF0S0XM002
F602▲	FUSE TIME RAG SLT250V2.5A	PDGSLB0NG252
JS603	WIRE CP STP-S-0.50	XZ40F0REN001
JS604	WIRE CP STP-S-0.50	XZ40F0REN001
JS609	WIRE CP STP-S-0.50	XZ40F0REN001
L35	SCREW B-TIGHT D3X8 BIND HEAD+	GBJB3080
SA601▲	VARIATOR 10D 471K SVR	NVQZVR10D471
T601▲	TRANS POWER BCK-28F0	LTT2PCMEK058